


Model: YLT-40-3C

USE AND CARE GUIDE

3-PACK INDOOR WIRELESS REMOTE CONTROL



THANK YOU

We appreciate the trust and confidence you have placed in Defiant through the purchase of this indoor wireless remote control. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Defiant!

Maintenance

2 Replacing the battery



WARNING: Do not mutilate or place the battery in a fire. The battery may burst or release toxic materials. Do not short circuit or reverse polarity as this may cause burns.

- Remove the battery compartment cover from the back of the remote control by sliding the cover in the direction that its threads curve.
- Remove the old battery and place a new DC 12V Type A23 battery into the battery compartment, correctly observing the polarity indications (+/-) inside the battery compartment.
- Replace the battery compartment cover.
- Dispose or recycle spent/discharged batteries in compliance with all applicable laws. For detailed information, contact your local solid waste authority.

Troubleshooting

Problem	Solution
The lights do not turn on and off via remote control.	Confirm remote operation after replacing batteries.
The lights do not turn on, even when the power indicator light indicates that the receiver is on.	Ensure the lights are functional by plugging them directly into an outlet.
	Be sure that the lights are in the "ON" position if they have their own switch.
	Be sure that the outlet that the receiver is plugged into is active.
Remote does not turn the device on or off.	Receiver and transmitter need to be re-synched. Replug the receiver into a properly grounded outlet and within 15 seconds, press and hold the ON(2) and OFF(2) buttons on the transmitter for 2 seconds until the green indicator flash 3 times on the receiver.

Safety Information

Federal Communications Commission Interference Statement

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter. Store indoors when not in use.



WARNING:

- Do not immerse the product in water or other liquids.
- This product is not intended for use by children and contains small parts that may pose a choking hazard to children under the age of three.
- Keep the product out of the reach of children and pets. Do not use an electrical device or appliance with this product whose electrical specifications exceed those specified in the "Electrical Specifications" section of this manual.


RATINGS
125 VAC, 60 Hz
15 A General Purpose
15 A Resistive
625 W Tungsten
1/3 HP Motor

Product Description



WARNING: For indoor use only.


- Power indicator light:**
The power indicator light indicates that the receiver is on.
- Outlet:**
The outlet located on the front of the receiver allows the user to plug an array of devices into it. Plug the light or device to be controlled by the remote into the outlet.
- Remote control:**
 - Channel 1 2 3 :
To control various devices with three different channels.
 - I : When the "ON" button is pressed, it will override the program to on function.
 - O : When the "OFF" button is pressed, it will override the program to off function.



Operating Instructions

1 Using the remote control

- To set up the three receivers (outlets) with various devices, locate channel 1, 2, 3, on the remote control and the 1, 2, 3, on each receiver and select ON/OFF function with same channel (1,2,3) respectively.
- To activate the receiver, press the "ON" button of the remote control. The green LED of the remote control will illuminate momentarily and the LED of the receiver will remain illuminated.
- Remove the insulation tab from the battery compartment.
- To turn the receiver OFF, press the "OFF" button of the remote control. The LED on the receiver will shut off.



Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils

radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.