Printed in China.



MODEL NO.: 1015867

THE 77 LOGO, TOMORROW'S TOMORROW, AND SPASTUDIO) ARE TRADEMARKS OR REGISTERED TRADEMARKS. DISTRIBUTED BY AND © 2022 MERCHSOURCE, LLC. IRVINE, CA 92618. ALL RIGHTS RESERVED.

SHARPER IMAGE® NAME AND LOGOS (INCLUDING

information for future reference.

YOUR PURCHASE OF THE SPASTUDIO[™] VANITY SOUND.

use. Keep this manual as it contains important

Please read all instructions and warnings prior to

CONGRATULATIONS ON

MIRROR FEATURES

• Main mirror rotates 360°.

. Front of main mirror features a distortion-free Δx reflection.

· Rear of main mirror features 5x magnification.

Magnetic mini mirror features 10x magnification.

· Mini mirror can be used separately or magnetically attached towards the top or

bottom of the main mirror.

of the mini mirror and then press the mini mirror firmly in place. If the gel pad loses Tip: For secure attachment in any position, peel the film from the gel pad on the back


SHARPER IMAGE[®]

SPASTUDIO™

VANITY SOUND

9-INCH LED MIRROR WITH

BUILT-IN SPEAKERS



Å Bluetooth

receiver is connected.

canse nudesired operation.

tollowing two conditions:

.oul (ວໄຊ The Bluetooth $^{\circ}$ word mark and logos are registered trademarks owned by Bluetooth

responsible for compliance could void the user's authority to operate the equipment. Warning: Changes or modifications to this unit not expressly approved by the party

- Connect the equipment into an outlet on a circuit different from that to which the

turning the equipment off and on, the user is encouraged to $\ensuremath{\mathsf{tr}}\xspace \gamma$ to correct the harmful interference to radio or television reception, which can be determined by interference will not occur in a particular installation. If this equipment does cause interterence to radio communications. However, there is no guarantee that and, if not installed and used in accordance with the instructions, may cause harmful installation. This equipment generates, uses and can radiate radio frequency energy

provide reasonable protection against harmful interference in a residential

B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

Note: This equipment has been tested and tound to comply with the limits for a Class

2. This device must accept any interterence received, including interterence that may

This device complies with Part 15 of the FCC Rules. Operation is subject to the

- Consult the dealer or an experienced radio/TV technician for help.


- Increase the separation between the equipment and receiver.

- Reorient or relocate the receiving antenna.

interference by one or more of the following measures:

1. This device may not cause harmful interference, and

FCC STATEMENT



use it to directly power other devices. 3. Plug the adapter end of the cable into a wall outlet. The red LED on the front of the 4. To charge another device from the Vanity Sound, plug a USB-C power cable (not included) into the USB-C output port on the rear left of the Vanity Sound base and then connect the device you want to charge. The Vanity Sound provides pass-through charging when plugged into a wall outlet. To power a device when the Vanity Sound is unplugged but the internal battery is

Β.

Ņ,

0

0

Ņ.

χ,

ò.

ð,

charged, connect the device to the USB-C output port on the rear left of the Vanity Sound base and then power on the Bluetooth speaker. The Vanity Sound will act as a power bank

HOW TO USE TURN BLUETOOTH SPEAKER ON/OFF

LED Light

Low

LED Light

Medium

(FRONT)

LED Light

High

- 1. To turn on the Bluetooth speaker, press and hold the power button on the rear of the Vanity Sound base (Figure A).
- 2. To turn off the Bluetooth speaker, press and hold the power button on the rear of the Vanity Sound base. A tone will play indicating it has shut down (Figure A).

TURN LIGHT RING ON/OFF

(BACK)

- 1. To turn on the light ring, press and hold the left dot in the touch bar located on the front of the Vanity Sound base (Figure B).
- To adjust light brightness, swipe across the touch bar or tap to choose from the 3 presets low, medium and high (Figure C).
 To turn off the light ring, long press the left dot in the touch bar (Figure D).

CONNECTING BLUETOOTH

- 1. Turn on the Bluetooth speaker and the Vanity Sound will automatically enter pairing
- 2. On the device you want to pair with the Vanity Sound, select to connect to the "SI Vanity Speaker Mirror 9 Inch" - see your device manufacturer's instructions for pairing your device.
- Note: After the initial pairing, the mirror will automatically connect to the device when powered on. A tone will play indicating it has connected.

PLAY MUSIC

- 1. Once your device is connected, adjust the speaker volume by turning the control knob in front of the Vanity Sound base. Turn the knob clockwise to increase volume or counterclockwise to decrease volume (Figure E). 2. To pause or resume tracks, press the control knob (Figure F).
- Note: To search or skip tracks, use your connected device

MAKE CALLS

- To answer an incoming call, short press the control knob (Figure F). The call will be made using the speaker and built-in microphone.
 To end an ongoing call, short press the control knob (Figure F).
 To reject incoming calls, long press the control knob for approximately 2 seconds (Figure F).

RECHARGEABLE BATTERY WARNINGS:

- This product contains batteries that are non-replaceable.
- · There is a risk of fire and personal injury if battery is punctured, damaged, or misused.
- · Do not dismantle, crush, incinerate or short-circuit battery.
- Never expose battery to extreme temperatures or moisture.
- Keep away from flammable materials and direct sunlight.
- Only charge using the provided charger, cable, and/or adapters.
- Rechargeable battery is only to be charged by an adult.
- Adult supervision is required while charging the battery.
- Allow battery to cool to room temperature before charging.
- Charge on a non-flammable surface and keep away from flammable products. · Discontinue charging if battery becomes hot, swells, smokes, or gives off a strong
- Battery chargers used with the product are to be regularly examined for damage to the cord, plug, enclosure, and other parts. In the event of such damage, chargers
- must not be used until the damage has been repaired. Recycle or dispose of battery according to federal, state, and local laws.
- Keep these instructions for future reference.

SAFETY WARNINGS: PLEASE READ ALL SAFETY WARNINGS **BEFORE USE**

- Not intended for children under 14 years of age.
- Keep out of reach of children.
- ·Use this product only for its intended use. Do not use attachments of any kind. · Use this item has no user serviceable components. Do not disassemble.
- · Do not expose to extreme temperatures or moisture.
- · Keep away from sources of water
- · Thoroughly inspect products before every use. If the product appears worn,
- frayed/splintered, cracked, or broken in any manner, discontinue use and discard immediately