


YD-005 User Manual

Suitable for 6 years old and above



Get 24/7 assistance at



Use camera or QR scanner to scan
Visit: <https://attpofterservice.vip>
Call: +1 (833) 307 2271 (Toll-free)
Email: attpo@afterservice.vip

www.attpoys.com

Customer Service Email : attpo@afterservice.vip



Made in China

Attention

- Electric control product: This product is suitable for 6 years old and above. It is assembled/charged by adults and then played by children.
- Please use the product under the supervision of adults. Please do not dismantle or modify the product without authorization. Any modification may cause the product to be unable to be used normally.



Precautions for Use

1. The toy car uses a 3.7V rechargeable lithium battery, the remote controller uses 2X1.5V "AA" non-rechargeable batteries, the watch remote control uses 2X1.5V "AAA" non-rechargeable batteries.
2. Battery removal and loading, should be carried out correctly according to the polarity and voltage in the toy battery box.
3. Uncharged battery not rechargeable.
4. The rechargeable battery must be charged under adult supervision.
5. The rechargeable battery should be taken out of the toy before charging.
6. Different types of batteries or old and new batteries can't be used in mix.
7. The car body must use the original configuration of battery. And the original USB cable must be used to charge the battery.
8. The run out of battery should be removed from the toys, If you haven't used it for a long time, please remove the toy's battery.
9. The power terminal shall not be short-circuited.
10. Use a screwdriver turned on the remote control battery cover screw, across the electrodes in the correct polarity into the battery, use a screwdriver on the battery cover screw drive at the end of the screw, the battery plug wire connected to the body the power cord in the correct polarity.
11. Repair and maintenance: this product is a plastic, hardware and electronic components, regularly check the wires, plugs, casing and other parts for defects and found defects should stop using, and restored.

2.4G Automatic Code Matching Specification

1. Install the battery on the remote control and press the remote control switch, then the indicator light flashes, turn on the switch of the remote control car, and it enters the state to be connected. When the connection is successful, the indicator light of the remote control is off, and the indicator light of the remote control car is always on. Note: If the connection is not successful, please repeat the above operation.
2. One remote control corresponds to a car, when the connection is successful, it will not be disturbed. Note: Not connect to many cars at the same time.
3. When the code matching of the remote control fails, it will enter sleep mode 45 seconds later, and it will enter sleep mode 5 minutes later when there is no operation after the code matching.
4. When it is necessary to match other remote controls or remote controlled car of the same model, press and hold the remote control switch for 2 seconds and turn off the power switch of the remote control car before re-matching.


Description to the Functions of Remote Control



Uses 2X1.5V "AA" Batteries

How to Recharge

1. This 3.7V lithium battery is new, before playing please charge the battery.
2. Need to first plug the battery cord in accordance with the correct polarity connection in the charger plug, and then plug the charger in the socket. (Note: Do not use the quick-charge charging device to charge, to avoid burning out the USB charging cable.)
3. It takes 2-3 hour to fully charge the battery, charging plug with indicator light, red light on when charging, light off when full. Please don't over charge, charging for a long time will not increase the power.
4. Check toys and batteries regularly. If accessories, batteries, charging cables, etc. are damaged, stop using them immediately. After repairing or renewing, can continue to using.



How to Install Batteries

1. Remote controller
 - (1) Open the battery cover of the remote control and load 1.5V "AA" battery according to the positive and negative polarity of the battery compartment.
 - (2) Cover the battery cover and lock the screws.
2. Remote control car
 - (1) Open the bottom battery cover and connect the rechargeable battery to the power outlet and load it into the bottom of the car.
 - (2) Cover the battery cover and lock the screws.

Operations of Remote Control and Cars


Operate the "Forward / Backward" rocker, remote control car Forward/Backward.



Operate the "Left horizontal move / Right horizontal move" button, remote control car Left horizontal move / Right horizontal move.




Long press the "Right sideslip" button to move the remote control car to the upper right side. long press the button again to move the remote control car to the lower left side.




Short press the "Music" button to switch between background sound and turn off music. By default, there is music when starting up.

Operate the "Left/Right turn" rocker, remote control car left / right rotates, and the steering is realized with the forward and backward buttons, and the steering diameter is 1 meter.



Long press the "Left sideslip" button to move the remote control car to the upper left side. long press the button again to move the remote control car to the lower right side.




Operate the "Light control" button to control all lightsof the remote control car ON/OFF.


Operate the "Snake function" button to switch from straight forward to snake shaped forward and backward, that is straight forward+left and right twisting movements.




Short press the "Twist" button, the remote control car will be deformed and arched.
Short press the remote control car again to restore straight, and the default is straight when starting up.



Short press the "One Key Demonstration" button, all functions will be automatically demonstrated once, and actions can be freely matched. The three background tones are divided into three segments, each lasting 30 seconds. Short press the demonstration button to switch to the next background tone, and the demonstration is completed and standby.



Description of watch functions



⏻ Short press to start up, short press to suspend after starting up, long press to shut down for 2 seconds.

(M) Mode key: Press once to switch from horizontal mode to rotate mode, and press again to return to horizontal mode.

4

Operating steps

1. Short press the watch switch button, LED flash, in the code state, code unsuccessful 45 seconds sleep, the light off. Code alignment success LED slow flash: short press pause, LED is always on.
2. Open the car power switch, the code success.

Note:

- ① Watch tilt towards four 45 degree directions, can achieve the car forward direction of left, right turn and backward direction of left, right turn.
- ② Watch and remote control can not be used at the same time, when replacing the remote control, you need to turn off the power of the car and the remote control. Then turn on the car and the corresponding remote control power again.
- ③ The charging time of the car is about 2 hours.

Operation of watch remote control and car


Fist level up or down to control the remote control car twist up or down.



Fist down to control the remote control car forward.




Fist left rollover to control the remote control car left horizontal.



Fist up to control the remote control car backward.



Fist right rollover to control the remote control car right horizontal.



5

Instructions

The toy battery charger should be checked before use to prevent damage to wires and other components. If there is damage, it must be repaired before use.

General Fault Handling

Symptoms	Fault cause	Treatment method
The vehicle cannot be operated	1. The remote control is not connected or the remote control car switch is not on. 2. The remote control does not load the battery properly. 3. The rechargeable battery is weak.	1. Open the car switch, contact the remote control again. 2. Insert the battery into the remote control in the proper location. 3. The car battery is charged.
The vehicle is not controlled and the distance is close by remote control	1. Remote control or car battery, lack of electricity. 2. There may be a source of disturbance near the site.	1. Replace the battery in your remote control or recharge your car battery. 2. Replace the site.
Abnormal protection	When the function of the remote control vehicle is hindered by external forces or the power is insufficient, circuit battery short circuit.	Re-turn on the power switch or take out the battery and reload it after it is powered off.

To consumers

1. When playing with remote control cars indoors, please be careful not to damage furniture or glass.
2. Please play in a safe place outdoors. Don't play with remote control cars on the road and in crowds, so as to avoid danger.
3. When you hear thunder when playing in a remote control car outdoors, you should stop playing immediately.
4. When the wheels rotate, don't stretch your hands close to avoid injury, and don't get involved in hair, clothes, etc.
5. Do not drive the remote control car at people.
6. Do not throw or collide the remote control car.
7. Keep away from fire sources and high temperatures when placing remote control vehicles.
8. This car uses complex electronic circuits and a large number of meta-accessories. Please do not disassemble or modify the circuit board at will.
9. When the remote control car is covered with dirt and dust after playing, it must be gently wiped with a wet cloth.
10. Don't put the toy in water, it will damage the electronic components.

⚠ WARNING: The contained widgets are at risk of suffocation and are not suitable for children aged 3 and under to play with. Adults must be present when using them for supervision and guidance. This manual contains important information, which cannot be discarded for inquiry.

Disclaimer

Please read this manual carefully before using our product. This product is not recommended for people under the age of 14. By using this product, you hereby agree to this disclaimer and signify that you have read it fully. You agree that you are responsible for your own conduct and any damage caused while using this product, and its consequences. You agree to use this product only for purposes that are proper and in accordance with local regulations, terms and all applicable polices and guidelines ATTOP may make available.

6

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



Guangdong Attop Technology Co., Ltd.

Linghai Industry Zone, Laimei Road, Chenghai District, Shantou, Guangdong, China.

Website: www.attoptoy.com

Customer Service Email : atop@afterservice.vip