

# 成品尺寸: 90\*120mm 材质: 128g双铜单色双面印刷(折页)



## **STRAP INSTALLATION**



06

## **PRODUCT SPECIFICATION**

Product Name	BLUETOOTH SPEAKER
Model Name	AD-SPK1
Bluetooth Version	5.0
Battery Capacity	3600mAh
WorkingTime	12-14 hours (50 % Volume)
Charging Time	4~6 hours
Charging Current	5V <del></del> 1.8A
Driver Unit	40W = 20Wx2
Dimension	11 x 4.6 x 4.7 inches
Weight	3lbs, 13oz
	07

### **FREQUENTLY ASKED QUESTIONS**

### Q: What kind of charger should we use for the speaker? A: All common USB chargers can be used, while we suggest the ones 5V/1.8A.

Q: What is the working sequence of the speaker? A: The priority is AUX IN input, phone call in Bluetooth mode and then playing music Bluetooth mode.

Q: The speaker cannot be started up in a normal situation. A: Please plug in the charger and try in a few minutes.


Q: What if there is noise or discontinuous sound when playing? A: The speaker can be normally used within 33ft under no obstruction environment. If it is over 33ft or with obstruction, there might be noise or discontinuous sound.

Q: Why will the speaker shut down automatically when it is working? A: When there is no Bluetooth pairing or AUX IN within 10 minutes, the speaker will shut down automatically to reduce power consumption.

Q: The speaker cannot connect the once-paired cellphone. A: First, remove the speaker's pairing name from the cellphone's Bluetooth list and then short press the Bluetooth Disconnection Button to restart paring mode.

\* This speaker supports mobile phones and tablet PCs etc. Here this User Manual is illustrated based on mobile phones.

### **BASIC OPERATION**



2 Power button/ Multi -Function button Long press ② 2-3S, power on/off When a call is coming, short press ② to answer When a call is coming, double press ② to refuse During a call conversation, short press ② to end call Short press ② when playing music for Play/Pause

### ①③Volume button

Short press ① for volume down, Long press ① for previous track Short press ③ for volume up , Long press ③ for next track

### ④ TWS button Short press ④ to turn on/off TWS function Long press ④ 2-3S to disconnect Bluetooth

04

### LED INSTRUCTION Indicator TWS Indicator — AUX in port USB charging port POWER ON Blue light flashes Play/Pause: Blue light is on. When it is over the Bluetooth connection range, the Blue light flashes (back to pairing status). BLUETOOTH MODE When the speaker is left in pairing mode for over 10 minutes without any activity, it will power off utomaticallv. AUX IN MODE Green light is on Red light is on when charging; Red light will be off once fully charged CHARGING STATUS LOW BATTERY Red light flashes when battery is running low INDICATOR The TWS indicators will stay white after TWS TWS connection is successful.

## 05

