



802.11a Power Spectral Density - Ant 3


Channel 36 (5180MHz)




Channel 44 (5220MHz)




Channel 48 (5240MHz)




Channel 52(5260MHz)




Channel 60 (5300MHz)



Channel 64 (5320MHz)









802.11n-HT20 Power Spectral Density - Ant 3


Channel 36 (5180MHz)




Channel 44 (5220MHz)




Channel 48 (5240MHz)




Channel 52(5260MHz)




Channel 60 (5300MHz)



Channel 64 (5320MHz)









802.11n-HT40 Power Spectral Density - Ant 3


Channel 38 (5190MHz)




Channel 46 (5230MHz)




Channel 54 (5270MHz)




Channel 62(5310MHz)




Channel 102 (5510MHz)




Channel 110 (5550MHz)






802.11ac-VHT20 Power Spectral Density - Ant 3


Channel 36 (5180MHz)




Channel 44 (5220MHz)




Channel 48 (5240MHz)




Channel 52(5260MHz)




Channel 60 (5300MHz)



Channel 64 (5320MHz)









802.11ac-VHT40 Power Spectral Density - Ant 3



Channel 38 (5190MHz)

Channel 46 (5230MHz)





Channel 54 (5270MHz)


Channel 62(5310MHz)



Channel 102 (5510MHz)


Channel 110 (5550MHz)






802.11ac-VHT80 Power Spectral Density - Ant 3


Channel 42 (5210MHz)




Channel 58 (5290MHz)




Channel 106 (5530MHz)




Channel 122 (5610MHz)



Channel 138 (5690MHz)





Channel 155 (5775MHz)



802.11ac-VHT160 Power Spectral Density - Ant 3


Channel 50 (5250MHz)

Channel 114 (5570MHz)




802.11ax-HE20 Power Spectral Density - Ant 3


Channel 36 (5180MHz)




Channel 44 (5220MHz)




Channel 48 (5240MHz)



Channel 52(5260MHz)



Channel 60 (5300MHz)



Channel 64 (5320MHz)

