

User Manual Draft v1.0

Requirements

iOS

Android

Components

Setup and Installation

Awair App

Create Awair account

Connect the device to app

Connect Awair to Wifi network

Understand your environment and interests

Test and learn Awair

Awair Device

Safety

Specification

Sensors

Dimensions

Supported Wireless Security

Power Consumption

System Requirements

Wireless

Limited Warranty

Duration and Coverage

Limited Warranty

Satisfaction Return Policy

Return and Warranty Service Process

Scope of and Limitation of Warranty

Wood Material Policy

Disclaimer of Warranties

Maintenance

Troubleshooting

Requirements

You need to have Wi-Fi network in place and an Awair account to use Awair's mobile application features.

iOS

Awair supports following devices running iOS 7 or later:

- iPhone 4s or newer
- iPod touch (5th generation) or newer
- iPad (3rd generation) or newer
- iPad mini (all models)

Android


Awair will support Android devices running Jelly Bean 4.3 or later

Components


Inside the box, you'll find:

- One Awair device
- Quick starting guide card
- Power adaptor *supports international plug types
- Plugs *your region-specific plug(s) will be provided

[Awair device illustration](#)



Awair device feature



Setup and Installation

Awair App

Before you setup Awair, you will need to install Awair app on your mobile device. If you have an iOS device, please [download the Awair app](#) from Apple App Store. If you have an Android device, please [download the Awair app](#) from Google Play Store.

When you install the Awair app for the first time, you will be asked a few questions to create an account, the information you provide will help t Awair to understand your preferences and hence give more personalized tips and recommendations. You can follow the steps described below:

Create Awair account

- Start creating your Awair account. You'll be asked to provide a few pieces of personal information such as birthdate, gender, your environment where Awair is going to be

placed(number of rooms, windows, ventilation set-up, etc.) This will help Awair to learn about you and your environment better so that it can give you relevant insights when you need most..

- Confirm your email in your mailbox.

Connect the device to app

- Plug your Awair into a wall outlet and [place the device](#). Make sure you see an LED light blinking in blue.
- When you're asked to turn on Bluetooth to allow Awair to connect to accessories. Press OK.
- To assist you with a secure pairing between your Awair device and the app, four digit PIN code will be displayed on the device. Enter the PIN into the app.
- Once the blinking LED turns to solid blue, the pairing is completed and you can move on to the next steps.

Connect Awair to Wifi network

- Let's connect Awair to WiFi network. You will see the light purple LED indicator starts to blink. Select the SSID of a WiFi network that you want to connect to and enter the password.
- When your Awair is successfully connected to the WiFi network, the LED light will turn into solid purple.

Understand your environment and interests

- Let's set your Awair to get more personalized insights. Your location is needed for Awair to better understand your environment. This is the only time we want to access to your location. Once we collect your information, we don't track it any more while using Awair.
- Let's set your preference. What matters to you most? Awair is smart and learns from your habits and lifestyle preferences to give you more personalized recommendations.

Test and learn Awair

- Let's check the current conditions in your space now and see how Awair speaks to you.
- You will test and learn how to read current air quality, Awair Score, and request displaying information by knocking on wood.

If you have another Awair device, set it up from [connect the device to app](#) step. Otherwise, it is all set. Enjoy!

Awair Device

It can be used in any location, but it's recommended to be stored near standard surface levels since CO2 doesn't rise. We also suggest placing it an inch from a wall which prevents natural air flow to get a more accurate reading.

One Awair covers about 1,000 sq feet. Generally we recommend one unit per closed wall environment (example: normal sized rooms, large closets, and so on). To stay connected, our app supports an all-in-one view for multiple devices for those who have multiple units in their homes or offices.

Safety

Awair should be powered with the provided adaptor in the original box. It will not work with accessories from other manufacturers.

Disassembling and opening Awair is dangerous when the power cord is connected to any power outlet. It will void your warranty too.

Specification

Sensors

- Temperature: -40 to +125°C (-40 to +257°F)
- Humidity: 0 to 95%
- CO2: 0 to 4000 ppm
- Dust: 0 to 500 µg/m3
- VOCs
- Ambient light

Dimensions

- 6.30" (wide)
- 3.54" (tall)
- 1.97" (deep)

Supported Wireless Security

WPA, WPA2

Power Consumption

Less than 0.05kWh per month

System Requirements

- Wi-Fi connection
- Smartphone or tablet with iOS 7 or later, or Android 4 or later
- Bitfinder Awair free account

Wireless

- Working Wi-Fi connection: 802.11 b/g/n @ 2.4 GHz
- Wireless Interconnect: 802.15.4 @ 2.4 GHz
- Bluetooth 4.0 @ 2.4 GHz

" This equipment should be installed and operated with minimum 20 cm between the radiator and your body."

Limited Warranty

IMPORTANT: By using Awair (the "Device") you are agreeing to be bound by the terms of this Limited Warranty set forth below. If you do not agree to the terms of this Limited Warranty you may return the Device (in its original, unused condition) within thirty days of the date of purchase (or the return period provided by your place of purchase, whichever is longer) for a refund in accordance with our returns policy as set forth in Section 3 of this Limited Warranty. This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province or jurisdiction. The disclaimers, exclusions, and limitations of liability under this Limited Warranty will not apply to the extent prohibited by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisory service.

Duration and Coverage

One (1) year Limited Hardware Warranty. Subject to the additional terms and conditions set forth below, Bitfinder provides the following Limited Warranty only to the person or entity that originally purchased the Device from Bitfinder or from one of its authorized resellers or distributors;

Limited Warranty

Bitfinder warrants the Device against defects in materials and workmanship under normal use for a period of one (1) year from the date of original purchase and with respect to pre-orders from the date the pre-orders are shipped ("Warranty Period"). If a Device is returned to Bitfinder during the Warranty Period as provided below, and Bitfinder determines that the Device is defective, Bitfinder will either repair or replace the unit with either a new or a refurbished Awair, or refund the original purchase price (less any discounts or promotional codes) in return for the Device, at its option. If the Warranty Period has expired or is otherwise not applicable as per the

Scope and Limitation on Warranty (below), we will return the Device to you. More information about this warranty can be found at <http://support.getawair.com>.

Satisfaction Return Policy

If you are the original purchaser of the Product and you are not satisfied with this Product for any reason, you may return it in its original condition within thirty (30) days of the original purchase and receive a full refund. To return your product you need to contact customer support for an RMA number. RMA numbers are valid for 30 days after issuance, product returned after that will be returned to the customer.

Return and Warranty Service Process

Please review the online help resources at <http://support.getawair.com> prior to seeking warranty service. To obtain warranty service, you must first obtain a Return Merchandise Authorization (RMA) number from a Customer Support Representative (CSR) at Bitfinder. Customer Support contact information can be found by visiting <http://support.getawair.com>. Bitfinder may attempt to troubleshoot a warranty-related problem prior to issuing a RMA number. Bitfinder may ask for additional information upon request. Issued RMA numbers remain valid for thirty days from issuance. Once an RMA number is obtained, your Device must be shipped freight prepaid; together with proof of purchase and all accessories, either its original packaging or packaging affording an equal degree of protection, to the Bitfinder authorized distribution facility identified by the CSR. Failure to return any of the accessories may result in a delay and/or result in a credit to Bitfinder or an invoice for the missing accessories.

In performing warranty service, Bitfinder may furnish replacement parts on an exchange basis and replaced parts will become the property of Bitfinder. Replacement parts provided by Bitfinder shall be new or refurbished and of comparable quality, and may be a different part that contains compatible features and functions. You will reimburse Bitfinder for the inspection, testing and repair of returned equipment determined by Bitfinder not to be defective or which falls under one of the warranty exclusions described below (as well as pay all shipping and handling charges). In all cases, Bitfinder's determination as to whether or not the equipment is defective and covered by warranty will be final. Any replacement equipment will be warranted hereunder for remaining period of one (1) year from original purchase or with respect to pre-orders one (1) year from shipment of the pre-order.

Bitfinder reserves the right to change the method by which Bitfinder may provide warranty service to you, and your Device's eligibility to receive a particular method of service.

Scope of and Limitation of Warranty

The warranty on this Device is limited to the repair or replacement of defective Devices as described in the Limited Warranty section above. This warranty does not cover customer training and education, installation, set up or adjustment, signal or reception problems.

The Awair is not a medical device and has not been submitted for approval by the FDA and Bitfinder makes no medical claims regarding the Awair.

This warranty does not cover damage (i) due to acts of God, other forces beyond our reasonable control, such as internet or power outages, wars, riots, terrorism, labor disputes, earthquakes, floods or other events of "force majeure," accident, misuse, abuse, negligence,

commercial use or modification of, or to any part of your Device; (ii) caused by any third party product, service or system, use of the Device for purposes other than for which the Device was designed or intended, abnormal physical or electrical stress, or use in improper environmental conditions, or use of the Device in violation of written instructions provided by Bitfinder (which may be provided at the time of purchase or on its website at <http://support.getawair.com>). This warranty does not cover defects due to normal wear and tear, scratches, nicks and dents or aging. This warranty does not cover damage due to improper repair, operation or maintenance or connections to improper voltage supply or, to the extent allowed by law, attempted repair by anyone other than a facility authorized by Bitfinder to service your Bitfinder Device. This warranty does not cover consumable parts (such as batteries). This warranty gives you specific legal rights, and you may also have other rights which vary from state to state (and jurisdiction to jurisdiction).

Wood Material Policy

Wood is a natural product containing natural variations in color, tone, and graining. Bitfinder does not warrant against natural variations in color, mineral streaks, small knots, and grain variations from plank to plank. Nor does Bitfinder warrant against natural variations, color, gloss level, or U.V. discoloration between samples/ models and products. Any sample or model is for demonstrative purposes only, and such sample or model does not create a warranty of any kind that the goods you purchased shall conform thereto. Any warranties based on any such sample or models are specifically disclaimed.

Disclaimer of Warranties

TO THE EXTENT PERMITTED BY LAW, THIS WARRANTY AND THE REMEDIES SET FORTH ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. BITFINDER DISCLAIMS ALL STATUTORY AND IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS, TO THE EXTENT PERMITTED BY LAW. IN SO FAR AS SUCH WARRANTIES CANNOT BE DISCLAIMED, BITFINDER LIMITS THE DURATION AND REMEDIES OF SUCH WARRANTIES TO THE DURATION OF THIS EXPRESS WARRANTY AND, AT BITFINDER'S OPTION, THE REPAIR OR REPLACEMENT SERVICES DESCRIBED ABOVE. SOME STATES (COUNTRIES AND PROVINCES) DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY (OR CONDITION) MAY LAST, SO THE LIMITATION DESCRIBED ABOVE MAY NOT APPLY TO YOU.

Limitation of Damages. IN ADDITION TO THE ABOVE WARRANTY DISCLAIMERS, TO THE MAXIMUM EXTENT PERMITTED BY LAW, NEITHER BITFINDER NOR ITS SUPPLIERS SHALL BE RESPONSIBLE OR LIABLE WITH RESPECT TO ANY SUBJECT MATTER OF THIS AGREEMENT OR TERMS OR CONDITIONS RELATED THERETO UNDER ANY BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY OR ANY OTHER THEORY (A) FOR LOSS OR INACCURACY OF DATA OR COST OF PROCUREMENT OF SUBSTITUTE GOODS, SERVICES^o OR TECHNOLOGY, OR (B) FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING, BUT NOT LIMITED TO HEALTH CLAIMS, BUSINESS INTERRUPTION, LOSS OF REVENUES AND LOSS OF PROFITS. THE FOREGOING SHALL APPLY EVEN IF BITFINDER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. TO THE MAXIMUM EXTENT PERMITTED BY LAW, BITFINDER'S AGGREGATE CUMULATIVE LIABILITY HEREUNDER SHALL NOT EXCEED THE ORIGINAL PURCHASE PRICE PAID FOR THE DEVICE THAT CAUSED SUCH DAMAGE. CERTAIN STATES (COUNTRIES AND PROVINCES) DO NOT ALLOW THE LIMITATION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE EXCLUSIONS SET FORTH ABOVE MAY NOT APPLY TO YOU.

FCC (Federal Communications Commission)␣

␣

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. ␣

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. ␣

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:␣

- Reorient or relocate the receiving antenna.␣
- Increase the separation between the equipment and receiver.␣
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.␣
- Consult the dealer or an experienced radio/TV technical for help.␣

WARNING: *This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.* ␣

This device complies with Part 15 of the FCC's Rules. Operation is subject to the following two Conditions:␣

1. This device may not cause harmful interference, and␣
2. This device must accept any interference received, including interference that may cause undesirable operation.␣