

Getting started with Blink is easy!

Existing users skip to step 3

1. Download the Blink Home Monitor App.
2. Add your Sync Module 2.
3. Add your camera(s) to your system.

Follow the in-app instructions to complete setup.

For more detailed setup and mounting instructions go to blinkforhome.com/setup or scan the QR code.



IMPORTANT PRODUCT INFORMATION

⚠ SAFETY INFORMATION

FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

⚠ BATTERY SAFETY

The Lithium batteries accompanying this device cannot be recharged. Do not open, disassemble, bend, deform, puncture, or shred the battery. Do not modify, attempt to insert foreign objects into the battery or immerse or expose to water or other liquids. Do not expose the battery to fire, explosion, high temperature or other hazard. Fires involving lithium batteries can usually be controlled with flooding with water, except in confined spaces where a smothering agent should be used.

If dropped and you suspect damage, take steps to prevent any ingestion or direct contact of fluids and any other materials from the battery with skin or clothes. If a battery leaks, remove all batteries and recycle or dispose of them in accordance with battery manufacturer's recommendations. If fluid or other material from the battery comes into contact with skin or clothes, flush skin or clothes with water immediately. An open battery should never be exposed to water, as fire or explosion may result from exposure to water.

Insert the batteries in the proper direction as indicated by positive (+) and negative (-) markings in battery compartment. Always replace with non-rechargeable AA 1.5V Lithium batteries (lithium metal batteries) specified for this product.

Do not mix used and new batteries or batteries of different types (for example, Lithium and alkaline batteries). Always remove old,

weak, or worn-out batteries promptly and recycle or dispose of them in accordance with applicable laws and regulations.

Do not expose your device or adapter to liquids. If your device or adapter gets wet, carefully unplug all cables without getting your hands wet and wait for the device and adapter to dry completely before plugging them in again. Do not attempt to dry your device or adapter with an external heat source, such as a microwave oven or a hair dryer. If the device or adapter appear damaged, discontinue use immediately. Use only accessories supplied with the device to power your device. To avoid risk of electric shock, do not touch your device or any wires connected to your device during a lightning storm.

PRODUCT SPECIFICATIONS **Blink Indoor, Blink Outdoor**

Model Number: BCM00410U, BCM00400U, BCM00401U, BCM00411U.
Electrical Rating: 2 1.5V AA Single Use Lithium Metal batteries and optional USB 5V 1A external power supply.
Operating Temperature Range Blink Outdoor: -20 to 45° F
Operating Temperature Range Blink Indoor: 0 to 35° F

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The party responsible for FCC compliance is Amazon.com Services LLC 410 Terry Ave North, Seattle, WA 98109 USA If you wish to contact Amazon visit www.amazon.com/devicesupport, select United States, click Help & Troubleshooting, then scroll to the bottom of the

page and under the Talk to an Associate option, click on Contact Us.

Device Name: Blink Indoor, Blink Outdoor.

Model: BCM00410U, BCM00400U, BCM00401U, BCM00411U.

RECYCLING YOUR DEVICE PROPERLY

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of, or recycle, your device in accordance with your local laws and regulations. For information about recycling your device, go to www.amazon.com/devicesupport.

Additional Safety & Compliance Information

For additional safety, compliance, recycling and other important information regarding your device, please refer to the Legal and Compliance section of the About Blink menu in the Settings in your app.

BLINK TERMS & POLICIES

BEFORE USING THE BLINK DEVICE, PLEASE READ THE TERMS FOUND AT [HTTPS://BLINKFORHOME.COM/PAGES/BLINK-TERMS-WARRANTIES-AND-NOTICES](https://blinkforhome.com/pages/blink-terms-warranties-and-notices) AND ALL RULES AND POLICIES FOR THE DEVICE AND SERVICES RELATED TO THE DEVICE (INCLUDING, BUT NOT LIMITED TO, THE APPLICABLE BLINK PRIVACY NOTICE AND ANY APPLICABLE RULES OR USAGE PROVISIONS ACCESSIBLE THROUGH THE [HTTPS://BLINKFORHOME.COM/PAGES/BLINK-TERMS-WARRANTIES-AND-NOTICES](https://blinkforhome.com/pages/blink-terms-warranties-and-notices) AND ALL RULES AND POLICIES FOR THE DEVICE AND SERVICES RELATED TO THE DEVICE (INCLUDING, BUT NOT LIMITED TO, THE APPLICABLE BLINK PRIVACY NOTICE AND ANY APPLICABLE RULES OR USAGE PROVISIONS ACCESSIBLE THROUGH THE [HTTPS://BLINKFORHOME.COM/PAGES/BLINK-TERMS-WARRANTIES-AND-NOTICES](https://blinkforhome.com/pages/blink-terms-warranties-and-notices) WEBSITE OR THE BLINK APP (COLLECTIVELY, THE "AGREEMENTS"). BY USING THE BLINK DEVICE, YOU AGREE TO BE BOUND BY THE TERMS OF THE AGREEMENTS.

Your Blink device is covered by a one year Limited Warranty. Details are available at <https://blinkforhome.com/pages/blink-terms-warranties-and-notices>.

©2022 Amazon.com, Inc. or its affiliates. Amazon, Blink, and all related marks are trademarks of Amazon.com, Inc. or its affiliates.



Blink Indoor & Blink Outdoor
Quick Start Guide