

MiFa



A1

Bluetooth Speaker

USER MANUAL ▶

LISTEN.MIFA THE MUSIC POWER TO YOUR DEEP HEART!



MIFA APP



MIFA WECHAT

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID: 2AF7A-A1



- ◆ To ensure proper use and trouble-free operation, please carefully read this user manual first.
- ◆ For the first use, a full charge is recommended.
- ◆ Please use and store the product at room temperature.
- ◆ Do not throw and drop the product to avoid damages.
- ◆ Do not expose the product to fire, high temperature, direct sunlight, etc.
- ◆ Do not use organic solvents or other chemicals to clean the product.
- ◆ Do not allow small particles to get into the product.
- ◆ Please contact the seller if the cable is not matched.
- ◆ Please keep volumes of the speaker moderate to avoid temporary or permanent hearing impairment.
- ◆ Do not disassemble the product, or make any modifications to the structure or any parts of it.
- ◆ Keep the product out of children's reach.

02 Product Features

English

- ◎Wireless Bluetooth music playback
- ◎Automatically connects to the last-connected device
- ◎Built-in Mic for hands-free calls
- ◎Aux-in jack and 3.5mm audio cable for non-Bluetooth devices
- ◎Supports up to 32 GB Micro SD card
- ◎Supports MP3, WMA,WAV, FLAC, APE
- ◎Automatically turns off after 10 minutes if there is no manual operation and no device connected
- ◎Supports ring tong playing under IOS system ,others are default tone

03 Packing Contents

English



1 x A1 Bluetooth Speaker



1 x 3.5 mm Audio Cable




1 x Micro USB Cable



1 x Detachable Strap




1 x User Manual



1 x Warranty card

Power Button

- Press and hold the button for 2 seconds to turn on or turn off
- When playing music, short press to pause or play
- When a call coming, short press to answer or hang up; press and hold it for 2 seconds to reject



Volume Down Button

- Short press to decrease the volume
- Long press to play the previous song

Volume Up Button

- Short press to increase the volume
- Long press to play the next song

Other Instructions



Modes Switch

- Once powered on, the speaker enters Bluetooth pairing mode by default.
- If it is inserted with a Micro SD card or an audio cable, double press the power button to switch modes in turns: Bluetooth mode → Micro SD card mode or Aux-in mode
- If it is inserted with a Micro-SD card and an audio cable, double press the power button to switch modes in turns: Bluetooth mode → Micro SD card mode → Aux-in mode


Restart

If the speaker doesn't respond to any operation, press and hold the power button for 8 seconds to restart it.



LED Indicator

- Blue light flashes after powered on
- Blue light stays on after connected to a device
- Blue light stays on while playing
- Blue light flashes slowly when playing is paused
- Blue light flashes rapidly at the max / min volume
- Red light stays on while charging; when fully charged, red light goes off



07 Bluetooth Connection

English

1. Press and hold the power button for more than 2 seconds until it beeps and the blue LED light flashes.

2. Turn on the Bluetooth of your device and select Mifa_A1. Once the connection is completed, the speaker will beep and the blue LED light will stay on.

Note1. The speaker will connect to the last-connected device automatically once the device's Bluetooth is turned on.

Note2. The operating range is about 10m / 33 feet and will be influenced by the surroundings.

Other Instructions

To connect to another device, press and hold the volume down and volume up buttons simultaneously for more than 2 seconds. The paired one will be disconnected and the speaker will enter the pairing mode.


To reconnect it to the last used device, short press the power button.



08 Specifications

English

Speaker Type	Portable Bluetooth Speaker
Speaker System	Mono
Loudspeaker	1.5 inches internal magnetic speaker + Passive radiators
Input	5V / 1A
Battery	Built-in 1200mAh Lithium battery
Charging Time	About 3.5 hours with 1A output adaptor
Output Power	5W, THD=10%
Frequency	80 Hz - 18 KHz
USB Standard	USB 2.0 (compatible with USB 1.1)
Supported Storage	Up to 32 GB Micro SD card (FAT32)
Supported Media Type	APE, FLAC, WAV, WMA, MP3



Size: 3.3 × 1.8 × 3.4 in / 85 × 46 × 86 mm

Weight: 6.2 oz / 175g (including the built-in lithium battery)

FAQ	Solutions
Not able to connect to your device	1. Restart the speaker and try again
	2. If your device requires a Pin Code, please enter 0000
Keeps cutting out when playing	Please ensure the speaker is within the operating range and there are no obstacles between the speaker and the device
Not able to play the music in Micro SD card	1. Please ensure the format of the Micro SD card is FAT32. It only supports FAT32 Micro SD card 2. Please ensure the formats of the music files are APE, FLAC, WAV, WMA or MP3
No sound when playing	1. Please adjust the volume of the speaker 2. Please adjust the volume of your device 3. Please check if the speaker is paused
No sound in AUX-in mode	Please ensure the audio cable is connected well
Not able to turn on	Please try to charge the speaker for about 3 .5hours
No respond to any operation	Please try to press and hold the power button for about 8 seconds to reset the speaker

MiFA MIFA INNOVATIONS LLC
www.mifa.net Designed in US Made in China

Copyright © MIFA. All rights reserved.

MIFA, the MIFA logo and other MIFA marks are all owned and registered by MIFA INNOVATIONS LLC. All other trademarks are the property of their respective owners. The information contained here is subject to change without prior notice.