User Guide Contents

Name: Bluetooth Headset Model: HUAWEI BL-LE04

Overview:

1.Multi-function Button (MFB) Power on/off Pair with mobile phone Answer/End a call Last number redials

2.Adjust volume

3.Indicator light

4.Microphone

5.Earpiece

6.DC Charging Socket



Product Specifications

Bluetooth Profiles Supported: Headset Profile, HandsFree Profile\A2DP Profile

Range of Frequency: 2.4GHz spectrum Nominal Charging time: Within 2 hours Up to 10 meters Operating Distance: Talk Time: Up to 10 hours Music Time: Up to 4 hours Standby Time: Up to 120 hours 57(L)*19(W)*20(H)mm Dimensions:

Weight:

Main functions: To answer / end / reject /phone calls,

Calls select freely between previous & next track, to start / pause music

Getting Started:

1.Ensure your headset is fully charged 2.Pair your charged headset with a

Bluetooth-enabled mobile phone.

Charging Your Headset

The headset comes with a built-in rechargeable battery. Prior to using the headset for the first time, it is recommended to fully charge the battery. Insert the charger's plug into the headset's DC charging socket and plug the mains charger to an AC wall outlet or plug to the PC/notebook

Indicator Light

| Headset Status | Status Indicator Light | |
|------------------------------|--|--|
| Standby | Flash Blue | |
| Charging (off Mode) | Solid red | |
| Fully charged (off Mode) | Solid blue | |
| Low battery | Flash red with short beep every minute | |
| Out of battery | The light turns off | |
| Charging (standby mode) | Double flash red | |
| Fully charged (standby mode) | Double flash blue | |
| Out of Range | Solid purple for 5sec then flash blue | |

Using your headset

| Function | Button | Beep / Buzzer | Status indictor |
|--------------------------------------|--|---|-------------------------------------|
| POWER ON | Press and hold the MFB for 2 sec | Short beep | Flash blue light twice |
| mode, i.e. the sta | n your headset for the first trus indicator flashes blue with your mobile phone. | t time, the headset pro- and red alternately, so | seeds into pairing that you can |
| POWER OFF | Press and hold the MFB for 2 sec | Long beep | Flash red light and then goes of |
| Incoming call | | Ringtone through the earphone and buzzer ON(depends on buzzer pattern) | Flash purple |
| Answer / End a call | | Press the MFB once | |
| When there is 2n 2nd incoming cal | d incoming call, press MF | B can hold the current of | all and answer the |
| Adjust Volume | Press Volume | Short beep at max. volume | |
| Last no. | In standby mode, double click MFB | | |
| Redial* | | | |

Resetting Your Headset / Removing the pairing History You may reset the headset to its default settings . Resetting will also remove the pairing history of your headset with the mobile phone.

- 1.During off mode, hold the Volume then plug the charging cable into the charging socket. The indicator will light in solid purple.
- 2.Release the Volume.
- 3. Hold the Volume for 2 sec until the status indicator blink in purple for 3 times.
- 4.Release the Volume and the headset will return to charge mode. Now the headset is reset. Bluetooth headset is designed to work with Bluetooth devices. Due to large variability between different Bluetooth devices from different manufacturers, interoperability between the headset and all Bluetooth -enabled products is not guaranteed.

Hereby, Shenzhen Pacemaker Electronic Technology Co., Ltd., declares that this Bluetooth Headset is In compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Environment friendly disposal You can help protect the environment! Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal centrer.

FCC NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment. The manufacture is not responsible for any radio or TV

interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to

operate the equipment.

成品尺寸:62X97mm 展开尺寸:372X97mm

材质: 双粉纸/128克