


# Internal Photographs

EUT - Open View



EUT - PCB View

Antenna Location



EUT -PCB View

