

Internal Photographs


Internal View of EUT-1




Internal View of EUT-2




Internal View of EUT-3




Internal View of EUT-4




Internal View of EUT-5




Internal View of EUT-6




Internal View of EUT-7




Configuration 1 antenna



Configuration 1 antenna



Configuration 2 antenna



Configuration 2 antenna

