

产品规格	
产品名称	PXN Sense Elf S2
连接方式	无线连接
输入	DC 5V = 1A
频 响	20HZ - 20KHZ
最大工作距离	10米 (无障碍)
工作时间	约5小时
充电方式	约1.5小时 (耳机) 约2小时 (充电盒+USB-C数据线)
产品尺寸	约 61.5 * 61.4 * 32 mm (充电盒)

#### 注意事项

- 1) 避免保存于潮湿、高温、油烟等场所。
- 2) 避免水或其它液体进入耳机内。
- 3) 避免长时间高音量使用耳机, 如果出现耳鸣、耳痛等现象, 应该停止收听。
- 4) 如有质量问题或建议, 请与销售商或售后人员联系。

警告: 本产品的可充锂电池必须妥善处置, 以便回收利用, 请不要将电池放入火中, 以免引起爆炸。


建议: 如果长时间不打算使用耳机, 请您储存在干燥的地方; 每月至少需要为耳机充电一次以延长电池使用寿命。

- 14 -

S-S2-V01-2205



PXN Sense Elf S2




### True Wireless Gaming Earbuds

使用说明书 | User Manual

#### 充电

首次使用充电盒进行充电时, 请将耳机放回充电盒并合盖, 用本产品附带的数据线, 连接电源充电。

耳机	耳机放入充电盒并合盖充电	—耳机充电时, 耳机白色指示灯常亮3秒 逐渐熄灭; 充电盒RGB灯循环一次熄灭; 充满电后, 对应的RGB白灯常亮3秒熄灭
充电盒	使用附带的数据线充电	充电中, L/R指示灯亮红色呼吸灯; 充电完成, L/R指示灯常亮绿色灯, 1分钟后熄灭



#### 恢复出厂设置 (谨慎使用)

首次使用将清除耳机的所有配对信息  
• 关机状态下, 长按耳机触摸区域10秒至耳机再次关机, 恢复完成后耳机蓝灯长亮2秒关机。

#### Q: 耳机听不到声音?

- A: a. 确认耳机处于工作状态。  
c. 确认耳机是否与手机正常连接。  
e. 确认耳机喇叭网位置是否有异物堵塞。
- b. 确认耳机的音量大小是否合适。

#### Q: 耳机通话信号不好?

- A: a. 确认智能设备是否在信号强的地区。  
b. 耳机的有效使用距离为10米, 请确认耳机在有效使用距离内, 且耳机与智能设备间无障碍物阻隔。

#### Q: 为什么播放音乐时, 耳机不能进行暂停、恢复、上曲和下曲控制?

- A: 此功能需要与耳机配对的设备支持AVRCP(Audio/Video Remote Control Profile)协议。

- 13 -

#### Overview & Package Contents

Package contents includes PXN Sense Elf S2 Earbuds, 3 sizes of earbuds tips ( M size tips are installed in the earbuds ), USB-C cable and user manual.



Download the APP "PXN Audio" in Apple APP Store or Play Store on Android to experience custom interactive operations. (Volume control, playback control, voice assistant activation...)



Scan to download the browser

- 1 -

#### 恢复出厂设置 (谨慎使用)

首次使用将清除耳机的所有配对信息

- 关机状态下, 长按耳机触摸区域10秒至耳机再次关机, 恢复完成后耳机蓝灯长亮2秒关机。
- 请按照“左右耳机的TWS配对连接”流程重新完成左右耳机的TWS配对和智能设备的连接。

#### Q: 耳机听不到声音?

- A: a. 确认耳机处于工作状态。  
c. 确认耳机是否与手机正常连接。  
e. 确认耳机喇叭网位置是否有异物堵塞。
- b. 确认耳机的音量大小是否合适。

#### Q: 耳机通话信号不好?

- A: a. 确认智能设备是否在信号强的地区。  
b. 耳机的有效使用距离为10米, 请确认耳机在有效使用距离内, 且耳机与智能设备间无障碍物阻隔。

#### Q: 为什么播放音乐时, 耳机不能进行暂停、恢复、上曲和下曲控制?

- A: 此功能需要与耳机配对的设备支持AVRCP(Audio/Video Remote Control Profile)协议。


- 13 -

接听来电	点击2次 (L/R) 双通有声	
拒接来电	长按2s (L/R)	
游戏模式	点击3次 (R) 语音提示: Game Mode	
音乐模式	点击3次 (R) 语音提示: Music Mode	
激活语音助手 开启/关闭	点击3次 (L)	
耳机RGB灯模式 开启/关闭	点击4次 (L/R)	

- 12 -

#### Auto Power ON & OFF

- Open the charging case and the earbuds will power ON automatically.
- Put the earbuds back to the charging case and close the case, the earbuds will power OFF and enter the charging state.
- If no connection to any smart device for more than 3 seconds after removing the earbuds from the charging case, the earbuds will power OFF automatically.



#### Manual Power ON & OFF

- Under power OFF state, long press the touch sensor area on the L & R earbuds simultaneously for 3 seconds to power ON. (Voice guidance: Power ON.)
- Under power OFF state, long press the touch sensor area on the L & R earbuds simultaneously for 5 seconds to power OFF. (Voice guidance: Power OFF.)



#### Connect Smart Device in Dual Earbud Mode

- For the first use, the earbuds indicator will keep on White for 2 seconds after removing from the charging case. (Voice guidance: Power ON.) L & R earbuds will pair automatically. (Voice guidance: Beep.) After successful pairing, the White and Blue indicator will flash alternately and enter the Bluetooth Search state. (Voice guidance: Pairing.) Now can connect with the smart device.
- Open the Bluetooth on the smart device and search "PXN Sense Elf S2" to pair. The earbuds will be paired with the smart device successfully. (Voice guidance: Connected.)



#### Connect Smart Device in Mono Earbud Mode

- Remove the L / R earbuds from the charging case and pair it according to the above dual earbud mode to complete the connection.

#### Auto-Reconnection

- Open the charging case, and the earbuds will automatically connect back to the last successfully connected smart device.
- The earbuds will be disconnected with the smart device when they are beyond the effective distance. (Voice guidance: Disconnected.) Return to the effective distance within 3 minutes, the earbuds and smart device will reconnect automatically.

#### TWS Pairing Connection of L & R Earbuds

When the earbuds leave the factory, the L & R earbuds have successfully completed TWS pairing under normal conditions, and the earbuds can be used normally after connecting with the smart device.

- 2 -

#### 指示灯状态

耳机模式	播放模式	游戏模式	音乐模式	待机模式	来电模式
指示灯状态	蓝/白灯 呼吸循环	蓝灯 闪烁	白灯 闪烁	蓝/白灯 4s/次	白灯 快闪

#### 功能

#### 触控操作说明

#### 手势

播放/暂停▶/II	点击2次 (L/R) 双击 L/R	
音量	点击1次 (L-/R+) 单击 L-/R+	
上一曲	长按2s (L) 长按2s	
下一曲	长按2s (R) 长按2s	

- 11 -

#### 自动开关机

- 将充电盒打开, 耳机自动开机。
- 将耳机放回充电盒内, 并关闭充电盒, 耳机将关机并进入充电状态。
- 取出耳机后超过3分钟未连接智能设备, 将自动关机。

#### 手动开关机

- 关机状态下, 同时长按左右耳触控区域3秒, 耳机开机。(语音提示: Power on.)
- 开机状态下, 同时长按左右耳触控区域约5秒, 耳机关机。(语音提示: Power off.)

#### 双耳机模式连接智能设备

- 首次使用耳机时, 从充电盒内取出耳机白灯长亮2秒(语音提示: Power on.)左右耳将自动配对(语音提示: 配对). 配对成功后白蓝灯交替闪烁进入蓝牙搜索状态(语音提示: Pairing). 此时可与智能设备进行连接。
- 将耳机放入充电盒后(语音提示: "PXN Sense Elf S2"的名称), 点击"配对", 耳机与设备配对成功后(语音提示: Connected.)。

#### 单耳机模式连接智能设备

- 从充电盒中取出左/右耳时, 按上述双耳机模式配对完成连接即可。

#### 自动回连

- 打开充电盒, 耳机将自动回连最后一次成功连接过的智能设备。
- 当耳机进入搜索状态时, 同时双击耳机, 耳机白色指示灯进入呼吸状态, 开始配对。
- 左右耳配对成功后(语音提示: 部部), 双耳指示灯进入白蓝灯交替闪烁, 此时可与智能设备进行连接。

#### 左右耳机的TWS配对连接

耳机出厂时, 正常情况下左右耳机已成功完成TWS配对, 连接设备可正常使用。

当特殊情况您需要重新配对时, 请按以下步骤操作:

- 左右耳机进入搜索状态时, 同时双击耳机, 耳机白色指示灯进入呼吸状态, 开始配对。
- 左右耳配对成功后(语音提示: 部部), 双耳指示灯进入白蓝灯交替闪烁, 此时可与智能设备进行连接。

- 10 -

#### 充电

当使用充电盒进行充电时, 请将耳机放回充电盒并合盖, 用本产品附带的数据线, 连接电源充电。

当充电盒充满电后, 请将耳机取出充电盒, 以延长电池使用寿命。

当充电盒充满电后, 请将耳机取出