


<div data-bbox="391 65 554 120" data-label="Text"><p>English</p></div> <div data-bbox="119 156 445 197" data-label="Section-Header"><h1>Instruction Manual</h1></div> <div data-bbox="141 225 429 518" data-label="Image"></div> <div data-bbox="76 565 545 592" data-label="Text"><p>Please read the instructions before use</p></div>	<div data-bbox="581 52 668 85" data-label="Section-Header"><h2>Connect</h2></div> <div data-bbox="570 107 1026 299" data-label="Image"></div> <div data-bbox="592 315 1051 378" data-label="List-Group"><div>1. Take out the earbuds (Earbuds auto power on)</div><div>2. After open the phone Bluetooth, Click the <Bluetooth> to Pairing</div></div> <div data-bbox="592 373 668 400" data-label="Section-Header"><h2>Reset</h2></div> <div data-bbox="592 408 1064 450" data-label="Text"><p>If there are connectivity or functional issues with the headset, please reset the headset:</p></div> <div data-bbox="592 452 1078 611" data-label="List-Group"><div>1. Delete Bluetooth pairing information on the device and turn off the device's Bluetooth functionality.</div><div>2. Put the headset into the charging box to charge.</div><div>3. Turn on the Bluetooth function of the device.</div><div>4. Take out the headset and wait for 20 seconds before pairing and connecting to the device again.</div><div>(If the above operation does not work, please try again)</div></div>	<div data-bbox="1124 52 1227 85" data-label="Section-Header"><h2>Operation</h2></div> <div data-bbox="1254 35 1553 216" data-label="Image"></div> <div data-bbox="1118 222 1580 326" data-label="Image"></div> <div data-bbox="1118 329 1580 375" data-label="List-Group"><div>Play / pause single click function keys</div><div>Switch Song Press and hold the volume +/- key for 2S</div><div>Adjust Volume Click the Volume +/- key Press and hold the function key 2/5S</div><div>Power on/off Press and hold the function key 2/5S</div></div> <div data-bbox="1118 381 1580 485" data-label="Image"></div> <div data-bbox="1118 488 1580 546" data-label="List-Group"><div>Answer/Hang up single click function keys</div><div>Reject Call Press and hold the function key 2S</div><div>Voice Assistant Press and hold the function key 2S</div><div>Restore factory settings Press and hold the Volume +/- key for 3s</div></div> <div data-bbox="1118 559 1567 595" data-label="Text"><p>X1: Click Once 2S: Press and hold for 2 seconds</p></div>	<div data-bbox="1654 52 1844 85" data-label="Section-Header"><h2>Problem handling</h2></div> <div data-bbox="1654 120 2012 170" data-label="Text"><p>① Can be connected but there is no sound: Click the left/right ear volume+button.</p></div> <div data-bbox="1654 200 2050 271" data-label="Text"><p>② One of earbuds cannot be charge: Clean the charging contacts of the headset and charging box.</p></div> <div data-bbox="1654 304 2012 353" data-label="Text"><p>③ One of the earbuds cannot be connected: Reset the earbuds (See page 2).</p></div> <div data-bbox="1643 373 2132 444" data-label="Text"><p>If the headset cannot be charged after activating the product (it is normally connected to the Bluetooth device for the first time), Contact us to send new products.</p></div> <div data-bbox="1654 471 2115 576" data-label="Image"></div>	<div data-bbox="2180 52 2362 85" data-label="Section-Header"><h2>Safety Instructions</h2></div> <div data-bbox="2180 98 2683 356" data-label="List-Group"><div>1. Keep the product away from extremely hot and cold environments, it will damage the battery and circuit.</div><div>2. Avoid liquid immersion into the product.</div><div>3. Do not disassemble the product.</div><div>4. Do not use concentrated chemical products or detergents to clean the product.</div><div>5. Use only 5V/1A power supply. Connecting the power supply voltage too high may cause serious damage.</div><div>6. Do not randomly discard or place the product near fire or high temperature to avoid the danger of explosion.</div></div> <div data-bbox="2180 364 2278 386" data-label="Section-Header"><h3>FCC Statement</h3></div> <div data-bbox="2180 395 2683 661" data-label="Text"><p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p></div> <div data-bbox="2180 666 2683 820" data-label="List-Group"><div>• Reorient or relocate the receiving antenna.</div><div>• Increase the separation between the equipment and receiver.</div><div>• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</div><div>• Consult the dealer or an experienced radio/TV technician for help.</div></div> <div data-bbox="2180 828 2683 891" data-label="Text"><p>Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.</p></div> <div data-bbox="2180 900 2683 1001" data-label="Text"><p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p></div> <div data-bbox="2180 1039 2354 1061" data-label="Section-Header"><h3>RF Exposure Information</h3></div> <div data-bbox="2180 1070 2683 1133" data-label="Text"><p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p></div>
	<div data-bbox="581 1292 668 1325" data-label="Section-Header"><h2>连接</h2></div> <div data-bbox="874 1286 999 1336" data-label="Image"></div>	<div data-bbox="1124 1292 1227 1325" data-label="Section-Header"><h2>使用说明</h2></div> <div data-bbox="1254 1286 1455 1372" data-label="Image"></div>	<div data-bbox="1673 1292 1776 1325" data-label="Section-Header"><h2>问题处理</h2></div>	<div data-bbox="2180 1292 2289 1325" data-label="Section-Header"><h2>安全说明</h2></div>

使用说明书



使用前请阅读说明




- 1. 取出耳机
(耳机将自动开机)
- 2. 打开手机蓝牙后
单击<BX28> 进行配对

重置

如果耳机存在连接或功能问题，请重置耳机：

- 1. 删除设备上的蓝牙配对信息，并关闭设备蓝牙功能。
- 2. 将耳机放入充电盒充电。
- 3. 打开设备的蓝牙功能。
- 4. 拿出耳机，等待20秒后，重新与设备配对连接。
(如果上述操作不起作用，请重试)



① 可以连接但没有声音:
单击左/右耳音量+键。

② 其中一个耳机无法充电:
清洁耳机和充电盒的充电触点。

③ 其中一个耳机无法连接:
请重置耳机（见第2页）。

激活产品（第一次正常连接蓝牙设备使用）后如耳机无法充电，
联系我们寄送新产品



请经常清洁耳机和充电盒的充电触点，
以避免充电失败。

- 1. 使产品远离酷热和寒冷，避免损坏电池和电路。
- 2. 避免液体浸入产品中。
- 3. 请勿拆卸产品。
- 4. 不要使用浓缩化学产品或洗涤剂清洁产品。
- 5. 仅使用5V/1A电源。连接电源电压过高可能会导致严重损坏。
- 6. 不要随意丢弃或将产品放置在火灾或高温附近，以避免爆炸危险。