


Internal Photographs

EUT - Open View



EUT - PCB View 1

Antenna location



EUT - PCB View 2

