

Figure 7
General Appearance of the EUT



Figure 8
Inside Configuration of the EUT



Figure 9
Inside Configuration of the EUT




Figure 10
Inside Configuration of the EUT




Figure 11
Inside Configuration of the EUT




Figure 12
Inside Configuration of the EUT




Figure 13
Inside Configuration of the EUT




Figure 14
Inside Configuration of the EUT




Figure 15
Inside Configuration of the EUT



Figure 16
Inside Configuration of the EUT



Figure 17
Inside Configuration of the EUT



Figure 18
Inside Configuration of the EUT



Figure 19

Car Charger M/N: DOA-5K05 050100



Figure 20

Car Charger M/N: DOA-5K05 050100



Figure 21
Car Charger M/N: CP28



Figure 22
Car Charger M/N: CP28



Figure 23
Car Charger M/N: CP28



Figure 24
Micro USB Power Cord

