

Figure 7
General Appearance of the EUT



Figure 8
General Appearance of the EUT



Figure 9
Inside Configuration of the EUT




Figure 10
Inside Configuration of the EUT



Figure 11
Inside Configuration of the EUT



Figure 12
Inside Configuration of the EUT




Figure 13
Inside Configuration of the EUT



Figure 14
Inside Configuration of the EUT



Figure 15
Inside Configuration of the EUT



Figure 16
Inside Configuration of the EUT




Figure 17
Inside Configuration of the EUT



Figure 18
Inside Configuration of the EUT




Figure 19
Inside Configuration of the EUT



Figure 20
Inside Configuration of the EUT



Figure 21
Inside Configuration of the EUT




Figure 22
USB Car charger M/N: DOA-5K05 050100



Figure 23
USB Car charger M/N: DOA-5K05 050100



Figure 24
Micro USB Power Cord



RF Module for FCC ID: 2AFIB-YCS1B18

Front side



Backside

