
User Manual for Bluetooth Voice Remote



Buttons

Button	What it's for
Power	Turn your connected devices on or off and wake up or sleep your
	Chromecast.
Input	Turn on your connected device and switch it to active input.
	OD Switch the input course on your connected device
Number (0, 0)	OR Switch the input source on your connected device.
Number(0~9)	Enter a number
Subtitles	Display subtitles
Information	Display information
Red, Green,	Move to the service corresponding to the color displayed on the
Yellow, Blue	screen
Google	Talk to Google. Press and hold the Google Assistant button while
Assistant	you ask a question or say a command.
Bookmark	Allow you to easily access your favorite channels
Setting	Set the functions of your host.
Directional pad	Use the D-pad ring to navigate up, down, left or right.
(D-pad)	
	To select, press the middle button.
Back	Go back one screen.
TV(Guide)	To guide TV
Home	Return to the Home screen.
Volume	Press the top or bottom of this button to adjust the volume.
Program	Press the top or bottom of this button to change the program.
Mute	Mute the volume on your Chromecast or connected device.
YouTube	Launch installed YouTube apps, including YouTube, YouTube TV,
	YouTube Kids or YouTube Music.
	Note: You can remap the YouTube button to open your preferred
	YouTube app. Press and hold the button until your YouTube apps
	appear on your TV screen, then select the app you want.
Netflix	Launch Netflix.

Prime Video	Launch Prime Video
Disney plus	Launch Disney plus

Pairing

Before using the Bluetooth Google Reference remote, you need to pair to your Host by pressing pairing keys.

Microphone

This is the mic you'll use to <u>talk to Google</u>. To learn more about Google Assistant, ask "What can you do?"

Tip: Use the voice remote to control the TV, search, and more.

Example queries:

- "What should I watch?"
- "Find funny movies."
- "Show me sci-fi adventure TV shows."

LED

The LED tells you the current status of your remote.

Software updates to your Reference Voice Remote

When software updates are released for your Voice Remote, they will be applied automatically as long as it's paired to your Host.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.