

Welcome to Spigen World!



Something You Want!

Check out this helpful manual for tips and tricks on getting the most out of this product!

Wireless Earphones - R12E

User Manual

About Spigen

The Spigen Brand

As a leading mobile accessories brand, Spigen strives to make the best products that fit your lifestyle.

www.spigen.com

Here are some tips and tricks on how to charge and use this portable charger!

Using the Earphones

Basic Settings

Power on : Press the "spigen" button for 3 seconds when the devices is off (the indicator light flashes blue slowly and you will hear the voice prompt "power on").

Enter the pairing mode : Press the "spigen" button for 8 seconds when the devices is off (the indicator flashes red and blue alternately, and you will hear the voice prompt "pairing").

Pairing : Pair the device with a mobile phone or other Bluetooth devices (refer to the below chapters about pairing for details).

Power off : Press the "spigen" button for 3 seconds when the device is on or standby (you will hear the voice prompt "power off" and the indicator light will flash red for 2 seconds).

Low battery warning : You will hear the voice prompt "battery low" and the indicator light will flash red.

Charging : Use the USB charging cable connected to a computer to charge the headset (the indicator is solid red when charging).

Reset system : When charging the device, press the "spigen" button for 3-5 seconds, the indicator light flashes purple for three times.

Turn off the voice prompt : Enter pairing mode, press " " for 3 seconds, the indicator light flashes red for 3 times.

Turn on the voice prompt : Enter pairing mode, press " " for 3 seconds, the indicator light flashes blue for 3 times.

Music Settings

Play/Pause : Press "spigen" to play or pause.

Volume up : Press " " to turn up the volume.

Volume down : Press " " to turn down the volume.

Next/Previous : Press " " for 1 second to play previous track, and " " ; next track.

Phone Settings

Answer a call : Press the "spigen" button once to answer an incoming call.

End a call : Press the "spigen" button once to end an online call.

Call voice

Reject a call : Double press the "spigen" button to reject an incoming call.

Multi-point connection : In power off mode, long press the "spigen" button for 8 seconds to enter pairing mode, pair with the 1st mobile phone. Power off R12E, turn off the Bluetooth function of the 1st mobile phone. Power on R12E and enter pairing mode again. Turn on the Bluetooth function of the 2nd phone and select R12E to pair with it. Turn on the Bluetooth function of the 1st mobile phone to pair with R12E and finish multi-point connection.

Switch calls between two mobile phones : When there's an incoming call on the 1st phone, press "spigen" to answer it; if there's another incoming call on the 2nd phone at the same time, press "spigen" again to hang on the current call and answer the call on the 2nd phone.

Redial the latest call : In standby or music playing mode, double press the "spigen" button

Mute : When talking, double press the "spigen" button to activate the function

Charging the Headset

1. Use a charger with DC5V output voltage or USB charging cable connected to a computer to charge the headset.
2. During charging, the indicator light will turn red.
3. When the headset is fully charged, the red indicator light will turn blue.

Note :

Use only chargers approved by R12E, the use of any other chargers may invalidate warranty, and may be dangerous.

Repeated charging and discharging of the earphone will cause the degradation of the battery performance. This is normal for all rechargeable batteries.

If the headset has not been used for over three months, please charge it before using.

Caution

1. Do not disassemble or modify headset for any reason to avoid any damages.
2. Keep dry and away from liquids.
3. Do not store in extreme temperatures (below 0°C or above 45°C).
4. Do not use during thunderstorms to avoid irregular function and increased risk of electric shock.
4. Charge headset before use if it has not been used for over three months.

Specification

- Bluetooth Specifications : V4.0
- Bluetooth Profile : HFP1.6, HSP1.2, AVRCP1.4, A2DP1.2
- Audio Codec : ART-X
- Operating Range : 33ft/10m
- Noise Reduction : CVC 6.0
- Standby Time : about 175 hours
- Talk Time : about 5 hours
- Music Playing Time : about 4 hours
- Charging Time : about 2hours
- Dimension (LxWxH) : 40x24x32mm
- Weight : 16.4g

Included

- Wireless Headphones(R12E)
- USB Charging Cable
- Extra Earbud (x4)
- Extra Ear Hooks (x4)
- User Manual

4MN00119_00

FCC REQUIREMENTS PART 15

Caution : Any changes or modifications in construction of this device which are not expressly approved by the responsible for compliance could void the user's authority to operate the equipment.

NOTE : This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:
1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to protect the equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the radio or television off and on, the user is encouraged to try to correct interference by one or more of the following measures.

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on another circuit.
4. Consult the dealer or an experienced radio/TV technician for help.

back

사용방법

기본 설정

전원 켜기 : 전원이 꺼진 상태에서 "Spigen" 버튼을 약 3초 동안 누릅니다. 표시등이 파란색으로 깜빡이면서 "power on" 음성 안내 메시지가 나옵니다.

연결 모드 : 전원이 꺼진 상태에서 "Spigen" 버튼을 약 8초 동안 누릅니다. 표시등이 붉은색과 파란색으로 번갈아 깜빡이면서 "pairing" 음성 안내 메시지가 나옵니다.

연결 : 제품을 휴대전화나 블루투스 기기와 연결시킵니다. 아래 연결 항목의 세부사항을 참조하시기 바랍니다.

전원 끄기 : 전원이 켜진 상태이거나 대기 상태에서 "Spigen" 버튼을 약 3초간 누릅니다. "power off" 음성 안내 메시지와 함께 표시등이 붉은색으로 2초동안 깜빡입니다.

배터리 방전 알림 : "battery low" 음성 안내 메시지와 함께 표시등이 붉은색으로 깜빡입니다.

충전 : USB 충전케이블을 사용하여 컴퓨터와 연결하여 충전합니다. 충전 중에는 표시등이 붉은색으로 빛납니다.

시스템 리셋 : 충전 중에 "Spigen" 버튼을 약 3-5초 동안 누릅니다. 표시등이 보라색으로 세 번 깜빡입니다.

음성안내 모드 끄기 : 연결 모드에서 " "를 3초간 누릅니다.

음성안내 모드 켜기 : 연결 모드에서 " "를 3초간 누릅니다.

표시등이 파란색으로 세 번 깜빡입니다.

음악 설정

재생/정지 : "spigen" 버튼을 누르면 음악 재생이 되거나 멈춥니다. **볼륨 증가** : "+" 버튼을 눌러 볼륨을 올립니다.

볼륨 감소 : "-" 버튼을 눌러 볼륨을 낮춥니다.

다음 곡/이전 곡 이동 : 1초 동안 "-"을 누르면 이전 트랙으로 이동, 1초 동안 "+"을 누르면 다음 트랙으로 이동합니다.

전화 설정

전화 받기 : 전화가 오면 "Spigen" 버튼을 누릅니다.

전화 끊기 : 통화를 마치면 "Spigen" 버튼을 누릅니다.

음성 통화 변경 : 2초 동안 "Spigen" 버튼을 눌러 음성 통화를 휴대전화에서 해당 기기로, 혹은 그 반대로 전환합니다.

수신 거절 : "Spigen" 버튼을 두 번 눌러 걸려오는 전화를 거절합니다.

멀티태어링 지원 : 전원이 꺼진 상태에서 8초 동안 "Spigen" 버튼을 누르면 연결 모드가 전환되며 첫 번째 휴대전화와 연결합니다. R12E의 전원과 첫 번째 휴대전화의 블루투스 기능을 끕니다. R12E의 전원을 켜고 연결 모드를 실행합니다. 두 번째 핸드전화의 블루투스 기능을 켜 후 R12E를 선택하여 연결합니다. 마지막으로 첫 번째 휴대전화의 블루투스 기능을 활성화 시킨 후 R12E와 연결합니다.

두 휴대전화 통화 전환 하기 : 첫 번째 휴대전화에서 전화가 걸려오면 "Spigen" 버튼을 눌러 수신합니다. 만일 두 번째 휴대전화에서 동시에 전화가 걸려올 경우, 다시 한 번 "Spigen" 버튼을 눌러 현재 통화를 대기 상태로 만들고 두 번째 휴대전화의 통화를 수신합니다.

재다이얼 : 대기 모드 혹은 음악 재생 중 "Spigen" 버튼을 두 번 누르면 마지막으로 통화한 번호로 연결됩니다.

음소거 : 대화 중 "Spigen" 버튼을 두 번 누르면 음소거 기능이 활성화 됩니다.

이어폰 충전

1. 충전을 위해 5V 전압의 충전기를 사용하거나 USB 충전케이블을 컴퓨터에 연결하여 충전해 주시기 바랍니다.
2. 충전 중에는 표시등이 빨간색으로 켜집니다.
3. 충전이 완료되면 표시등이 빨간색에서 파란색으로 변합니다.

주의사항 :

R12E 충전시 인종이 된 충전기만 사용하지기 바랍니다. 그 외 비인가 충전기를 사용하여 충전을 할 경우 문제 발생시 보상을 받을 수 없으며, 위험하므로 반드시 인가된 충전기를 사용하여 충전하시기 바랍니다. 반복적인 충전과 방전은 이어폰 배터리 성능 저하의 원인이 될 수 있으며, 모든 일반 충전용 배터리에 일어난는 공통된 사항입니다. 만약 이어폰을 3개월 이상 사용하지 않았을 경우, 충전 후 사용하지기 바랍니다.

주의사항

1. 손상을 피하기 위해 이어폰을 분해하거나, 개조하지 마십시오.
2. 항상 건조한 상태로 유지하고 액체류를 피하십시오.
3. 극한 기온에 노출 마세요.(0°C 이하 혹은 45°C 이상)
4. 오작동 및 전기 충격을 피하기 위해 뇌우시 사용을 자제하십시오.
5. 3개월 동안 사용하지 않았을 경우 충전 후 사용하시기 바랍니다.

* 해당 무선기기는 전파선정 가능성이 있으므로 안전 관련 서비스는 할 수 없습니다

사양

- 블루투스 사양 : V4.0
- 블루투스 프로파일 : HFP1.6, HSP1.2, AVRCP1.4, A2DP1.2
- 오디오 코덱 : ART-X
- 작동 범위 : 33ft/10m
- 노이즈 감소 : CVC 6.0
- 대기 시간 : 약 175 시간
- 통화 시간 : 약 5 시간
- 음악 재생 시간 : 약 4 시간
- 충전 시간 : 약 2 시간
- 치수 (LxWxH) : 40x24x32mm
- 무게 : 16.4g

구성품

- 무선 이어폰(R12E)
- USB 충전케이블
- 여분 이어버드 팀 (x4)
- 여분 이어 후크 (x4)
- 사용 설명서

Thank you for your purchase!

If you have any issues or concerns, let us know at spigen.desk.com

Happy with Your Purchase?

GOOD!

★★★★★

Share with others how much you like our product!



Explore More Products

amazon.com Spigen

google.com

ebay.com All Categories

