



WICKED HUM 900  
FULL-SIZE WIRELESS HEADPHONE

WI-BT900

WIRELESS

13.5HR  
RECHARGEABLE  
BATTERY




SOFT-TECH  
CUSHIONS



### FIRST TIME USE

1	Make sure that the Wicked Audio HUM 900 is charged, your phone turned on, with the Bluetooth feature enabled.
2	Turn on the Hum 900 Bluetooth and the LED will flash red and blue.
3	Your mobile phone should detect "WICKED HUM 900."
4	Select "WICKED HUM 900" to pair and once successfully paired, the LED will slowly flash blue.

### WHAT'S WHAT



### FUNCTIONS

	QUICK PRESS	PLAY/PAUSE/ANSWER CALL/HANG UP
	QUICK PRESS	NEXT TRACK
	QUICK PRESS	PREVIOUS TRACK
	LONG PRESS	VOLUME UP
	LONG PRESS	VOLUME DOWN
	UP	ON
	DOWN	OFF

### HANDY L.E.D. INDICATORS

RED/BLUE	PAIRING MODE / DISCONNECTED
FLASHING BLUE	BLUETOOTH IS ON AND CONNECTED
SOLID RED	BATTERY IS CHARGING
SOLID BLUE	BATTERY IS FULLY CHARGED
GREEN (right side)	HUM 900 IS ON

### TROUBLESHOOTING

#### Product does not turn on:

- 1 - Make sure to switch Bluetooth on/off button to the on position (up), LED will turn on.
- 2 - Make sure battery is charged. Charge battery for at least 30 minutes and power on again.

#### Your Bluetooth device is unable to search for/locate/pair with Wicked Audio Bluetooth product:

- 1 - Be sure your Bluetooth device has Bluetooth capabilities turned on/activated
- 2 - Be sure your Wicked Audio product is in pairing mode (LED will be flashing Red AND Blue.) The Hum 900 is in pairing mode automatically if a recognized device cannot be found and the product's Wireless capabilities are turned on.
- 3 - Delete/Forget/Unpair the Wicked Audio product from your Bluetooth list on your device or other nearby devices and search again.
- 4 - Double check the device is not paired to another device within 100ft. "Forget" the Wicked Hum 900 from the list of available Bluetooth devices. Turn Hum 900 off and repair to selected device. Hum 900 will flash red/blue when in pairing mode and only blue when already connected to a device.
- 5 - If still unable to search for/locate/pair with Wicked Audio Bluetooth product, please restart your Bluetooth device and the Wicked Audio product and search again
- 6 - Turn the Hum 900 off and charge for at least 30 minutes. Try to pair again after battery is charged.

#### Disconnected after your Bluetooth device successfully connected/paired with your Wicked Audio product:

- 1 - The Bluetooth signal has been blocked with an obstruction/exceeded Bluetooth range between your Bluetooth device and the Wicked Audio product OR the "Power/Bluetooth" button was held down for too long and disconnected. You will need to manually select "Wicked Endo" in your Bluetooth list on your device to successfully pair your Endo to your device.
- 2 - Check to see if the battery is at low power, charge if needed.
- 3 - The Hum 900 was out of range of the device for too long and powered down.
- 4 - Another Bluetooth audio device was turned on within range and your device is now connected to that device instead of the Hum 900. Turn off second audio device, and pair again to the Hum 900.

#### Unable to connect/pair your desired Bluetooth device with your Wicked Audio

#### product after connecting your Wicked Audio product with multiple Bluetooth devices:

- 1 - Your Wicked Audio product will attempt to connect/pair with last Bluetooth device it paired with.
- 2 - Turn off Bluetooth capabilities on other Bluetooth devices in your vicinity that were recently paired to your Wicked Audio product. This will allow your desired Bluetooth product to connect with your Wicked Audio product.
- 3 - If still unable to pair with Wicked Audio Bluetooth product, please restart your Bluetooth device and the Wicked Audio product and search again.

#### No sound when talking with someone on the phone using mic on Wicked Audio product:

- 1 - Make sure the Wicked Audio product is successfully paired with your Bluetooth device.
- 2 - Increase the volume of your Bluetooth device and/or Wicked Audio product.
- 3 - Make sure no fabric, dirt, or other gunk is obstructing the mic.

#### No sound when playing music:

- 1 - Increase the volume of your Bluetooth device and/or Wicked Audio product.
- 2 - Make sure the Wicked Audio is successfully paired with your Bluetooth device.
- 3 - Make sure the Hum 900 is charged.

#### Unable to charge:

- 1 - Wicked Audio product will have a solid red LED when charging and the LED will be solid blue when fully charged.
- 2 - Make sure the USB cable is connecting well with charger and the micro USB cable is connecting well with your Bluetooth device.
- 3 - Check to see if another device will charge from the same power source.

### LINE-IN MODE

When you'd like to use the Hum 900 as normal wired headphones (no Bluetooth), plug the aux cord into the "line-in" port. This is handy for listening to movies on the plane, if you don't want to drain the battery, or if the battery is dead.

### HELPFUL TIPS

- 1 - When the line-in port is being used, the button functions cannot be used. Return your product to Wireless mode to be able to use the full range of features.
- 2 - It is recommended to turn off the Hum 900 when using the aux cord as the battery will still drain if the Hum 900 is not in the off position.

### SPECIFICATIONS

**DRIVER** 40 mm Neodymium  
**SENSITIVITY** 103 dB  
**FREQUENCY** 20-20,000 Hz  
**IMPEDANCE** 32 Ohms  
**AUX CORD** 4 ft / 1.2 m / Gold-Plated  
**BLUETOOTH VERSION** 4.0  
**BLUETOOTH RANGE** 32ft / 10m  
**BATTERY LIFE** 13.5 Hours  
**CHARGE TIME** 2 Hours

### FEATURES

**WIRELESS BLUETOOTH**  
Version 4.0  
**SOFT-TECH CUSHIONS**  
Extra soft foam combined with luxury synthetic leather  
**COMFY FIT**  
Better conductivity  
**HANDS-FREE**  
Control your music without pulling your phone out of your pocket  
**ENHANCED BASS**  
Clear strong bass  
**WIDE RANGE**  
Broader range of sound  
**HIGH FIDELITY**  
High sound clarity  
**RECHARGEABLE BATTERY**  
13.5 hour battery with our Triple Battery Protection  
**FOLDS FLAT**  
COLLAPSIBLE  
**MIC, TRACK, & VOLUME CONTROL**  
**ALL DAY WEAR**  
**RUBBERIZED FINISH**  
Extra protection, feels good too  
**TOTAL EAR COVERAGE**



WICKED AUDIO, INC.  
875 W 325 N  
Lindon, UT 84042  
WICKEDAUDIO.COM



FOLLOW US!

### PRECAUTIONS

#### LISTENING TO AUDIO AT EXCESSIVE VOLUMES CAN CAUSE PERMANENT HEARING DAMAGE. USE AS LOW A VOLUME AS POSSIBLE.

Over exposure to excessive sound levels can damage your ears resulting in permanent noise-induced hearing loss (NIHL). Please use the following guidelines established by the Occupational Safety Health Administration (OSHA) on maximum time exposure to sound pressure levels before hearing damage occurs.

#### SAFE USE & HAZARD WARNINGS

90 dB SPL at 8 hours, 95 dB SPL at 4 hours, 100 dB SPL at 2 hours, 105 dB SPL at 1 hour, 110 dB SPL at 30 min, 115 dB SPL at 15 min, 120 dB SPL: Avoid as damage may occur

### ADVERTENCIA

#### ESCUCHA DEL AUDIO NIVELES EXCESIVOS DE VOLUMEN PUEDE CAUSAR DAÑOS PERMANENTES AUDIENCIA. SE USE COMO VOLUMEN MÁS BAJO POSIBLE.

Durante la exposición a niveles excesivos de ruido puede dañar los oídos resultando en ruido permanente pérdida de audición inducida (PAIR). Por favor, use las siguientes pautas establecidas por la Administración de Seguridad de Salud Ocupacional (OSHA) de tiempo máximo que los niveles de presión de sonido antes de que se produce una lesión auditiva.

#### USO SEGURO DE PELIGROS Y ADVERTENCIAS

90 dB SPL a 8 horas, 95 dB SPL a 4 horas 100 dB SPL a 2 horas, 105 dB SPL a 1 hora, 110 dB SPL a 30 minuto, 115 dB SPL a 15 minuto, 120 dB SPL: Evite que se puede producir daños

#### LIMITED ONE-YEAR WARRANTY

Keep your receipt to obtain warranty service. Go to [www.wickedaudio.com](http://www.wickedaudio.com) for more details.

#### GARANTÍA DE POR VIDA

Guarda su recibo para obtener servicio de garantía. Hora de salida [www.wickedaudio.com](http://www.wickedaudio.com) para más detalles.

Developed in Utah, U.S.A.  
Made in China



FCC ID: 2AMF7WI-BT90X

**FCC Statement:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

**Limitation of Liability:** Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. In no event, under any cause of action of theory of liability, shall Wicked Audio Inc., its distributors or suppliers be liable to you or any third party for indirect, incidental, consequential, special, exemplary or punitive damages, of any and all nature whatsoever, arising out of use of or inability to use a product. This includes without limitation, property damage, loss of value of the product or any third party products that are used in or with the Wicked Audio products, even if the Wicked Audio product has been advised of the possibility of such damages that one may encounter. Without limiting the foregoing, you understand and agree that Wicked Audio has no liability for any damages or destruction to the consumer electronics devices or other personal property that are contained in inside or outside the Wicked Audio products. This includes without limitation, laptops, cellular phones, or other hand-held devices, or any loss of data contained on the foreign device. Notwithstanding any damages that you might incur for general damages in contract, tort (including negligence) or otherwise, the entire aggregate liability of Wicked Audio and any of its distributors and/or suppliers shall be limited to the amount actually paid by you for the Wicked Audio product giving rise to liability. Some states and/or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. The Limitations of liability set forth above shall apply to the maximum extent permitted under applicable law.