X3S-SP3151-User Manual
# Product Name:Bluetooth speaker

Product speci ications：
- ●Bluetooth : 3.0
- ●Support: L2CAP/A2DP(AVCTP/AVDTP/AVRCP), can receive AUDIO signal and control the AUDIO device.support HSP/HFP (Handsfree profile), Built-in Mic for hands-free phone call
- ●Working distance: 10M
- ●SNR: ≥85db
- ●Battery:3.7V 600mAh Mah
- ●Normal volume playing time: 2H
- ●Speaker driver : Ø 40 mm,
- ●Power : 4Ω/3W
- ●Frequency response: 120 Hz-18KHz
- ●Unit size：120mm*39mm*56mm
- ●Unit weight：200g
- ●Charging: 5 V /500mAh

Product Feature:
1. International advanced bluetooth chip and circuit design techniques, support all bluetooth device ;
2. With FM function, can search radio station broadcast automatically.
3. With HI-FI speaker, to sure the clear and bright sound quality.
4. Support USB and Micro TF Card,

5. Dual power suppor by Mini USB charging /BL-5C lion battery, smart and fast charging
6. Support LINE IN audio input, connect bluetooth speaker through output devices, for example MP3, MP4,PSP,tablet pc, mobile phone,etc.
7. Play music after pairing with bluetooth device .for example mobile / MID/ TV, the working distance is within 10M.

key & slot function:

1. Power switch: off to close, on is working
2. DC 5V /LINE IN /ANT:
DC 5V:use the standard mini USB V8 charging cable for power charging.
LINE IN : it can play audio via AUX cable to audio device
ANT:you can put in the mini USB V8 charging cable or AUX cable to get better FM radio station
3. MICRO TF slot: it can decode and play MP3 format audio when put Micro TF card into the slot
4. USB slot:it can decode and play MP3 format audio when put USB card into the slot
5. When play music, press short to switch USB/TF/FM /bluetooth/line in . press 3 seconds long to close/open the LED flashing light .
6. Press short for last song, press long to turn down the volume.
7. Press short for next song, press long to turn up the volume.
8. When play music(USB card/ TF card/LINE IN/ bluetooth), press short for "play/pause ". under bluetooth mode with mobile paired ,press short to answer a call ,press again to hand up,

press twice to ring up a call .(in FM mode, press short to search station automatically, press again to stop searching)

NOTE:
Under FM mode, put in the charging cable or AUX cable to get better FM radio station

The device should only be charged via an USB port on a laptop or Portable DC Power.

The user manual