

User Manual for Smart Watch ACB110

Thank you for choosing our sport health intelligent Bluetooth watch. You can read this manual and fully understand the use if the device, in fact, with a taste of the functions and simple method of operation.

This equipment is mainly used brand of intelligent machines to be adapted to use, you can synchronize the phone book smart machines and provides a variety of useful feature and services to facilitate your work and leisure activities in the smart machine operation. This device has the fellow features: support for Bluetooth phone, Bluetooth message push (SMS, micro letter, QQ, ect., need Android to install smart machine above the Bluetooth notification APK), Bluetooth music player, calories, pedometer, sleep monitoring ,anti-lost, remote camera and so on.

Before you start using this device, the first smart phone to install the "Bluetooth notice"(BTNotification) application (support Android version ,Apple does not currently supported) and run, Bluetooth Smart Watch will be able to automatically synchronize with the time and date of smart phones, and the ability to interface display in the "message" and "distal notice" watch smart phone received notification of each application or send reminders, including SMS alerts, chat tool QQ, micro letters and other messages and reminds.

Use the "Bluetooth notice" need to open the "Bluetooth notification" service in the smart phone "Accessibility setting", and the in the option "Bluetooth notification " application needs to choose a good news message push or require shielding applications. Restart the phone and smart watches; you can use the Bluetooth connection.

"Bluetooth notification" Application "Bluetooth notice" application in the country can be a two-dimensional code, or visit the following link to download attachments by scanning: <http://pan.baidu.com/s/1hqsuR7A>, can also be installed via smart phone Searching " Bluetooth notice" application and download and install the application treasure.

1. How to wear and operate.

Wear this Bluetooth smart watch in the correct direction, the power button should be on the watch when worn on the right side, three touch buttons located beneath the mirror.



- On/off button, exit buttons: Press on/ off; after power in the operating menu short press buttons, refillable clock interface. The clock in the standby Screen, press the button lights on and off the backlight
- Touch keys at lower left corner. Menu / Enter key: The standby clock interface to access the main menu, as a confirmation key menu operation.
- Middle touch key. Dial into / flip key: The standby clock interface can enter dial interface, menu operation as the next flip key, Bluetooth when playing music and calls can enter volume adjustment.
- Lower right corner of the touch keys, return / hang up button: standby no effect, as the return menu operation keys, call hang up button.

In addition, the sliding finger touch can achieve the following functions:

- slide your finger around the touch screen: Menu page;
- finger tap the touch screen: Enter the menu;
- finger down from the top of the screen vertical stroke: Exit menu;

2. Bluetooth devices to connect, disconnect, and continued even

Connection way: watch initiate pairing Bluetooth connectivity information, Two connections: phone pairing information to initiate a Bluetooth connection. After a successful connection of Bluetooth Smart Watch will automatically send a request requires reading smart phone phonebook and call log (involving personal privacy, some intelligent machines do not open this feature) Please confirm the smart phone, or else the watch can not be synchronized to the phone book and call history will affect its normal use.

If the distance between the watch and smart phones more than 10 meters (middle case no obstructions such as walls, or else shortened distance) will be automatically disconnected within five minutes if the disconnect between the two can be connected also to achieve the distance, the watch will automatically and smart phones continued even otherwise need to manually connect continued.

Watches and smart phones are ringing to off the connection is successful and prompt.

3. Features

- Bluetooth search for Bluetooth device, connection, disconnection and other operations:
- Dial clock interface point in the middle of the dial at the bottom of the screen to enter the key or menu option to enter, dial numbers can also be selected via the menu "Call log".
Note: Do not block the speaker or microphone position during a call.
- Information can be viewed Smartphone received a text message.
- Phone book synchronization of the phone book.
- synchronize phone call records of the "missed call", "Dialed", "Received Calls" . "all talk" and other 30 records
- Bluetooth smartphone push notifications can view the QQ. micro letters and other information.

- Bluetooth music can play music on your smartphone via Bluetooth. Some intelligent machines will need to open the music player software to run properly. Bottom of the screen on the player interface points into the middle button to adjust the volume, or directly on the touch screen point of the volume "+"、"-" sign to enter the volume control interface that automatically returns after stopping operation, without manually exit.

- Remote camera control via Bluetooth smartphone camera to take pictures. Need the phone off the screen and not in the non-locked state, some smart phones are not matched.

- Pedometer

Pedometer designed specifically for those concerned about the health, recommends the use of chest stride proudly state of motion, the magnitude of the normal walking arm. Enabling a more accurate count to the number of steps. Top pedometer interface display for time, as the number of steps for the left window, the top right window distance (meters) below the display of calorie consumption, the middle square button to start\stop switch. The upper right corner of pedometer option. You can set parameters pedometer, reset, view records. Pedometer can run in the background.

To avoid false count, taking the initial steps for each user will not show up immediately in the number of steps the window, but steady pace until the count to start after the show, but also the number of the previous steps counted.

Number steps pedometer steps number displayed window is automatically cleared once a day. In the middle and then stop start pedometer, steps number continues to accumulate, not cleared.

For clearing the "Reset pedometer" by selecting the Options menu.

- Altimeter displays the current altitude.
- Barometer shows the current ambient air pressure and temperature.
- And-lost alarm when between Bluetooth Smart watches and smart phones connected over a certain distance, the watch will sound an alarm.
- power saving mode
- Setting the clock, the tone mode, volume , language , display settings, view battery power, as well as Bluetooth settings and restore the factory settings.

4. Charge

Bluetooth smart watch can connect a standard USB data cable, via computer USB port or a USB charger jack.

5. FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate this equipment.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.