
Seaboard **RISE**

۲

Quick Start Guide

۲








Welcome to your Seaboard RISE

This guide will help you set up your Seaboard RISE and its bundled software. After this simple installation, you'll be ready to start pushing the boundaries of musical expression.

۲


Package contents

۲



 (\bullet)

Register your Seaboard RISE



 (\bullet)

۲

Download and install your software

(0



Download the Seaboard RISE software bundle from My ROLI. Double click the installer "Seaboard RISE Bundle" in your downloads folder to begin the installation.

Installer contents

۲

Inside the installer package you will find ROLI Dashboard, Equator, and the Seaboard RISE User Manual. After the installation, you can find the software in your computer's applications or programs folder.



User Manual

()

Activate your software

(4)

۲

Launch Equator from your applications or programs folder. When prompted, fill in your username and password the same ones you chose in the registration step. You have now successfully activated your software bundle.

 (\bullet)

⊗⊝⊕	Equator	
	Please log-in with your ROLI account details to authorise this software.	
	Email address or ROLI username	
	Password	
	Register	


•

Connect with USB

Plug the USB cable into the USB B port on your Seaboard RISE. Connect the other end of the cable to your computer. Press the power button to turn on your Seaboard RISE, and you're ready to make music!

۲

 (\bigcirc)




Power

Connect over Bluetooth


Your Seaboard RISE can play Equator and other software instruments when using any MIDI over Bluetooth-compatible computer or mobile device. To prepare your Seaboard RISE for Bluetooth pairing, simply switch it on without a USB cable attached or detach the cable you already have plugged in. You will notice the Mode indicator light flashing dark blue. You are now ready to pair your device.

For more information on how to connect the Seaboard RISE to your specific computer or mobile device, please check out our Knowledge Base on roli.com/support/bluetooth.



User control panel

۲



۲

۲

Mode indicators



۲

Battery indicators

۲





۲




Ports

۲

Please note that you can charge your Seaboard RISE via the USB B port or the 9–12V 2A DC port (power adapter not included). The Seaboard RISE cannot be charged via the USB A port.

۲

The USB A port can be used to communicate with your mobile device using a camera connection kit. It can also be used to charge your device, but only while your Seaboard RISE is powered via a DC cable.




()

Using the 1/4 inch pedal jack

You can use a sustain or expression pedal by plugging a 1/4 inch connector into the pedal jack on your Seaboard RISE. Please note that part of the 1/4 inch connector will continue to be visible after a secure connection has been established.

۲

(�)



Caring for your Seaboard RISE

The Seaboard's unique silicone surface can gather dust over time. We recommend cleaning the surface with cleansing wipes regularly.



Using your Storage Case

۲

Your storage case will give you great protection for your Seaboard RISE at home, on the go, or as an insert in a flight case, but it has not been designed for rugged use or international travel on its own.



Get in touch

۲

Have we answered all of your questions? If not, please get in touch with our product support team. You can contact them directly through My ROLI. On this page you'll also find FAQs, user guides, DAW templates, and a lot of other useful information.

(

•



We're here to help you at any time!

The ROLL team

ROLI

۲

© 2015 ROLI Ltd. All rights reserved.

۲

