



413 **Air3** 

**MANUFACTURER**  
 Shenzhen SoundPEATS Information Technology Company Limited  
 #1 Room 1001, Building 4, Huihai 3rd Road, Changan Road,  
 Longhua District, Shenzhen, China 518102  
 www.soundpeats.com


**IC** **SRP**

CE, FCC, RoHS, REACH, WEEE, PSE, BSMI, UKCA, UKCA-Mark II, UKCA-Mark II (UKCA)

Use Guide | Gebrauchsanweisung | Manuel de l'utilisateur |  
 How to use | How to use | How to use | How to use




**Pairing**




1. Open the charging case lid while the case is with enough power left. Press and hold the button on the charging case for 3 seconds until the white light flashes. Both earbuds will turn on and enter pairing mode.
2. Activate the Bluetooth on your device and choose "SOUNDPEATS Air3" to connect.

**Reset**




1. Place both earbuds in the charging case. The white light on the charging case flashes twice. The earbuds start charging.
2. With the case lid open, press and hold the charging case button for 10 seconds until the white light flashes 7 times. Reset complete.
3. Close the case lid and repress to activate the earbuds.

**Wearing**



**Product Diagram**



**Touch Control**

Power On	Auto Open the case lid
Power Off	Auto Close the charging case and close the lid
Play/Pause	Manually Press and hold the MFB for 1s
Next	Auto Skip after touching the MFB for 1s
Previous	Auto Skip after touching the MFB for 1s
Volume Up	Press and hold the left MFB for 1.5s
Volume Down	Press and hold the right MFB for 1.5s
Power Off (Phone)	Double tap the MFB
Call	Press and hold the MFB for 1.5s
Next Between Call	Tap and hold the MFB to transfer the call to the phone
Device	Using a call
Switch Between Two Calls	Press and hold the MFB for 2s
Microphone Mute/Unmute	Press and hold the charging case button for 2s
Microphone Assist	Tap the right MFB
Enter Exit Game Mode	Tap the left MFB

**Game Mode**

1. Use AC21351. Add network the latest technology to ensure low latency in game mode and make sure the sound sync with the image.

2. Press and hold the earbuds and charging case lid once for 3 seconds when not in use to activate the game mode with a voice prompt "Game Mode" and deactivate the mode with a prompt "Exit Game Mode".

**Q&A**

**Q1: What does the indicator on the charging case light?**

If shows the battery power left in the charging case.

Charging Case Indicator	Battery Life
Green	51% - 100%
Yellow	21% - 50%
Red	1% - 20%

While charging the case, the indicator flashes slowly.

Charging Case Indicator	Battery Power
Blue	0 - 10%
White	20% - 30%
Green	50% - 99%
Red	100%

LED: Power on

**Q2: How to charge the charging case?**

1. Use a Type-C adapter to charge the case. Connect the mode that "AC" the indicator flashes while charging.
2. Press and hold the earbuds and charging case lid once for 3 seconds when not in use to activate the game mode.

**Q3: Why are the earbuds still connected to my phone after placing them back and closing the case lid?**

1. The charging case has no sleeping covers. The case QR1. Turn off the earbuds if the case battery is dead.
2. Please make sure the earbuds are correctly placed in the charging case, and the contacts on both the charging case and earbuds are clean. Please try to clean them with something like microfiber cloth.

**Q4: Why is the playtime not same as described?**

A single charge will not support continuous use for 17.5 hours. The earbuds work 5 hours for single charge and the charging case provides extra 2.5 recharges.

**FCC Statement**

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference to a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not properly installed and used, it may cause interference with other electronic equipment. It is encouraged to use proper shielding and grounding techniques to reduce the interference and to take the following steps to minimize the interference:

- 1. Increase the separation between the equipment and sensitive equipment.
- 2. Connect the equipment to an outlet on a circuit different from that to which the sensitive equipment is connected.
- 3. The device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) The device may not cause interference, (2) The device must accept any interference received, including interference that may cause undesired operation.

Changes in modifications or accessories approved by the manufacturer for compliance could void the user's warranty to operate the equipment.