Air3 Pro User Manual

1. POWERING ON/OFF:

Open the charging case,the earbuds will automatically power on.
To power off,place the earbuds into the charging case and close the case.
打开充电盒,耳机自动开机。如需要关机,请将耳机放入充电盒并关上盒盖即可。

2. PAIRING:

Open the charging case, the earbuds will automatically enter the Bluetooth pairing mode. Select "SOUNDPEATS Air3 Pro" on your device's Bluetooth list to connect. 打开充电盒,耳机自动进入蓝牙配对模式。从您设备的蓝牙列表中选择 "SOUNDPEATS Air3 Pro"并点击连接。

3. CONTROLS:

Under the music mode, tap twice the earbuds can make them pause/play. 在音乐模式下,双击可以使其暂停/播放。

Under the music mode, press and hold 1.5 seconds the R earbud can switch to the next track.

音乐模式下,右耳长按1.5秒可以切换到下一曲。

Tap three times the L earbud can open game mode or exit game mode.

左耳三击可以开启或者退出游戏模式。

Tap three times the R earbud can open Siri or exit Siri.

右耳三击可以开启或者退出语音助手。

Tap the L earbud can make the volume-,Tap the R earbud can make the volume+. 单击左耳音量减,单击右耳音量加。

When the call coming in,press and hold 1.5 seconds the earbuds can reject the call. Or tap twice the earbuds can answer the call and end of the call tap twice again. 来电时,您可以长按耳机 1.5 秒拒接电话。或者您也可以双击接听来电,再次双击可以结束通话。

Press and hold 1.5 seconds the L earbud can switch to the ANC ON or ANC OFF or Transoarency.

长按左耳 1.5 秒可以切换降噪开/关模式或者通透模式。

4. RE-PAIRING:

Pairing with another device:Place the earbuds into the charging case and close the case,and then remain the case open,Press and hold the button on the case for 3 seconds until the case Green LED indicator flash three times to enter pairing mode. 重新和其他设备配对: 把耳机放入充电盒先关盖,然后再打开盖子并且保持开盖状态,长按充电盒上面的按键 3 秒直到盒子上绿色 LED 闪烁 3 次即可重新进入蓝牙配对模式。

5. RESET:


Reset if the earbuds cannot properly pair with each other or with other devices. Place the earbuds into the charging case and close the case, and then remain the case open,Press and hold the button on the case for 10 seconds until the case Red LED indicator flash three times to enter Reset mode.in this way,earbuds can pair and connect with other devices.

如果耳机无法相互配对或者无法与其他设备配对,此时请复位耳机。 把耳机放入充电盒先关盖,然后再打开盖子并且保持开盖状态,长按充电盒上面的按键 10 秒直到盒子上红色 LED 闪烁 3 次即可进入复位模式。这样,耳机就可以和其他设备配对连接了。

6. Charging:

If the earbuds is warning Low voltage, please place the earbuds into the charging case and close the case, the charging case will automatically charge for earbuds. 如果耳机提示低电,请将耳机放入充电盒并关盖,充电盒会自动给耳机充电。 If the charging case is warning Low voltage, please place the Type-C into the charging cas, the external 5V power supply will automatically charge for the charging case. 如果充电盒提示低电,请将 Type-C 插入充电盒,外部 5V 电源会自动给充电盒充电。





FCC Statement:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.