



Life

Life
WIRELESS EARBUDS

MANUFACTURER
Shenzhen SoundSOL Information Technology Company Limited
Room 1308-1309, Building B, Huihai Square, Chuangye Road, Longhua District, Shenzhen, China, 518109
support@soundpeats.com
www.soundpeats.com

FCC ID: 2AFTU-D0031 IC: 27785-V0003
MADE IN CHINA

EC REP
Company: Qing Li (China) GmbH
Address: Lindendstr. 7, 12203 Berlin Germany


UK REP
TANMET INTL BUSINESS LTD
9 Pantygraigwen Road, Pantybridd, Mid Glamorgan, CF37 2RRLUK
tanmetbz@outlook.com

FC CE UK CA

FR DE GB ES IT PAPER

Life

First Start & Re-Pairing



- Please make sure the charging case have remaining power. Open the charging case lid, both earbuds will automatically enter TWS pairing mode. After successfully pairing with each other, the indicator on main earphone will flash in red and white, the indicator of second earphone will stay white, then the earphones will enter pairing mode.
- Find and click "SOUNDPEATS Life" in the Bluetooth list of your device to connect. The indicators of both earphones will stay on after successfully connected.
- SOUNDPEATS Life Bluetooth earphones can remember previously paired devices. When you make the second connection, simply activate the Bluetooth in your device and take out both earbuds from the charging case at the same time, these earphones will automatically connect to each other and pair with your device. If the earphones can't pair with your device automatically, please activate the Bluetooth in your device and choose "SOUNDPEATS Life" to connect.


Reset

Please try to reset the earphones according to following steps if the earphones fail to build connection or re-pair with your devices.


- Clean pairing record of the earphones in all your devices.
- Place back both earphones into the charging case and make sure they are in charging status. The indicator of the charging case will flash once when the earphones are successfully put in.
- Keep the charging case lid open, press and hold the button of the charging case for 10s until the white light flashes twice, reset complete.
- Close the lid and open it again to activate the earphones.

Wearing

- Identify the left and right earbuds according to the "L" and "R" logos on each side of the earphones.
- Rotate earphones and find the most comfortable position.



Product Diagram



Touch Control

Power On	Auto: Open up the case lid Manually: Press and hold the MFB for 1.5s
Power Off	Auto: Place earphones back into the charging case and close the lid Manually: Press and hold the MFB for 10s
Play / Pause	Double tap the MFB
Volume -	Single tap the left MFB
Volume +	Single tap the right MFB
Next Track	Press and hold the right MFB for 1.5s
Answer / Hang Up Phone Call	Double tap the MFB
Reject Phone Call	Press and hold the MFB for 1.5s
Switch Between Two Calls	Press and hold the MFB for 1.5s
Manually Enter Pairing Mode	Press and hold the MFB of the charging case for 3s
Activate Voice Assistant	Triple tap the right MFB
Enter / Exit Game Mode	Triple tap the left MFB
ANC / Transparency / Normal Mode	Long press the left MFB for 1.5s


Q&A

Q1: What does the indicator light of the charging case mean?

- It shows the power of charging case while:


100%—50%	Green
49%—10%	Yellow
10%-0%	Red
- When charging the case, the indicator light shows:

0%-20%	red light breathing slowly
21%-69%	yellow light breathing slowly
70%-99%	green light breathing slowly
100%	green light on
- Open the charging case lid, every time you place back or take out the earphones, the indicator of the charging case will flash once and stay on for 10s (the indicator light will change according to the remaining power of the charging case).



Q2: How to charge the earphones and the charging case?

- When the earphone is in low power state, a low power prompt will be broadcast. You can place back the earphones into the charging case to charge them.
- Please use a Type-C adapter to charge the case (current no more than 1A).
- Please charge the earbuds and charging case at least once per 3 months when not in use for a long time.



Q3: Why are the earphones still connected to my phone after placing them back and closing the case lid?

- The charging case has no remaining power. The case can't turn off the earbuds if the case battery is dead.
- Please make sure the earbuds are correctly placed in the charging case, and make sure the charging contactors and PIN pins are clean. Please try to clean where the charging case and the earphones are in contact with microfiber cloth.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC ID

-English-
This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) This device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

-Français-
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF warning statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.