


### Description of parts



### Package Contents



### Specifications

Item	Description
Bluetooth specification	4.1 (Headset/Hands-Free/A2DP Profiles)
Talk Time	Up to 12 hours
Music Time	Up to 10 hours
Standby Time	Up to 100 hours
Charging Time	Around 2-3 hours
Battery	3.7V/180 mAh Li-Polymer
Dimension	30g
Weight	135mm(w)*175mm(L)*15mm(H)

1

### How to Use

#### Power ON/Power Off

-Slide the Power switch to the ON or OFF position.

#### Charging

- When charging (with the power on or off) the headset will turn off.
- While charging, the LED indicator will show a solid red and then change to blue & red when charged 80% and above.
- When charging is completed, the LED indicator will show a solid blue light.

#### Low Battery

- An announcement will be made once every 2 minutes.
- If the battery is not charged, the headset will turn off.

#### Battery Status Alert

Battery Status	Full	High	Medium	Low
Voice Prompt	Battery Full	Battery Level High	Battery Level Medium	Battery Level Low
LED Indicator	Blinking Blue 3 times	Blinking Blue 3 times	Blinking Blue 3 times	Blinking Red 3 times

2

### How to Use

#### Pairing

- Before using the headset for the first time, you must pair it with a Bluetooth-enabled mobile phone.
- To pair your headset with an additional mobile phone, the headset must be placed in Pairing Mode.
- There are 2 Pairing Mode Methods with Q800.

#### Easy Pairing(First Time Pairing)

1. Slide the Power switch to the ON position to turn on the Q800. When the headset enters Pairing Mode, the LED indicators will show as a blinking blue & red light.
2. Using your mobile phone, find the Bluetooth Menu and search for or add new devices. Select Q800 from the list of the devices and pair it with your mobile phone.
3. If asked for the Pass/PIN code, please enter 0000(four zeros).

\*Note: If your mobile phone supports Secure Simple Pairing (SSP), you will not need to enter Pass/PIN code.

-Once pairing has completed successfully, you will hear "Your headset is connected".

\*The Q800 will first automatically connect with the last paired mobile phone when it turn on.

\*The Q800 will automatically turn off if not paired within 3 minutes.

#### Manual Pairing(Pairing when standby status)

- When Q800 is under standby status with solid blue light, long press CALL button to make the headset enter Pairing Mode with blinking blue and red light. Repeat Easy Pairing step 2 through 3 to pair the mobile phone with Q800.

3

### How to Use

#### Multi-connection

The Q800 is capable of having two devices connected to the headset at the same time. This will give you the freedom of using call waiting between calls on both of your connected phones.

#### Connection

- Pair the headset with one of your Bluetooth-enabled mobile phone (see pairing instructions on page 3, this will be your first mobile phone).
- Turn off the Bluetooth on first mobile phone.
- Don't turn off the headset, but long press CALL button till blue and red light blink, repeat Easy pairing step 2 through 3 to make another mobile phone connect with Q800. ( This will now be your 2nd mobile phone.)
- Turn on the Bluetooth on your first mobile phone and choose Q800. Then both mobile phones are connected with Q800.

\*NOTE: When the Q800 is connected to two mobile phones at the same time, the headset calling functions will work with the first mobile phones.


#### Calling Function

-Voice Dialing and Last Number Redial features work with first mobile phone (or mobile phone which made the last outgoing call).

#### Calling Waiting

-While speaking on an active call, long press CALL button to switch to an incoming call.

4



### How to Use

- To switch between 2 active calls, long press the CALL button.
- To terminate the active call or both calls at once, briefly press the CALL button.
- If both mobile phone are receiving an incoming call, the headset will default to the first mobile phone.

#### Auto Reconnect

-If the Q800 is turn off (either accidentally or intentionally) while connected to a mobile phone, the headset and mobile will disconnect. The headset and mobile phone will automatically reconnect when the Q800 is turned back to on while in range.

-The 2nd mobile phone need to be connected via selecting Q800 from the list of devices at Bluetooth menu.

#### Out of range

-If the paired devices are separated by a range of 10 meters (33 feet) or more, the headset and mobile phone will disconnect and Q800 will vibrate to alert.

-The headset and mobile phone can automatically reconnect if they back to required range within 3 minutes.

#### Calling

##### Answering a call/Ending a call

-When there is an incoming call, the headset will ring and vibrate.

-Briefly press the CALL button to answer or end a call.

##### Transferring a call

-While on a call on your mobile phone, press PLAY/PAUSE button twice on the Q800 to transfer the audio either from headset to mobile phone or from mobile phone to headset.

5

### How to Use

#### Voice dialing

-Briefly press the CALL button to activate the Voice Command.  
NOTE: If the mobile phone doesn't support Voice Dialing, it is possible that performing this action will activate Last Number Redial.

#### Last number redial

-Press and hold the CALL button to activate Last Number Redial.

The headset will beep, and call the last number dialed.

#### Reject a call

-Press the CALL button for 2 seconds when the mobile phone rings.

-Press Volume + & Previous track button at the same time.

\*Precaution: For your safety, do not operate microphone mute during driving.

#### Volume control

-Press Volume + or - to adjust volume.

#### Audio playback/Control

-PLAY: Briefly press the PLAY/PAUSE button.

-PAUSE: Briefly press the PLAY/PAUSE button.

-NEXT TRACK: Briefly press the NEXT TRACK button.

-PREVIOUS TRACK: Briefly press the PREVIOUS TRACK button.

6

### How to Use

#### LED indicator

Function	Q800 Status	Action
Operating	Power on	The blue LED light flickers 4 times.
	Power off	The red LED light flickers 4 times and then turns off.
	Pairing mode	The red and blue light flickers alternatively.
	Call connected	The blue LED light flickers 1 time every 5 seconds
Charging	Charging	The red LED light stays on and changes to red & blue light when charged 80% and above.
	Charging complete	The blue LED light stays on.

7

### Troubleshooting

Issue	Possible problem	Resolution
Does not turn on	Check whether the battery of the Q800 is fully charged.	Charge the battery.
Unable to communicate with the Bluetooth Headset Q800	Check whether the mobile phone supports the headset or hands-free Bluetooth profiles. Check whether the battery of the Q800 is low.	Determine whether your mobile phone supports the headset or hands-free Bluetooth profiles. Charge the battery.
Unable to pair the Q800 with the Bluetooth device	Check and make sure the headset is on. Check and make sure the headset is placed in pairing mode.	Slide the Power switch to the ON position to turn on the headset. When Q800 is in standby mode with solid blue light, long press CALL button till red and blue light blink, then Q800 enter Pairing Mode.
Low sound (speaker)	Check the speaker volume level.	Increase the volume level.

8



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.