# Dual mode wireless keyboard (2.4G & Bluetooth) User Manual Compatible System iOS / Android / Windows / Mac OS 2.4G Pairing Instructions 1. Insert the USB receiver into the

### Keys and Functions 1 x Phone Holder iOS Android Windows 10 1 v I ISB Reneiver Brightness + Brightness + Brightness Weight: 197.3g Stand-by time: 560 hours Previous Previous Previous Track Track Track Madrian distance: 10m Gleen time: Ten minuter Play/Pause Play/Pause Play/Pause Lithium hatten/ canacity: 140m&h Awaken way : Arbitrarily key to awaken Next Track Next Track Next Track Mute Mute Mute Volume - Volume - Volume -Volume + Volume + Volume + Battery Battery Battery Checking Checking Checking Print Screen Print Screen Or N/A Print Screen (j) Power Indicator: Displays blue when turned or; stay in red when charging; flash red Lock Scren Lock Scren Lock Scren quickly when low power. \_\_\_\_ Delete Delete Delete ② Bluetooth indicator: Displays blue and then goes out when switching channels

Mac OS	Windows	
Mac OS	Windows	
	Windows Mac OS	
Press fn +	Press fin+ shift+	
Home	esc	
Brightness -	F1	
Brightness +	F2	
Search	F3	
Previous Track	F4	
Play/Pause	F5	
Next Track	F6	
Muse	F7	
Volume -	F8	
Volume +	F9	
Battery Checking	F10	
Print Screen	FII	
N/A	F12	
Delete	N/A	

### button ( fn + Q/W/E/R ) to switch, so as not to affect no • If it fails to co If it fails to connect properly, it is recommended to turn off the Bluetooth keyboard power supply, restart and connect again.

When switching the operating system, please rememb.

Special Keys	Descriptions
	The fn key is used in combination with other keys to access special features.
A.	Press fn + this key to choose 2.4G Channel.
8	Press fn + this key to choose Bluetooth Channel 1.
□.	Press fn + this key to choose Bluetooth Channel 2.
<u> </u>	Press fn + Q to switch the function keys to iOS system.
W	Press fn + W to switch the function keys to Android system
	Press fn + E to switch the function keys to Windows syste
P	Press fn + R to switch the function keys to Mac OS system
Z	Press fn + Z to perform a left mouse click.
×	Press fn + X to perform a right mouse click
=======================================	Press fn + this key to work as virtual keyboard.  Note: this function work for iOS only.
	Press fn + 1 to work as page up. Press fn + 1 to work as page down.

	Press fn + to work as end.  Press fn + this key to check the battery reminding. The Indical flashes once for 25%, twice for 50%, 3 times for 75%, and 4 times.
	Press fn + to work as home.  Press fn + to work as end.
	Press fn + to work as page down.
1 [-1	Press fn + to work as page up.

ine

# yboard Language Switching

- · iOS 8 or below: command + space
- · iOS 9 or above: ctrl + space
- · Android: ctd + space / shift + space / others • Windows 10: ctrl / command +Space or alt + shift / caps Lock

Due to different system versions, the above way may not work in all

# Important \

As this is a multilingual keyboard, set the language of the device to your desired language before use

### · For iOS devices only:

Settings > General > Keyboard > Keyboards > Add new keyboard > Select desired language

### · For Samsung Android devices only:

Settings > Controls > Language and input > Samsung Keyboard > Select input languages > Select desired language

Settings > Language & input > Physical Keyboard > Set up keyboard

# layouts > Select desired language • For Windows devices only:

Control Panel > Clock, Language and Region > Select desired language

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off a nd on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receive
- -Connect the equipment into an outlet on a circuit different from that to
- -Consult the dealer or an experienced radio/TV technician for belo

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

Charge Samsers Bluetooth keyboard for 30 minutes. Low battery power

3. Make sure that your Samsers Bluetooth keyboard and computer are

can adversely affect connectivity and overall functionality.





2. Turn on the power switch located power indicator lights up in blue



3. Press fn + @ to select 2.4 G channel.



you can use the keyboard.



5. Press fn + Q/W/E/R to select your system to ensure that the function keys and touchpad functions are

# Bluetooth 1&2 Pairing Instructions

(i) Caps lock indicator: Displays blue when caps is locked



1. Turn on the nower switch located on the side of the keyboard, The power indicator lights up in blue and then goes out.



2. Press fn + 01/02 to select Bluetooth 1 channel or Bluetooth 2 channel



3 Press the Bluetooth connection button to make the keyboard enter the pairing state: the Bluetooth indicator light starts to flash blue.



4. Turn on the Bluetooth settings on the



After the connection is successful you can use the keyboard.



6. Press fn + Q/W/E/R to select your system to ensure that the function keys and touchpad functions are used normally.

### NOTE:

- 1. If multiple devices are used at the same time, press Fn + 6/m/ a to
- 2. If you want to change the device connected to the 2.4G / Bluetooth1 / Bluetooth 2 channel, just follow the above connection method and connect to the 2.4G / Bluetooth 1 / Bluetooth 2 channel.
- 3. Auto re-connect function: when you turn on the keyboard, it will connect with the last-used device automatically. (After the connection, don't press the connect button again, or it will disconnect and you have to reconnect it.)
- 4. If the connection fails, please delete all the pairing records from your device; turn off your device Bluetooth function and turn it on again and then follow the above instructions again.

# Touchpad Function Introduction

Touch Gesture	iOS (higher 13.4)	Android	Windows10	Mac OS
Switch Shortcut	fn + Q	fn + W	fn + E	fn + R
(One-layer (Mok)	Mouse Left	Mouse Left	Mouse Left	Mouse Left
(Twafinger dick)	Mouse Right	Mouse Right	Mouse Right	Mouse Right
(Twefinger skide)	Mouse Wheel	Mouse Wheel	Mouse Wheel	Mouse Wheel

Touch Gesture	(above13.4)	Android	Windows10	Mac OS
Switch Shortcut	fn + Q	fn + W	fn + E	fn + R
(Two-linger stretch)	Web Page Zoom	N/A	Zoom	N/A
(Three-finger click)	Main Screen	N/A	Screen	N/A
(Three-linger slid up)	Open/hide Window or N/A	N/A	Open Task Browser	N/A
(Three-larger skil dawn)	Open Al Active Windows	N/A	Back to Desktop	N/A
(Threefinger sld)	Switch Active Window	N/A	Switch Active Window	N/A
(Four-linger click)	Screenshot	N/A	Open Action Center	N/A

- Please press the corresponding button to switch, so as not to affect normal use.
- Touch gestures may vary depending on the system version or device type.
   If the touchpad doesn't work in iOS13.4 or higher, please make sure you have it enabled.
- Open "Settings"-"Accessibility"-"Touch"-"AssistiveTouch"-"On", and you can enable

# System Requirements

- Mac OS X v10.6 to Mac OS X v10.12 and above
- Windows XP / Vista / 7 / 8 / 10 , PC computer with a Bluetooth host
   Android 3.0 and above with Bluetooth HID profile
- (Smartphones and Tablets)
- This keyboard is not compatible with Samsung Smart TV , Xbox and

# How to Charge it

- 1. Use the included USB cable for charging. Connect one end to a USB
- charger, and the other to the keyboard. (USB charger is not included) In charging, the power indicator will turn red. Generally, it takes approximately 2-3 hours for a full charge. (Output: DC 5V/500mA)

# FAQ

# Q: Fail to connect. Step 1. Before to connect, please set as below.

- \*Charge Samsers Bluetooth keyboard for 30 minutes.
  \*On your device, delete/remove/forget the previous connection record with "Bluetooth Keyboard".
  \*On your device, turn Bluetooth off, and turn Bluetooth on again.
- \* Make sure that your Samsers device and your device are within close
- Step 2. Follow the Pairing Instruction to connect it again. Q: My Samsers Bluetooth keyboard frequently gets discont or laggy.

# within close proximity of each other. 4. Do not use on metal surfaces. Try moving away from: \* Any device that could emit wireless waves: Microwave, cordless

Restart your Bluetooth product.

- phone, baby monitor, wireless speaker, garage door opener,
- WiFi router

- \*Computer power supplies

  \*Metal or metal wining in the wal

  5. Make sure your operating system (OS) is up to date.

  6. Check if there are any updates running in the background that may
  cause the delirent computer/smartphone/tablet.

  7. Try on a different computer/smartphone/tablet.
- If the problem still persists, you will need to follow specific steps based on our device OS (Windows/Mac OS). Please email ur
- More questions about using under Android devices.

Android operating system is still not unified, and different manufacturer make different rule. For standard keyboard, because of rule change, the standard function may not work any more. If you are using under Android device and suffering some problems, please contact us.

If you have any use problems with our keyboard, please do not hesitate to contact us! Please rest assured that we will definitely help you solve them! Please contact us for a 24-month worry-free warranty: Samsers@126.com