Product features

IOS/Android		Windows	
Fn+	Corresponding function	Fn+Shift+	Corresponding function
~ 🖒 • Esc	Return to Desk	~ 🖒 • Esc	Home
! Q 1 F1	Search	! Q 1 F1	Search
@ ¹ 4 2 F2	Select	@ N 2 F2	Select
# D 3 F3	Сору	# D 3 F3	Сору
\$ B 4 F4	Stick	\$ 🖺 4 F4	Stick
% ¼ 5 F5	Cut	% ¾ 5 F5	Cut
^ 1 44 6 F6	Pre-Track	^ I 44 6 F6	Pre-Track
& ►II 7 F7	Play/Pause	& ►II 7 F7	Play/Pause
* ►►I 8 F8	Next	* ►►1 8 F8	Next
(◀ 9 F9	Mute	(◀ 9 F9	Mute
) ◄) 0 F10	Volume-) ◄) 0 F10	Volume-
— 4 8 — F11	Volume+	— ∢ 8 — F11	Volume+
+ <u>∩</u> = F12	Lock	+ <u>△</u> = F12	Lock

Three system switching languages

iOS: control+Space key switch language Windows: Alt+Shift switch language

Android: Shift+Space key switch language

Warranty Card

User information

Company or personage full name

Contact address_


The purchased product name and model NO.

Purchased date -

connection of power during use;



Android Connection Instructions:



1. Please turn on the power at the side of the keyboard, blue lights up,press the Bluetooth connection button, blue light will twinkle and into the match mode quickly



2. Open "Settings" and then click "Connect"





4. Click the pair name "Bluetooth Keyboard". pair request is displayed, click OK.

FAQ

Remarks: After connecting successfully the next time you don't need match code, just open the Bluetooth keyboard power switch and the tablet PC "Bluetooth." The BT keyboard will search the device and automatic connects.

1) At first check the BT keyboard is into match code state, then open

2) Checking the BT keyboard Battery is enough, the battery low is also

Keyboard indication always flashing when use, is means the keyboard

The Bluetooth keyboard is not used for a period of time, the device will

automatically enter the sleep state in order to save power. Press any

key on the keyboard to wake up, and the Bluetooth connection will be

1. The tablet PC can't connect the BT keyboard?

lead to can't connect, you need charge.

3. The table PC display BT keyboard is disconnect?


automatically restored.

2. The keyboard indication light always flashing when use?

will be no power ,please charge the power as soon as possible.

the table PC Bluetooth searching.

• Win 10 Connection Instructions:



1. Please turn on the power at the side of the keyboard, blue lights up,press the Bluetooth connection button, blue light will twinkle and into the match mode quickly



2. Open settings, turn on Bluetooth, click Add Bluetooth



Select "Bluetooth" in the Add Device to search




. You will find the "Bluetooth keyboard" and then click the pairing name to connect.



5. There is a tip for connecting successfully, you can use your keyboard comfortably

• iOS Connection Instructions:



1. Please turn on the power at the side of the keyboard, blue lights up,press the Bluetooth connection button, blue light will twinkle and into the match mode quickly.




Open the tablet PC setting "Bluetooth" into searching and pairing status



ou will find the "Bluetooth Keyboard"and then click



There is a tip for connecting successfully ,you can



Compatible System

Win /iOS /Android

Bluetooth Keyboard User's Manual

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Regrient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Please read the user manual carefully before you start using this product

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this manual without the permission of seller.

Safety instructions

Do not open or repair this device, Do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from the purchase day.

Keyboard Maintenance

1.Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet

- 2.Please don't expose the keyboard at too high or too low temperature
- 3.Please don't put keyboard under sun for a long time.
- 4. Please don't put keyboard close to the flame, such as cooking stoves, candles or fireplace.
- 5. Avoid sharp objects scratching products, timely to recharge products to ensure the normal use.

Touch pad function description (Android), must be switched to Android system



Tap — The left of mouse button











User-defined:



'single finger, Two-finger, Three-finger'.





Settings - Auxiliary Functions - Touch - Auxiliary Touches - Device -

Click the keyboard's pairing name, and then customize the function of

Touch pad function description (iOS 13.4.1 and

above), must be switched to iOS system











Technical Specifications

Touchpad size: 54.8 x 44.8 mm

Key working current: < 5 mA

Working distance: 10 m

Working voltage: 3.7 V

Touchpad working current: <11 mA

Lithium battery capacity: 140 mAh

switched to Windows system

Keyboard size: 304.5 x 97.95 x 8 mm (open)





Touchpad function description (Windows10), must be

Three-finger slide to the

Weight: 197.3 g

Standby current: < 1.5 mA

Sleep current: < 60 uA

Sleep time: Ten minutes

Awaken way : Press key



hree-finger slides up



hree-finger slide to the - Active window switch

Switch the active window

The right of mouse button

Two-finger sepration.

- Zoom in / out







Status Display LED

- Connect : Open the power switch, blue lights up, press the connect button, blue light twinkles.
- Charging: Indicator light will be on red, after fully charging, the light crush out.
- Low Voltage Indication : When the voltage is below 3.3 V, red light twinkles.

Remarks: In order to prolong the life span of the battery, when you do not use the keyboard for a long time, please switch off the power.