

©2018 Zeikos, Inc. iHip is a trademark of Zeikos, Inc. All Rights Reserved. iPod, iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries. All other trademarks and trade names are those of their respective owners. United States and International patent pending. The illustrated product and specifications may differ slightly from that supplied. Designed by iHip, Manufactured in China. For ages 12+. This is not a toy. This product contains chemicals known to the state of California to cause cancer and/or birth defects or other reproductive harm.

iHip
19 Progress street
Edison, New Jersey
08820
Limited 1 Year Warranty.
Customer service: 1-800-500-4434
To activate your product warranty go to our website www.ihip.com & register this product.

Bluetooth®

iHip.



WARRIOR

BREACHED - IPWARBT1
INSTRUCTION MANUAL

PAGE 2.

TURNING ON/PAIRING:


1. Press the **POWER/PLAY/PAUSE** button for 5-6 seconds the LED light will quickly flash four times continue to hold the **POWER** button until the LED light flashes **BLUE & RED**
2. The flashing **BLUE & RED** indicates being in pairing mode. Make sure the audio device or the smartphone's **BLUETOOTH** is turned **ON**. The device should start searching for **BLUETOOTH** enabled devices. Once the **IPWARBT1** is found click on it or select pair. If there is a password required enter **000 0**

PAGE 11.


PAGE 10.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



PAGE 3.



PAGE 4.


TAKING CALLS

1. Press the **POWER/PLAY/PAUSE** button to Answer the call. To end the call press the power button again.
2. To Reject an incoming call Press and Hold **POWER/PLAY/PAUSE** button

VOLUME CONTROL:

1. To adjust the volume, press the Volume +, or Volume - repeatedly to adjust the volume.

PAGE 9.



CHARGES WITH USB PORTS

PAGE 8.

POWER/CHARGING:

1. To Power on/off press and hold the **POWER/PLAY/PAUSE** for 3 seconds You will hear a beep going up in tone while turning on and a beep going down in tone while being powered off.
2. To charge, plug the Micro USB cord into the Micro USB port on the back of the headphones. When charging, the red light will remain on. When the battery is low, the red light on the back will flash quickly 3 times & a beep can be heard in the headphones. This beep will indicate when it is time to recharge the batteries.

PAGE 5.

Technical Specs

Driver: 10mm


Sensitivity: 103+/-3dB/mw 1Hz

Frequency: 20-20kHz

Impedance: 16 ohm

Transmission Distance: 33ft


PAGE 6.



SMARTPHONES

LAPTOPS

PAGE 7.



TABLETS