



# SOUND • FLEX

## In-ear Bluetooth ear-buds

# User Manual



- ① USB Charging port
- ② V+
- ③ Multi-functional button
- ④ MIC
- ⑤ V-
- ⑥ LED



### Specifications

Product size: 630\*21\*23mm  
 Product weight: about 13g (bare units)  
 Working voltage: 3.7 V  
 Low-voltage implication: 3.2 V  
 Play time: about 2-3 hours  
 Charging voltage: DC 5 V  
 Charging interface: MICRO USB  
 Charging time: about 1 hour  
 Charging current: 40mA  
 Automatically turns off after 5 min. of no use.  
 Battery indicator: supports IOS system battery indicator

### Components

Battery lifetime: 300 times



### Warnings & Notes

- DO NOT OVERCHARGE. Unplug after 4 hours charging time.
- Do not store unit in high temperature environment, including intense sunlight heat. Do not place unit near fire or other excessively hot environments.
- Be cautious of excessive drops, bumps, abrasions or other impurities. If there is any damage to the battery such as dents, punctures, tears, deformities of corrosion, due to any cause, discontinue use and contact manufacturer or dispose of in an appropriate manner.
- Do not disassemble or attempt to modify it or replace any part of this unit.
- Do not expose unit to moisture, snow or submerge it in liquid.
- Do not attempt to charge unit using any other method, or connection other than the supplied accessories.

### Warranty & Limitations

- To activate your product warranty go to our website <http://www.pomgear.com/warranty/> & register this product
- Warranty limited to three years from the date of purchase.
- Guarantee will not be applied to the damages caused by faulty usages.

Products that have been subjected to abuse, misuse, accident, alteration, modification, tampering, negligence, faulty connection, attachment to any unauthorized accessory, lack of responsible care, repair or service in any way that is not mentioned in the manual for the product.

The damage caused by dust, wetness, coldness, overheating, placement near hot objects, near fire storage or use of corrosive elements.

No warranty in damage caused by of acts of god or natural disasters such as floods, fires, typhoons, earthquakes and related matters.

To the extent permitted by law, POM GEAR shall not be liable for damages beyond replacing the defective product.

#### Technical support:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product, please do not return it to the store you purchased it from. You can contact a POM Gear representative and they will assist you with any questions you might have. Send email to [warranty@pomgear.com](mailto:warranty@pomgear.com)

©2016 POM GEAR Inc. All Rights reserved. All other trademarks and trade names are those of their respective owners. The illustrated product and specifications may differ slightly from that supplied. Designed by POM Gear USA. Manufactured in China.

### User instructions

- Power on: Press & hold the multi-functional button until blue LED goes on.
- Power off: Press & hold the multi-functional button until red LED goes on.
- Pairing: When unit is powered off, press & hold the multi-functional button for about 8-10s until rapid blinking blue & red LED lights appear. Unit is now in pairing mode. make sure you bluetooth enable device is on and search for "Pom sound flex" to appear and select to pair.
- Volume control: while listening, press the V+ button to increase volume, or the V- button to decrease volume.
- Music track: while listening, press & hold the V+ button for the next song, press & hold the V- button for the previous song.
- Pause/Play: While listening, press the multi-functional button to pause music; Press the button again to play music.
- Answer/End call: Tap the multi-functional button.
- Reject call: Press the multi-functional button for to 1-2s.
- Redial last number: Double click the multi-functional button to call the last phone number.

### LED Indication

- Low voltage alarm: red LED flashing
- Charging: red LED on when charging and blue LED on when fully charged;
- Bluetooth connected: blue LED flashing slowly
- Bluetooth unconnected: blue LED flashing rapidly
- Bluetooth pairing: Blue and red LED flashing rapidly together

### Accessories

- Charging cable: 30CM+USBAM+Micro USB 5 PIN black PVC
- Large and small size of earpieces
- Shirt clip

### Compatibility:

In-ear Bluetooth ear-buds designed and intended to be used for all mobile devices that support bluetooth .



### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation