

<div data-bbox="131 158 253 711" data-label="Image"></div> <div data-bbox="34 776 348 840" data-label="Section-Header"> <h2>Bluetooth AI Translation Stick User Guide</h2> </div> <div data-bbox="19 921 361 960" data-label="Text"> <p>Bluetooth AI translation stick user's manual</p> <p>Please read carefully before use</p> </div>	<div data-bbox="455 54 672 119" data-label="Section-Header"> <h2>Product Function Description</h2> </div> <div data-bbox="392 294 742 825" data-label="Image"></div> <div data-bbox="557 952 582 970" data-label="Text"> <p>-1-</p> </div>	<div data-bbox="780 39 1117 64" data-label="Section-Header"> <h2>Download and connect to the app</h2> </div> <div data-bbox="780 78 1127 409" data-label="List-Group"> <ol style="list-style-type: none"> 1. Scan the QR code below with your mobile phone to install the translation and communication APP 2. Open the mobile APP account with the mobile account to log in 3. Follow the operation steps to complete the connection with the translation stick. Main: Location/Bluetooth/Microphone /Notification and other permissions need to be selected and allowed; IOS system mobile phone needs to manually connect to the Bluetooth device prefixed with AUD in the Bluetooth settings. </div> <div data-bbox="957 123 1117 284" data-label="Image"></div> <div data-bbox="780 441 946 466" data-label="Section-Header"> <h2>Switch machine.</h2> </div> <div data-bbox="780 476 1127 515" data-label="Text"> <p>Press and hold the power button to switch the translation stick.</p> </div> <div data-bbox="780 544 984 570" data-label="Section-Header"> <h2>Dialogue translation</h2> </div> <div data-bbox="780 582 1127 709" data-label="List-Group"> <ol style="list-style-type: none"> 1. Press and hold the A key to speak, and release it to translate the language corresponding to the A key in the APP; 2. Press and hold the B key to speak, and release it to translate the language corresponding to the APPB middle key. </div> <div data-bbox="780 736 1041 762" data-label="Section-Header"> <h2>Language switch selection</h2> </div> <div data-bbox="780 772 1127 791" data-label="Text"> <p>Please switch the language at the top of the APP:</p> </div> <div data-bbox="793 825 1102 934" data-label="Image"></div> <div data-bbox="938 952 963 970" data-label="Text"> <p>-2-</p> </div>	<div data-bbox="1165 39 1235 64" data-label="Section-Header"> <h2>Repeat</h2> </div> <div data-bbox="1165 78 1511 135" data-label="List-Group"> <ol style="list-style-type: none"> 1. Short press the M button to play and repeat the last translation content, and you can listen to the repeat while following it. </div> <div data-bbox="1165 152 1281 178" data-label="Section-Header"> <h2>AI assistant</h2> </div> <div data-bbox="1165 188 1511 358" data-label="Text"> <p>Long press the M button to enter the AI assistant function, which can conduct encyclopedia questions and answers, play nursery rhymes, listen to opera comics, and more than 40 AI artificial intelligence skills. How to use: Long press the M key to speak the question you need to know, and after releasing it, the corresponding answer or corresponding audio content will be played.</p> </div> <div data-bbox="1165 384 1494 409" data-label="Section-Header"> <h2>Volume addition and subtraction</h2> </div> <div data-bbox="1165 417 1511 501" data-label="List-Group"> <ol style="list-style-type: none"> 1. Short press the A button to increase the volume; 2. Short press the B button to decrease the volume. </div> <div data-bbox="1165 527 1348 552" data-label="Section-Header"> <h2>State of work light</h2> </div> <div data-bbox="1165 562 1511 917" data-label="List-Group"> <ol style="list-style-type: none"> 1. The red light is on in the charging state; 2. The blue light is on after fully charged; 3. The red light flashes in the low power state; 4. The blue light keeps flashing slowly when the Bluetooth is not connected when the device is turned on; 5. The blue light goes out after successful Bluetooth connection; 6. Turn off the voice broadcast without lighting; 7. Press the A/B button to pick up the sound and turn on the blue light, let go and start translating and turn off the light; 8. To repeat the last sentence, press the M button and the blue light will flash once to start repeating. </div> <div data-bbox="1319 952 1344 970" data-label="Text"> <p>-3-</p> </div>	<div data-bbox="1546 39 1711 64" data-label="Section-Header"> <h2>Troubleshooting</h2> </div> <div data-bbox="1546 78 1892 115" data-label="Section-Header"> <h3>The translation stick often disconnects from the phone</h3> </div> <div data-bbox="1546 125 1892 241" data-label="List-Group"> <ol style="list-style-type: none"> 1. Switch the Bluetooth of the mobile phone again; 2. Close the APP in the background and reopen it; 3. Try to connect the translation stick after restarting the phone. </div> <div data-bbox="1546 266 1892 303" data-label="Section-Header"> <h3>The translation stick is silent after connecting to the app</h3> </div> <div data-bbox="1546 313 1892 431" data-label="List-Group"> <ol style="list-style-type: none"> 1. Please turn the phone and translation stick to the maximum; 2. (IOS) Please go to the Bluetooth settings and confirm that the AUD Bluetooth device has been connected, and the audio data needs to be connected to transfer to the translation stick. </div> <div data-bbox="1546 458 1675 484" data-label="Section-Header"> <h2>Can not boot</h2> </div> <div data-bbox="1546 491 1892 548" data-label="List-Group"> <ol style="list-style-type: none"> 1. Check whether the battery is exhausted, connect the charger and charge it for 2 minutes and check whether the red light is on. </div> <div data-bbox="1700 952 1725 970" data-label="Text"> <p>-4-</p> </div>
<div data-bbox="100 1015 277 1048" data-label="Section-Header"> <h2>Precautions</h2> </div> <div data-bbox="19 1099 361 1211" data-label="Text"> <p>★ Do not random discard the machine or place it in a fire, as it may cause danger because of built-in polymer battery.</p> </div> <div data-bbox="19 1234 361 1303" data-label="Text"> <p>★ The charging voltage of this machine is 5V. When charging this machine, use a 5V charger.</p> </div> <div data-bbox="19 1326 361 1438" data-label="Text"> <p>If you charge this machine with a charger higher than 5V, it will burn out the chip inside the machine and cause the machine to malfunction.</p> </div> <div data-bbox="19 1462 361 1528" data-label="Text"> <p>The following conditions are not covered by the warranty:</p> </div> <div data-bbox="19 1552 361 1844" data-label="List-Group"> <ul style="list-style-type: none"> ★ 1. due to improper use of the user, and self-repairing caused by artificial disassembly; ★ 2. Failure caused by irresistible factors (such as flood, fire, earthquake, lightning, etc.) after purchase; ★ 3. no product warranty card, valid purchase certificate, Don't match the product model. </div> <div data-bbox="177 1934 201 1952" data-label="Text"> <p>-5-</p> </div>	<div data-bbox="496 1015 635 1070" data-label="Section-Header"> <h2>Warranty</h2> <p>Warranty Terms</p> </div> <div data-bbox="399 1097 742 1203" data-label="Text"> <p>1 year warranty Since purchasing this product, the user enjoys free warranty service when the machine fails according to the user manual operation instruction.</p> </div> <div data-bbox="399 1211 742 1321" data-label="Text"> <p>When applying the warranty, the user needs to present a valid proof of purchase to the local dealer, and the dealer will contact the manufacturer for repairs.</p> </div> <div data-bbox="399 1328 742 1438" data-label="Text"> <p>During the warranty period, the manufacturer will charge a reasonable raw material fee or maintenance fee based on the specific failure in the following circumstances:</p> </div> <div data-bbox="399 1446 742 1848" data-label="List-Group"> <ol style="list-style-type: none"> 1. Damage caused by improper storage, improper use, fall off, or failure to use as required after purchase. 2. Damage caused by disassembly, maintenance, and cleaning of the machine without permission. 3. the appearance of scratches during use, artificial damage and other circumstances need to replace the new shell. 4. The use of fast charging causes the machine to malfunction (including fast charging head and fast charging cable), please use the charging cable that comes with the machine to charge. </div> <div data-bbox="527 1881 727 1901" data-label="Text"> <p>Note: The company has the</p> </div> <div data-bbox="557 1934 582 1952" data-label="Text"> <p>-6-</p> </div>	<div data-bbox="837 1015 1052 1070" data-label="Section-Header"> <h2>Warranty Card</h2> <p>WARRANTY CARD</p> </div> <div data-bbox="780 1097 1127 1177" data-label="Text"> <p>Thank you for purchasing our products, please fill in the following content when purchasing and save this card properly .</p> </div> <div data-bbox="877 1195 1022 1226" data-label="Section-Header"> <h3>User profile</h3> </div> <div data-bbox="780 1266 1127 1287" data-label="Text"> <p>Contact person: _____</p> </div> <div data-bbox="780 1362 1127 1383" data-label="Text"> <p>Contact number : _____</p> </div> <div data-bbox="780 1458 1127 1479" data-label="Text"> <p>Date of purchase : _____</p> </div> <div data-bbox="780 1554 1127 1575" data-label="Text"> <p>Purchase address: _____</p> </div> <div data-bbox="780 1650 1127 1671" data-label="Text"> <p>contact address: _____</p> </div> <div data-bbox="780 1746 1127 1767" data-label="Text"> <p>Remark: _____</p> </div> <div data-bbox="919 1879 1115 1901" data-label="Text"> <p>★ Warranty with this card</p> </div> <div data-bbox="938 1934 963 1952" data-label="Text"> <p>-7-</p> </div>		

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.