



Contact us


Distributor's Information



Contact us

Add: No.666 Jianlin Road,
High tech Zone, Suzhou, Jiangsu, China
TEL: 0512-66710918
Email: sales@yoko-bct.com
Web: www.yoko-bct.com

*Unique & In Fashion
A brand new world for you*



YOKO BCT-GLASS User Manual U3

Suzhou YOKO BCT Electronic Corporation

Accessories

Items	Quantity
Warranty card	1
User manual	1
Charging cable	1
Charger	1

Troubleshooting

Issue	Possible problem	Resolution
Does not turn on	Check if the battery power is low	Charge the battery. During charging, the indicator light will turn red. Once the headset is fully charged, the red indicator light will go out.
Unable to pair	U1 doesn't enter pairing mode	Turn off U1, press and hold the MFB button for 3 seconds. When flashes blue and red, search for the headset again.
If the above resolutions cannot solve your problem, please contact us immediately. We will settle these for you as soon as possible. Do not dismantle.		

FCC CAUTION:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) this device may not cause harmful interference, and
 (2) this device must accept any interference received, including interference that may cause undesired operation.

Note:
 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF EXPOSURE STATEMENT:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Technical Parameters

Speaker sensitivity: 92dB
 Frequency range: 20Hz-20KHz
 Bluetooth version: Bluetooth4.1
 Bluetooth protocol: AVRCP A2DP HFP HSP
 Operating range: 10 Meters
 Working temperature: -10°C ~ +65°C
 Working altitude: 0-10,000 Meters

Product model: U3
 Product type: Bone conduction Bluetooth Sunglasses
 Charger port: Micro USB 5V
 Weight: 54g
 Standby time: Up to 100 Hours
 Talk time: Up to 6 Hours
 Play time: Up to 6 hours
 Charging time: Approximately 3 hours
 Producer: Suzhou YOKO BCT Electronic Corporation

Storage and maintenance

- Wipe your headset with a soft towel.
- Do not store your headset with any sharp object.
- Do not store your headset in very hot or very cold areas.
- Try to avoid pull, stress or other artificial damage that will make the headset deformed and influence the comfort.
- The headset is not waterproof.

Charging the battery

Connect the headset to the USB socket on your PC or a wall charger via Micro USB cable. The headset fully charges in approximately three hours. During charging, the indicator light will turn red. Once the headset is fully charged, the red indicator light will go out.

Note:
 It's recommended to charge U1 before using for the first time.

Functional description

Status	Previous status	MFB button	Volume (+) button	Volume (-) button	LED indicator	Voice prompt
Power on (Reconnect mode or Bluetooth Pairing Mode)	Power off	Press and hold MFB button for about 3 seconds	---	Volume (-) button	LED indicator	Voice prompt
Power off	Power on(Connection mode or Pairing mode)	Press and hold MFB button for about 3 seconds	---	---	Flashes blue once, then flashes blue and red. When connected successfully, continuously on blue.	Four ascending notes, when connected successfully, one note
Answering a call	Incoming call (ringing)	Press MFB button	---	---	Flashes red once	Four descending notes
Ending a call	Talking	Press MFB button	---	---	Flashes blue once every 3 seconds	Incoming call, one note
Rejecting a call	Incoming call (Connection mode)	Press and hold MFB button for about one second	---	---	---	---
Playing A2DP music	Music software works and no other function works (Connection mode)	Press MFB button	---	---	Flashes blue once every 3 seconds	---
Pause A2DP music	Playing (Connection mode)	Press MFB button	---	---	Flashes blue once every 3 seconds	---
Adjusting the volume	Playing (Connection mode)	---	Short press VO+ button to increase the volume	Short press VO- button to decrease the volume	Continuously on blue.	---
Skipping to the previous song	Playing (Connection mode)	---	---	Press and hold VO- button	Flashes blue once every 3 seconds	If the volume has been the maximum, one note
Skipping to the next song	Playing (Connection mode)	---	Press and hold VO+ button	---	---	---