

60 mm

90 mm

Congratulations on your Bluetooth speaker.

This Bluetooth speaker allows you to enjoy your music without wires. Please read this manual before use.

How to use

- Before using the speaker please charge it for at least 1 hours. You can do so by plugging the micro USB cable into the speaker and the other part into the USB port of your computer. Once the speaker has been charged switch the device on by switching the on/off button.
- If you want to pair your mobile device or computer with the speaker please make sure the Bluetooth mode on your device is switched on. Please select "AAAA" to pair your mobile device with the speaker.

Troubleshooting

- If the battery runs low the device will produce a beeping sound. Please reconnect the speaker to your computer to charge it.



Remarks

- If a password is requested to connect the device please fill out 0000 as password.
- Once the device has been connected once the device will automatically be recognized.

Warning!

- Keep speaker away from water and moisture
- Keep speaker away from any heat source

Top-side Buttons	
1	Next song (tap)/Volume up (press and hold)
2	Ⓜ / Answer / Reject call
3	Previous song(tap)/ Volume down (press and hold)
BACKSIDE	
A	AUX
B	Micro USB-in
C	Turn on/Turn off



FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.