

尺寸: 85x55mm

正面

Wireless Charging Power Bank

USER MANUAL



Specification

Battery Capacity	8000/10000mAh	Battery Type	Polymer Lithium-ion
Input	5V~2A(Max)	USB output	5V~2.1A(Max)
Wireless output	5W	Dimension	142x70x18mm

Package Contents

Power Bank x1

Charging Cable x1


User Manual x1

Product Introduction

Thank you for purchasing the Wireless charging Power Bank. Before using the power bank, Please read the manual carefully and follow the instructions to operate properly.

The wireless charging power bank can be charged by connecting the charging cable to a powered USB port with DC5V output. It offers you a chance to discover wireless charging at any time and place and provides perfect charging service for your electronic devices with DC5V input.

IO Ports, Buttons and Indicators



① Type-C input
② Lightning input
③ USB output
④ Power button
⑤ Center of Wireless Transmitter
⑥ Hidden Stand
⑦ LED Indicators

4 White LEDs: Each indicating display about 25% of electricity capacity. If only 1 white LED is on or flashing, Please recharge the power bank.

Red LED: When press the power button or charging your mobile device, the red LED is on. When wireless charging, the red LED is off.

Blue LED: When wireless charging only, Blue light is on.

Operating Instructions

1. Charging Power Bank



1. Connect the Type-C connector or Lightning of a USB cable into the related input port, and connect the USB connector to a power supply with USB output (not included). We recommend USB chargers with a 1A to

背面

2A output.

2. When charging, the white LEDs are on. Each white light indicates about 25% of the capacity. When fully charged, all white LED lights will stay on.

3. Note: Fully charge the power bank for at least 10 hours before using the power bank for the first time. Recharge the power bank once every three months when not in use or seldom used.

2. Charging Mobile device





A. Wired charging

Press the power button, white indicator lights are on. One end of charging cable must be inserted in the USB port, and the other end must be inserted in the charging port of your device which needs to be charged. When charging mobile device, The white LED lights are on.

B. Wireless charging

Press the power button, red indicator light is on. Put your smartphone on top of the power bank, exactly in the center of the wireless charging area and the blue LED light is on and the red indicator is off.

Note: Make sure your smartphone is fit for Qi standard receiving equipment.

Troubleshooting

1. Press the power button, If only one white LED light is flashing, battery is running out soon, please recharge.

2. This power bank can automatically identify equipment that need to charge, If there is no equipment on it, the power bank will be turned off after 30 seconds.

3. For wireless charging, your mobile device must be equipped with a Qi wireless receiver. The device can automatically identify a Qi-compatible device placed on it.

4. If the center point of the receiving terminal is deflected over 10mm from the center point of transmitting terminal, the power bank will be turned off automatically.

5. If wired charging is not working properly, please try a different charging cable, since the connector may become loose due to wearing.

6. During charging, the device may become warm due to high currents and resistance, especially during wireless charging. To reduce temperature, avoid running intensive applications or using GPS on your mobile device when charging.

Caution:

Read all the instructions and warnings carefully prior to using this product.

The power bank will generate heat when charging. Always charge in a well-ventilated and open-air area. Do not charge under pillows, blankets, clothing or on flammable surfaces.

- Keep the power bank away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
- Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into the power bank.
- Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy objects on the power bank.
- Do not short-circuit the power bank or store it in a receptacle where it may be short-circuited by other metallic or conductive objects.
- Do not operate the power bank if it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury. Contact the dealer or authorized agent.

two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.