

- Hold the sound amplifier with your index finger and thumb.

product is stable in the ear and will not fall.

**PAIRING-FIRST USE** 

circle icon to pair and connect.

- Gently insert the sound amplifier into the ear canal, and then rotate it forward or backward until the

1. Open the charging box, the sound amplifier will automatically enter the bluetooth pairing mode.

2. Open your phone settings, turn on the Bluetooth, search for device HAT607, and then click the

HOW T	O USE SOUND	AMPLIFIER			
Number	Mode	Function	Tone Noitce	Led Indicator	Operation
1	Sound Amplifier Mode	Turn on	Ten Ti din Tin	/	Take out sound amplifier from charging case.
2		The battery on the left is low	Left battery is low	/	
3		The battery on the right is low	Right battery is low	/	
4		Turn off	/	/	Put the sound amplifier into the charging box bin, close the charging box coversound amplifier automatically turn off after 3 seconds and start to charging.
5		The sound amplifier shuts off when the battery is low	Don Di Din Den	/	
6		Volume 1	Du	/	
7		Volume 2	Du	/	1.Double click the touch panel to adjust volume from 1 to 5, when reach volume 5, double click again to volume 1 in a circulation.
8		Volume 3	Du	/	2.Volume control left and right seperatly, once you control the right side, just operate the right earbud, will not affect the left side.
9		Volume 4	Du	/	just operate the right earbud, will not affect the left side.
10		Volume 5	Dudidi	/	
11	Call Mode	Answering the phone 1 🌓	/	/	When a call is coming, double click the touch panel no matter right or left to answer the phone.
12		Answering the phone 2	/	/	Answer the call on your cell phone while a call is coming.
13		Reject a call	/	/	when a call in coming, long press the heaing aid touch panel 2 seconds no matter right or left to reject the call.
14		Adjusting call Volume	/	/	Control the volume by adjusting the "volume +" or "volume -" button on your device.
15	Music Mode	Play or pause music	/		Play or pause music by using the "Play" or "Pause" symbol of the player software on the mobile phone.
16		Adjust the volume of the music	/	/	Control the volume by adjusting the "volume +" or "volume -" button on your device.
17	Charging case	Charging case low battery	/	The orange light blinks quickly for 10 seconds	when open the charging case, the case led indicator showed in orange, now the charging case is in low battery, please charge the case now.
18		Recharge the charging case	/	when the case is fully charged, uncover the case top then the LED indicator on the case will flashing three time in five seconds	Insert Type-C cable to charge the charging box

Remarks: 1. Enter the call mode when the music is playing. When the call is over, the music is played automatically. 2. The earphone enters the call mode in the sound amplifier mode. After the call, the earphone automatically returns to the sound amplifier mode.

#### **TECHNICAL SPECIFICATIONS**

Model	HAT607
Output.OSPL90 Max.	≤105dB±3dB
OSPL90 HFA Avg	≤101dB±3dB
FOG50 MAX Gain	≤30±3dB
EQ Input Noise	≤22dB+3dB
Frequency Range (Not narrower than)	220Hz-5500Hz
Working current	≤12mA
Total Harmonic Distortion	≤3%
Bluetooth version	5.0
Operating Voltage	DC 3.7V
play time	4H
The number of times the charging box can be charged	>2 times
Headphone charging time	about 2 hours
Charging time of charging box	about 2 hours
Input voltage	5V/500mA

Notice: The above parameter index testing is on basis of FONIX8000Hearing Aid Test System: Inspection standard: IEC 60118-7 2005, 2CC coupling cavity SB-1

#### **SOUND AMPLIFIER CARE**

- Use a cleaning brush or soft cloth to clean debris from around the user control and microphone; inspect the the receiver, earbud, or ear tip and wax guard regularly.

- Never use water, solvents, cleaning fluids, or oil to clean your sound amplifier.

- Charging contacts should always be kept clean and dry.

Your hearing professional can provide further information on additional maintenance procedures for your sound amplifier, if needed.

#### **MAINTENANCE AND CLEAN**

#### 1. Daily maintenance

It is important to keep your instrument clean and dry. Daily, cleanthe hearing instruments using a soft cloth or tissue. To avoid damage due to humidity or excessive perspiration, please use a drying kit.

#### 2.Care and maintenance

Please put it in where children could not reach, dry and no exposed in the sun. Do not place sound amplifier near high-temperature heating areas such as stoves.

Do not leave the sound amplifier in a humid place for a long time. Do not scratch the microphone with sharp objects to avoid damage to the microphone.

#### Do not disassemble or attempt any repairs by yourself.

3.Cleaning 1) Cleaning the eartips

Remove ear wax plugged in the earpiece by using a stick and brush. 2) Cleaning hook

Using a soft cloth or tissue, wipe off any moisture, sweat, or debris from the surface of the device. Note: Do not use alcohol or other cleaning solvents to clean the hook as this could damage the protective covering.

#### **SERVICE AND REPAIR**

1. If for any reason, your sound amplifier and charger do not operate properly, do not attempt to fix it yourself. Not only are you likely to violate any applicable warranties or insurance, you may also cause further damage. 2. If your sound amplifier and charger fail or perform poorly, check the guide on the next page for possible solutions. If problems continue, contact your hearing professional for advice and assistance. Most of the problems can find in your hearing professional's office or clinic.


TROUBLESHOO	TING GUIDE		
Symptom	Possible Causes	Solutions	
	Blocked tubing/earbud	Clean or replace ear wax guard as needed.	
Not Loud Enough	Hearing change	Contact your hearing professional.	
	Too much dust	Clean both microphone and receiver with brush.	
Inconsistent Performance	Restart required	Put the sound amplifier into charging case, close the top cover to turn off. Then take out the sound amplifier.	
	Blocked tubing/ earbud	Clean or replace ear wax guard as needed.	
Unclear, Distorted	Restart required	Put the sound amplifier into charging case, close the top cover to turn off. Then take out the sound amplifier.	
Performance	Blocked tubing/ earbud	Clean or replace ear wax guard as needed.	
	Defective sound amplifier	Contact your hearing professional.	
	Charge required	Put the sound amplifier into charging case, close the top cover, and wait for charging.	
Dead sound amplifier	Blocked earbud/tubing	Clean or replace ear wax guard as needed.	
ampillel	Ear canal fulfilled with oil wax	Contact your hearing professional.	
No LED indicator when sound amplifier are inserted into the charging port	Low battery	Connect the Type-c cable to your charging case and plug it into the wall. The on-board battery LEDs will flash for a few seconds to indicate the connection to the power source.	
Orange blinking LED by charging port	Low battery	Insert your type-c cord to charge the case	
sound amplifier whistling in the charging case	Dead battery	Put the sound amplifier into charging case, close the top cove and insert your type-c cord to charge the case.	
If the sound amplifier	Sound Amplifier earplug	Gently turn the sound amplifier, so that the sound amplifier eartips and ear canal sealing and fitting better, so that you can deal with the whistle phenomenon.	
whistles in the ear	and ear canal sealing or fit is not good	2. The size of the eartips on the Sound Amplifier does not match your ear canal. Use earplug of a different size to improve the whistle phenomenon.	
Council A regulifican	Low battery	Put the sound amplifier into the charging case to charging	
Sound Amplifier has no sound	Blocked up the Eartips' sound port or microphone port	Clean the sound port or microphone port	
	Low battery	Put the sound amplifier into the charging case to charging	
The voice is very weak and unclear	The volume is too low	Click to adjust the volume level	
	Eartips loose	Re-wearing the sound amplifier	

#### Factory Reset Mode

1. Put the left sound amplifier and the right sound amplifier into the charging case bin, open the top cover of the charging case, long press the button at the bottom of the charging case for 5 seconds, and the Yellow indicator light on the charging case starts to blink quickly that enter TWS pairing mode or reset mode

2. The Yellow indicator light on the charging case flashes quickly about 15 seconds and off; 3. You can connect your smart phone by "Pairing First Use" page;





Press and hold for 5 seconds

# **HELPFUL HINTS**

- Do not take apart your sound amplifier or insert the cleaning tools inside them. (When not in use, place your sound amplifier in the charger and store them.)

- Away from direct sunlight or heat to avoid extreme temperatures. - Where you can easily find them. - Safely out of reach from children and pets. Synergy Charger Care
- Keep your charger clean. Heat, moisture, and foreign materials can result in poor performance. - Do not use water, solvents, or cleaning fluids to clean the charging ports. - Keep lid closed as much as possible to avoid dust and debris build-up.
- Store your charger in a clean and dry location. - Fully charge sound amplifier batteries every night.

# INTENDED USE

- In a dry, safe place.

1. Medical purpose - The sound amplifier intends to compensate for impaired hearing. 2. Intended patients and environment

- The sound amplifier uses for indoor and outdoor environment, and patients under 18 years old must 3.Side effects

- For patients with sensitive skin, the silicone material may irritate your ear canals. - First use may cause slight pain to the ear canal due to maladjustment.

# **IMPORTANT SAFETY INSTRUCTIONS**

**1.CONTRAINDICATION** The device is unsuitable in the following situations:

- Usage is prohibited for patients with chronic suppurative otitis media and congenital ear atresia. - This sound amplifier can only compensate patients with hearing impairment and do not have hearing

1) Congenital atresia of external ear or deformity of external auditory meatus, a large number of foreign bodies in external acoustic meatus; 2) Deafness is unstable, and the degree of hearing loss often fluctuates;

3) Complaint with headache, dizziness, earache, tinnitus, and other symptoms that are not suitable for adaptation; 4) Sudden deafness in the past three months; progressive rapid deafness; apparent unilateral deafness or

other acute ear diseases;

5) Effusion in the middle ear and frequent purulence; 6) Central deafness; non-organic deafness;

7) Patients with acute otitis externa and tympanitis; 8) Patients with acute and chronic suppurative otitis media (in the period of purulent infection);

9) Patients who are allergic to the material of this product.

# **1** 2.WARNINGS

- Keep small swallow-able accessories out of children's reach. - Dropping, immersing in liquid, and accessing strong electromagnetic fields or over heat will damage sound amplifier. If a sound amplifier or accessories remain in the ear, please go to see a doctor as soon as possible, do not take it out by yourself.

- Warning not to use in explosive or oxygen-enriched atmospheres; it may damage the device. - Warning that only the intended person can use it; using a sound amplifier designed for someone else may result in hearing damage.

- Statement about the special needs of particular patient groups. - Warning about common conditions that could damage the device.

- Warning that results from the risk management file permissible environmental conditions of transport and - Each warning/safety contains: nature of Hazard; likely consequences; precautions

# **⚠** 3.NOTICE

the sauna room).

- Please Do not use it at high volume for a long time. Otherwise, it will injure your ear. If you feel uncomfortable, please stop using it. - Please check the product every time before using it, and avoid wearing the earplug with foreign objects in ear canal. It will affect the sound amplifier. - Avoid shocking and dropping the product. Do not keep or use it in high humidity environments (such as

- Do not throw the scrapped battery as standard rubbish.

- Do not use the product in a potential explosive or dangerous environment. - Do not share your sound amplifier with others. Your sound amplifier setting is personal and individual, share with someone else will result in others' hearing damage.

- Be careful with any unusual skin reactions. In some instances, wearing a sound amplifier can cause an allergic reaction leading to it chiness or rashes. If you notice any uncommon skin condition, stop wearing the sound amplifier, and check with a medical specialist. - Do not place the sound amplifier near the magnetic objects.

- Be sure to take off the sound amplifier when getting a diagnosis or treatment. - Never pry the inside of the sound amplifier with a needle or similar object; otherwise, it will damage the

- Do not put the sound amplifier near heating appliances or in direct sunlight, and you should also avoid high moisture areas such as bathrooms or near a humidifier. - In a closed car in summer, the temperature can rise to very high levels. Do not leave your sound amplifier in a high-temperature car.

- Do not use the sound amplifier close to a cell phone, otherwise it may increase the noise and affect the sound quality.

- Please contact the MANUFACTURER: Any questions in setting up, using, or maintaining the sound amplifier; • To report unexpected operations or events.

# MATTERS NEEDING ATTENTION, WARNINGS, AND TIPS

1. Do not immerse the sound amplifier in any liquid. Remove the sound amplifier before swimming and shampooing. After swimming or washing, wait for the ear canal to dry before wearing the sound amplifier. 2. Please use the function and volume control switch correctly, open and close as lightly as possible to avoid excessive force. 3. Applicable objects: Suitable for people with air-conducting hearing loss of about 30-50dB.

4. Please use sound amplifier with sound amplifier charging cases. recommended charging time interval of sound amplifier is ≤28 days;

5. When you do not use sound amplifier, please charge the product regularly to avoid battery damage; the

# **MAINTENANCE, STORAGE AND DISPOSAL**

1. Maintenance 1) We do not authorize any institution or individual to maintain and repair the product. If you suspect that the products have any issues, please contact the manufacturer or distributor to handle them. 2) The user must not attempt any repairs to the device or any of its accessories. Please contact the

3) Opening of the equipment by unauthorized agencies is not allowed and will terminate any warranty claim. warning: No modification of this equipment is permitted!

1) If you Do not use it, and then put the sound amplifier into the charging case.

which maybe get in touch with fire or is vulnerable to vibration 3) Keep the device storage in following environmental ranges:-20~55 ℃, ≤95%RH, 700-1060hPa

2) Do not put the device under the sunshine, high temperature, and moist environment or someplace,

Please dispose of the device under the directive 2002/96/EC – WEEE (Waste Electrical and Electronic Equipment).and Don't dispose with domestic waste. If you have any queries, please refer to the local authorities responsible for waste dis-postal.

# **IMPORTANT NOTICE FOR PROSPECTIVE SOUND AMPLIFIER USERS**

Good health practice requires that a person with a hearing loss have a medical evaluation by a licensed physician (preferably a physician who specializes in diseases of the ear) before purchasing a sound amplifier. Licensed physicians who specialize in diseases of the ear are often referred to as otolaryngologists, otologists or otorhinolaryngologists. The purpose of the medical evaluation is to assure that all medically treatable conditions that may affect hearing are identified and treated before the sound amplifier is purchased.

Warning to sound amplifier dispensers

A sound amplifier dispenser should advise a prospective sound amplifier user to consult promptly with a licensed physician (preferably an ear specialist) before dispensing a sound amplifier if the sound amplifier dispenser determines through inquiry, actual observation, or review of any other available information concerning the prospective user, that the prospective user has any of the following conditions:

(i) Visible congenital or traumatic deformity of the ear. (ii) History of active drainage from the ear within the previous 90 days.

(iii) History of sudden or rapidly progressive hearing loss within the previous 90 days. (iv) Acute or chronic dizziness.

(v) Unilateral hearing loss of sudden or recent onset within the previous 90 days. (vi) Audiometric air-bone gap equal to or greater than 15 decibels at 500 hertz (Hz), 1,000 Hz, and 2,000

(vii) Visible evidence of significant cerumen accumulation or a foreign body in the ear canal (viii) Pain or discomfort in the ear. Special care should be exercised in selecting and fitting a sound amplifier whose maximum sound pres-

sure level exceeds 132 decibels because there may be risk of impairing the remaining hearing of the sound amplifier user. (This provision is required only for those sound amplifier with a maximum sound pressure capability greater than 132 decibels (dB).)

#### FCC WARNING RF exposure statement

This equipment complies with the FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

# **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received,

including interference that may cause undesired operation. NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# **WARM TIPS:**

Due to the different actual situations, each customer's experience of using product is different. If you have any questions in the using process, please contact our professional customer service staff by our aftersales email (aftersalesmailbox@163.com) or by the platform where you purchased this product as soon as possible. Please believe that our customer service staff will offer you satisfactory assistance.

# NORMALIZED SYMBOLS

 $\bigcap_{\mathbf{i}}$ Consult instructions for use B type applied part FCC ID: 2AGA6-HAT607 Please dispose of the device under the directive 2002/96/EC – WEEE (Waste Electrical and Electronic Equipment). and Don't dispose with domestic waste. Manufacturer Date of manufacture SN Serial number Warning/ Danger: Improper use might cause serious injuries. IP code of the device: this device's grade of against ingress of solid foreign objects – the IP41 access probe of 2.5 mm Ø shall not penetrate; the grade of waterproof is vertically falling

MANUFACTURE: JIANGXI YIANG MEDICAL TECHNOLOGY CO., LTD Address: Floor 3, Building 3, Ganzhou National High-level Talents Science And Technology Innovation Park, No.1 Wudang M Ganzhou, Jiangxi, 341000, CHINA

drops shall have no harmful effects.