



Read these manual to avoid any damage.

#### **IMPORTANT**

The instructions of these manual are for reference about the product.

There may be differences due to update.


Please check our web site (www.steren.com) to obtain the latest version of the instruction manual.

"The operation of this device is subject to the following two conditions: (1) it is possible that this device may not cause harmful interference and (2) this device must accept any interference, including that may cause undesired operation."

### **IMPORTANT**

Please read the instructions and warnings before using your new selfie stick with bluetooth.

- Do not use the selfie stick in case of rain or thunderstorm
- Be sure to pay attention to your surroundings while using the device; It could be risky if there are high voltage cables



### **CAUTIONS**


Take spectacular pictures with this selfie stick with Bluetooth. Bring it on everywhere, this selfie stick has been designed to be fold in one single piece and store it easily.

The holder can be adjusted to fit almost all kind of smartphones and the handle is covered with an anti-slippery material, for a perfect grip. It has 6 sections to reach a distance up to 70cm, nobody will be out of the picture anymore.


The selfie stick is compatible with iOs and Android, and it is very easy to use it: just pair your mobile via Bluetooth, open the camera app and press the shutter to take the perfect picture.

- Internal battery (can be recharged via Micro USB)
- · Up to 20 hours of battery use
- Durable
- Light weight (148g)
- Six sections
- Maximum length: 70cm
- · Maximum holder aperture: 7.5cm

### **HIGHLIGHTS**



## **PARTS**



Before using the selfie stick for the first time, charge the battery for 4 continuous hours.

Insert the USB cable into the micro USB port and connect it to a PC or an outlet adapter (not included). The LED indicator lights; it turns off when charging is complete.



**BATTERY CHARGE** 

#### **Pairing**


- 1. Activate Bluetooth in your smartphone. Make sure it is in visible mode.
- 2. To turn on and put in search mode the selfie stick, press the button for a few seconds until it turns on and off continuously, immediately release.
- 3. On your smartphone, search for Steren device and select it. In case that request a password, enter 0000.

  When the connection is established, the button will remain lit.
- 4. The selfie stick will automatically connect to the last device that has been paired; if not, search it in the list of Bluetooth devices and connect manually.


Note: To link a new device, it is necessary unpair the previous device.




### **PAIRING**



## **HOW TO USE**



# HOW TO USE







**6.** Turn it off when is not in use, pressing the button for a few seconds.

## **HOW TO USE**



Input: 5 V --- (x USB)

Operating frequency: 2.4 GHz

Internal battery: 3.7 V --- 60 mAh

# **SPECIFICATIONS**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.