

# Turn up procedure

## 1 User mode

Rotate the knob clockwise to turn the radio on, rotate counter-clockwise to turn the radio off.

Press PTT key to transmit, speak to the microphone with normal voice. Release PTT key when receiving.

## 2 Manual Turning mode

Press the A/B button to switch A/B band display and working band.

Press the UP/DOWN button to select the desired Channel(0-22 channels selectable).

In channel mode, press ▲ or ▼ key to select the desired channel.

MENU key: This is start key to enter the menu items. EXIT key: This is Return/Clear key, press this key to exit the menu setting when in menu setting state.

Press MENU key to enter the menu setting mode. Then High/Low output power levels can be changed. Also you can change the frequency step of the equipment.

Frequency range	UHF:462-467MHz TX/RX
Power output	High:5W Low:1W
Modulation	FM(F3E)
Maximum frequency deviation	≤5KHz
Frequency stability	2.5ppm
Receiving sensitivity	<0.25uV