interesting information at helpful tips? You can find those and much more Need detailed instructions, up-to-date information, and please read it carefully and save it for future reference. brovided to help you get started quickly with your tablet; Your NeuTab tablet is here in your hand. This guide is

THANK YOU FROM NEUTAB

Congratulations!

Predominant Quality Persistent Perfection



life span. If the device is not used for an extended period of time, the battery will slowly discharge and the device will need to be recharged before using again. Unplug the drarger from the wall when it is not being used. week. Doing so runs the risk of overcharging the battery and shortening its total circulated environment. Do not leave your battery charging for more than one circulated environment. Make sure to charge the battery in non-closed well air (1) Operate battery in right way: Do not dharge the device in a dosed or non-air

explode or ignite and cause injury and/or damage. these instructions could cause the Lithium Ion battery to leak acid, become hot, thoroughly with water and seek medical attention immediately. Failure to follow (140°F). If the battery leaks and you come into contact with the leaks fluids, mise confainer or in a microwave oven. Do not expose it to temperatures over 60°C in direct strong sunlight, in a high temperature location, in a pressurized environment. Don not put, store or leave your product in or near sources of heat, Thirding in the pattery caution: This product is equipped with a Lithium-lon battery. Do not pierce, open, disassemble it, or use it in a humid and/or corrosive

radiators, heat registers, stoves, or other products (including amplifiers) that (6) Heat: The product should be situated away from heat sources such as

the service technician to perform safety checks to ensure that the product is in 📵 Safety Check: Upon completion of any service or repairs to this product, ask

may result in fire, electric shock, or other hazards. have the same characteristics as the original part. Unauthorized substitutions service technician has used replacement parts specified by the manufacturer or Peplacement Parts: When replacement parts are required, be sure that your

f) when the product exhibits a distinct change in performance—this indicates a

e) it the product has been dropped or damaged in any way;

improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal Adjust only those controls that are covered by the operating instructions as d) if the product does not operate normally by following the operating instructions. c) if the product has been exposed to rain or water; b) if liquid has been spilled or if objects have fallen into the product; a) when the power-supply or plug is damaged;

servicing to qualified service personnel under the following conditions: (8) Damage Requiring Service: Unplug this product from the wall outlet and refer servicing to qualified service personnel.

Servicing: Do not attempt to service this product yourself as opening or that could result in a fire or electric shock. Never spill liquid of any kind on the through openings as they may touch dangerous voltage points or shout-out parts

removing covers may expose you to dangerous voltage or other hazards. Refer all

(1) Object and Liquid Entry: Never push objects of any kind into this product convenience receptacles as this can result in a risk of fire or electric shock. Overloading: Do not overload wall outlets, extension cords, or integral

to your home, consult your product dealer or local power company. For products intended to operate from battery power or other sources, refer to the operating source indicated on the rating label. If you are not sure of the type of power supply 9 Power Sources: This product should be operated only from the type of power

charge and use is in non-closed well air dirculated environment. environment. Even if the device does not have ventilation slots make sure to been solhered to. Do not charge the device in a dosed or non-air circulated rack unless proper ventilation is provided or the manufacturer instructions have This product should not be placed in a built-in installation such as a bookcase or

openings should never be blocked by placing the product on a bed, sofa, rug, or ensure reliable operation of the product and to protect it from overheating. These 8 Ventilation: Slots and openings in the cabinet are provided for ventilation to

washbowl, kitchen sink, laundry tub, in wet basements, or near a swimming pool Water and Moisture: Do not use this product near water (e.g., near a bath tub,

other attachments may be hazardous. S Attachments: Use only attachments recommended by the manufacturer. Use of

liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning. S Cleaning: Unplug this product from the wall outlet before cleaning. Do not use ● Follow Instructions: All operating and usage instructions should be followed.

### **ADDITIONAL INSTRUCTIONS**

that may cause undesired operation. This device must accept any interference received, including interference This device may not cause harmful interference. This device complies with Part 15 of the FCC Rules. Operation is subject to

#### FCC DECLARATION

updates. If these resources do not resolve the problem, please contact www.neutab.com for Frequently Asked Questions (PAQ) and product If you have a problem with this device, please check our website at

## **SUPPORT**

Unauthorized reproduction or distribution of the tablet design, or any portion of this package will be TRADEMARK permission from Grand Electronics INC. intormation storage and retrieval system without writter in any form or by any means, electronic of mechanical,

and design, is allowed to be reproduced or transmitted

No portion of this package, including shape, graphics

**NOTICES QNA** LEGAL

# **FEATURES**

#### **WEB BROWSING** Visit your favorite websites

## **E-MAILING**

Set-up your email VIDEO WATCHING

### YouTube application pre-installed

Download thousands of books with the included

#### Google reader, Google books

**GOOGLE PLAY STORE** Games, applications, and more with the installed marketplace

### WIRELESS INTERNET

High-speed Wi-Fi 802.11 b/g/n networking

## **ENTERTAINMENT ALL THE WAY**

Portable powerhouse plays popular music, video, and photo formats **EXPAND YOUR TABLET CAPACITY** 

#### Micro-SD card slot supports up to 32GB card.

**BUILT-IN CAMERA** 

Designed for video chatting

02

## PACKAGE CONTENTS

This package includes your tablet and basic accessories. Please contact us at contactus@neutab.us if you find one or more items missing. NeuTab Tablet USB cable

Tips: This manual is available for download from the NeuTab website as a Warning: This package may contain plastic bags or other materials that pose a

hazard to children. Be sure to safely dispose of all packing materials after opening.

#### **GETTING TO KNOW YOUR TABLET**

(The location of different buttons and other components are subject to change, please refer to the icon or text for identification)

	¥	Speaker	$\leftarrow$	Micro USB port
C	ି	Camera	<b>\psi</b>	Power jack
(	Ŋ	Power button Reset/Restart key	$\cap$	Headphone jack
<b>1</b> [+	- 14-	Volume +/-	TF}	Micro TF card s
	ELINECTE EXP	HDMI Output ( OPTIONAL )		
Tips: Please refer to the icon on tablet to find those buttons/ports)				

03

## PACKAGE CONTENTS

Your tablet comes equipped with an easy-to-use touchscreen. Our capacitive multi-touchscreen requires gentle fingertip touch on the glass screen to activate

Multiple fingers may be used to perform gestures (e.g. 2-finger picture zoom). Please note: Your fingertips must not be covered. A stylus may be used. Make sure it is designed for capacitive touchscreens.

Tips: To avoid damaging the screen, do not touch it with excessive force or with any object other than your finger. For best response, make sure your hands are clean before using the touchscreen controls.

#### PROTECTIVE FILM

A thin film has been applied to the touchscreen to protect it during shipping. The ore use. To remove it, simply take a corner of the film and peel it away from the screen.

04

#### PACKAGE CONTENTS

Your NeuTab tablet comes with a built-in rechargeable lithium polymer battery. Before 1<sup>st</sup> time using the tablet, the battery should be charged fully to extend future battery life.

1. Plug one end of the included power adapter into an AC 100-240V outlet. 2. Plug the other end of the included power adapter into the Power jack on the

3. Disconnect the power adapter when the tablet is fully charged.

Warning: The battery used in this device may present a fire or chemical burn if mistreated. Do not disassemble, incinerate, or heat the device. Do not leave the device in a place subject to direct sunlight, or in a car with its windows closed. Do not connect the device to a power source other than that which is indicated here or on the label as this may result in the risk of fire or electric shock.

## **Resetting/Restarting the Tablet**

Reset the tablet if it should freeze and not respond or otherwise malfunction.

1. Disconnect your tablet if it is connected to a computer.

2. Press and hold the POWER key for about 10 seconds to turn off the tablet, and then press and hold the POWER key until you see NeuTab logo.

05

# **GETTING STARTED**

# TURNING THE TABLET ON AND OFF

-Press and hold the Power key until the LCD screen turns on and you see NeuTab Logo, then wait until you see the Unlock screen.

1.Press and hold the Power key until the "turn tablet off" message appears. 2.Touch OK to turn off the tablet.

CONNECTING TO THE INTERNET

This tablet can utilize Wi-Fi data networks to connect to the Internet.

In general, being closer to Wi-Fi router improve performance.

In order to connect to the Internet, you will need either of the following:

A wireless router or access point with a broadband Internet connection The tablet can receive 802.11 b/g/n Wi-Fi radio. The tablet will also work with

You will need to know the name of your network (SSID), as well as the

usually be found on the administration webpage of your wireless router.

password or other credentials if your network is secured. These settings can

Tips: You may encounter open Wi-Fi networks, or "hotspots". These networks are

usually configured so that you can simply connect to them without needing to

know its settings; the tablet will obtain all the information it needs from the router

**REQUIREMENTS** 

automatically.

wireless routers that only support 802.11 b/g.

CONNECT TO A Wi-Fi NETWORK

Wireless Wi-Fi technology can provide Internet access at distances of over

however, this distance can be affected by your surrounding environment and

# TURNING THE SCREEN ON AND OFF (CONTD)

When the tablet is on, you can turn off the screen to conserve battery power. Simply press the Power button once to turn the screen off. Press the Power button again to turn the screen back on.

Tips: To conserve battery power, the screen can be set to turn off automatically when the tablet is not in use (between 15 seconds and 30 minutes). This Sleep option can be found in the Display menu.

# UNLOCKING THE SCREEN

When the screen turns off, you will have to unlock the screen when you turn it

To unlock the screen, touch and drag the lock icon to the edge of the circle that appears (or swipe up to unlock). If a password has been set, enter the password to finish unlocking the screen. The Screen Unlock password can be set in the Security settings menu.

Warning: Please write down your password lock pattern/PIN/Password. Misplacing or forgetting this method will lock the user out. Updating device firmware will reset the device to factory default and remove password, but all your data & programs will be lost. NeuTab takes no responsibility of retrieving nformation and data on locked devices.



The home screen is the starting point for all of the features of your tablet.

1 Google Search Touch to search with Google Search Engine. 2 VOICE Search Search by voice input.

Touch to back to the central Home Screen. 4 Back icon

display more detail.

Touch to go back to the previous screen. 5 Recent Apps

Open the Application Launcher to view the list of all Applications and Widgets installed on the tablet. Touch the applications tab to open the Launcher.



# 1. Turn on the Wi-Fi radio if it is not already on. To turn on Wi-Fi:

a. Go to the Home screen: Touch the Home icon. b. Open the Launcher screen:

Touch the Launcher Tab, then touch Settings. c. Open the Wireless & networks menu: Touch WIRELESS & NETWORKS.

d. Open the Wi-Fi settings menu:

e. Make sure that the Wi-Fi option box is setted to ON: Touch and slide the block right to enable the Wi-Fi connection When Wi-Fi is on, the tablet will look for and display a list of available Wi-

#### Warning: Open Wi-Fi networks operates under the risk of information surveillance, your account information, especially password and other credentials might be 2. Select an available Wi-Fi network to connect to: audited by third parties. Please use caution when connected to open hotspots. In the same Wi-Fi settings menu above, touch a network in the list.

If the network is open, the tablet will prompt you to confirm connection to the network. Touch Connect to confirm. If the network is secured (as indicated by a Lock icon), the tablet will prompt you to enter a password or other credentials. Touch the Wireless password box to show the on-screen keyboard and then use it to enter the password. Touch Connect to confirm.

When you have successfully connected to a Wi-Fi network, the Notifications bar at the bottom of the screen will show a Wi-Fi signal

11

# YOUR TABLET HOME SCREEN

3 Home icon

Touch to display the list of thumbnails of apps you have worked recently. Touch a thumbnail to open it.

Touch an icon to open an application or application folder. 8 Notification bar Shows notification icons and time, battery level, plus the network signal strength; touch the bar to open the full Notifications panel. Touch a Notification icon to

# **DOWNLOAD APPLICATIONS**

This tablet is Google certified and has Google Play Store pre-installed. When connected to WiFi network, you can browse apps in Play Store and download/install them.

# THE PLAY STORE

Google Play Store can be found in the applications menu, you can always taphold-drag it to the main screen to make it easier to access.



12

# **DEFAULT APPLICATIONS**

To open an application, touch the application icon on the home screen or in the

(The screenshot shown above is for demonstration purposes only. NeuTab reserves the right to modify and improve the final default applications available on different tablet models.)

Chrome: Default internet browser. Calculator: Default science calculator. Calendar: Setup reminders on dates.

Camera: Access front and back camera to take pictures. Clock: World clock, timer, and alarm setup. Downloads: Manage downloaded materials from internet.


Gmail: Setup your gmail account to access email. Photos: Browse saved pictures. Google: Browse Google account features.

Maps: Browse Google maps. Play Music: Play music stored in your tablet. File Manager: Manage files and folders on your tablet.

Play Store: Download/purchase applications, music, movie and more from Google market. Settings: Manage your tablet settings.

Sound Recorder: Record microphone input. Play Movies: Play movies in different formats stored in your tablet.

Play store requires a Google Account (a Gmail Account is good enough) to lunch and to help you stay updated with the applications you installed. If you do not have a Google Account, just tap "Create New" and let this tablet help you with a new account.



When logged-in, you can browse apps under different categories and featured/popular apps. Tap on the app icon and you have to choice to install/purchase this app. You can also search for an exact app or search an app by keyword by tapping the magnifying glass



13

10

The Notification bar displays icons that indicate your tablet's Wi-Fi status.

Connected to a Wi-Fi network (waves indicate connection strength).

[no icon] There are no Wi-Fi networks in range, or the Wi-Fi radio is off.

#### **FCC Statement**

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

#### **SAR Information Statement**

Your Tablet PC is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. \* Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use on the body, as described in this user guide, is **0.728W/Kg**(Body-worn measurements differ

among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RFexposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/ oet/fccid after searching on FCC ID: 2AGNKK1S1 Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Asso-ciation (CTIA) web-site at http://www.wow-com.com. \* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a sub-stantial margin of safety to give additional protection for the public and to account for any variations in measurements.

#### **Body-worn Operation**

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance

of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.