

# \*\*\*\* Remote Control - CUSTOMER SETUP GUIDE

Before you begin, check your package contents to make sure you have all of the following:

- \*\*\*\* Remote Control (RC)
- \*\*\*\* Set-Top Box (STB)
- \*\*\*\* STB Power Adapter & HDMI Cable

**FIRST:**

Setup the \*\*\*\* STB using the instructions provided in the STB Customer Setup Guide

**NEXT:**

Follow the steps below to set up your \*\*\*\* Remote Control (RC)

**STEP 1:** Check that your \*\*\*\* STB is connected to your TV and is plugged in to a power outlet. Make sure your TV is ON

**STEP 2:** Pull and Remove the plastic tab on the back of the \*\*\*\* RC to activate the batteries.

*4 AAA batteries come already installed in the Remote Control.*

**STEP 3:**

- Follow the on-screen instructions to set up the \*\*\*\* RC for your TV's Mfg. and Model. Your \*\*\*\*<sup>®</sup> \*\*\*\* Remote Control comes already paired with and ready to control the \*\*\*\*<sup>®</sup> \*\*\*\* STB that it was shipped with.

\*\*\*\* LOGO

# Troubleshooting:

## PROBLEM:

*You point the \*\*\*\*\* Remote Control at the TV, press the “Power Button”, and nothing happens.*

## SOLUTION:

1. Check that the TV is connected to the \*\*\*\*\* STB and that the TV has the correct input selected.

*You may need to use the TV’s remote control to change the TV’s Input to the correct source.*

2. Check that the \*\*\*\*\* STB is plugged into a power adaptor and that the power indicator light is on.
3. Check that you have completely removed the plastic tab on the back of the \*\*\*\*\* Remote Control.
4. Check that when you press a button on the \*\*\*\*\* Remote Control, the indicator light on the bottom front of the Remote control lights up.

*You may need to replace the AAA batteries in the Remote Control.*

5. Check that the \*\*\*\*\* Remote Control is in the same room as the \*\*\*\*\* STB that it came packaged with.

*You may need to move the \*\*\*\*\* Remote Control back into the room with the \*\*\*\*\* STB that it was packaged with.*

***If you have checked the items above, and the problem is still not fixed,  
please contact \*\*\*\*\* Customer Support for assistance.***

**\*\*\*\*\* LOGO**

# FCC Information:

**FCC ID: 2AGOFRC360 MODEL: IPRC1000, \*\*\*\*\* Remote Control**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

The FCC ID: 2AGOFRC360 on your \*\*\*\*\* Remote Control is located inside the battery compartment. The battery cover must be removed to view the FCC ID.

## **FEDERAL COMMUNICATIONS COMMISSION (FCC) STATEMENT INFORMATION TO THE USER:**

**CAUTION:** Changes or modifications to the equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, increase the separation between the equipment and receiver. If applicable, connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio / TV technician for help.

**\*\*\*\*\* LOGO**

# Additional Statements:

## **Electrical Safety Statement:**

Use 4 AAA Batteries 1.5VDC

Rechargeable batteries not recommended.

© 2015 \*\*\*\*\* All rights reserved

**\*\*\*\*\* LOGO**