

FCC compliance statement
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generally does not cause harmful interference, and if it does, it can be corrected by one of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

FCC SAR statement
 This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for applying SAR exposure compliance. This equipment must not be operated in conjunction with any other antenna or transmitter. The purpose of this statement is to inform the user of the requirements for radio waves established by the Federal Communications Commission (FCC). These requirements set a limit for the amount of radio frequency energy that can be absorbed by the human body. The equipment should be used with minimum distance, 10cm between the antenna and the body.

Telephone:
 +86-10-84493638

Email:
 sales@mail.dspread.com

Address:
 Rm 407 B10C #10 (Universal Business Park),
 Huangguo Road, Chaoyang District, Beijing,
 China. Zip code 100015



1 →

← 14

Device layout

Package contents
 Be sure all items listed here were included with your device.

Procuration

⚠ Damaging the antenna would cause device lose function. Please do not tear the antenna.

13 →

← 2

Code scanning

Your device supports to scan bar code and QR code.

- Launch the app
- Put the QR code / bar code into the box. Your device will read the information automatically.

Device Layout

Hard keys

Key	Function
Power key	Short press: • When the device is on, press to light the screen, or to lock the screen.
	Long press: • Press and hold 2-3s to turn it on, or to switch it off.
	• Press and hold 10s to restart the device.
Volume Key	Press to adjust the volume.

3 →

← 12

Soft buttons

Key	Function
Home	Return to the main interface.
Back	Go back to the previous menu.
Recent	View recent opened apps.

Others

☑ The lanyard needs to purchase separately. You can wear the lanyard by a needle.

IC card reader

☑ Card chip area facing up, insert the IC card. When you insert the card, please ensure the chip area is toward.

You can distinguish the front and the back by the chip area. Please do not pull out the card until the transaction is done.

NFC

☑ Use the NFC to proceed the transaction from NFC tag. Place the card on the back of your device and over the NFC tag.

11 →

← 4

Payment functions

Your device allows you to read magnetic card, IC card and near field communication (NFC).

Magnetic card reader

☑ Swipe the card from left to right with the magnetic strip facing the device back (swipe direction refers to the arrow of 'C').

Please pay attention to the front and back of the magnetic stripe card and the upper and lower sides of the card when swiping.

Battery

Charging the battery

Charging with following steps:

- Connect the USB cable to the power adapter.
- Plug the USB cable into the device's connector.
- Plug the USB power adaptor into an electric socket.
- After fully charged, disconnect the charger from the device. Then, unplug the charger from the electric socket.

Charge the battery before using it for the first time or when it has been unused for extended period.

Install battery

When you get a new device, please install the battery to device with following instructions.

Install with following steps:

- Open the battery cover.

5 →

← 10

Remove battery

To remove battery, please flip up the battery from the buckle.

☑ Please make sure your device is powered off before remove the battery.

Using quick setting buttons

You can swipe downwards on the screen to do quick settings.

• To change the settings, tap each button icon above the icon description.

Drag the ☺ along the bar to left and right adjust brightness

You can add and reduce the quick functions show on your panel by tapping ➕

If you want to change your device setting, you can tap ⚙

☑ If you tap and hold the icon for a second, it will jump to the corresponding setting page.

9 →

← 6

How to remove SIM card

You will need to use a needle to drag the card switch downward to pull the SIM card out.

To remove SIM card, you will need to remove TF first. Otherwise it will be difficult to operate.

Battery charging tips and precautions

- When the battery power is low, the battery icon appears empty.
- Using a power source other than the charger, such as a computer, may result in a slower charging speed due to a lower electric current.
- The device can be used while it is charging, but it may take longer to fully charge the battery.
- Charging temperature ranges from 1°C to 45°C.

⚠ Read all following instructions and safety information before use to avoid the possible injury.

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type of battery recommended by the manufacturer. Dispose of used batteries according to battery manufacturer's instructions.
- Don't dip the battery in water or seawater, attention damp-proofing.
- Don't approach heat source, such as fire or heater.
- Don't short-circuit the positive (+) and negative (-) terminals of the battery with conductor, and don't store the battery with metal conductor.
- Don't beat or throw battery, don't impale the battery with needle and sharp things.
- Don't disassemble or alter the battery structure, because there is safety device inside the battery for its inherent safety function.
- Don't charge when the battery near the fire source or heating circumstances.

7 →

← 8

SIM, SAM card and TF (Trans Flash)

How to install SIM card

Your device is support dual SIM cards, you can insert two SIM cards so you can have two phone numbers or service providers for a single device.

- Remove the battery. Please make sure your device is powered off before remove the battery.
- Insert Nano-SIM only for SIM 1, make sure SIM 1 card insert in the second layer of the left card slot.
- Insert Mini-SIM only for SIM 2, make sure SIM 2 card insert in the first layer of the right card slot.

☑ Please pay attention to the front and back of the card and the upper and lower sides of the card when you insert.

Please make sure SIM cards are insert in same direction as instruction.

How to install SAM card

- Remove the battery. Please make sure your device is powered off before remove the battery.
- Insert SAM card. Make sure SAM card insert in the second layer.

☑ Please pay attention to the front and back of the card and the upper and lower sides of the card when you insert. Please make sure SAM cards are insert in same direction as instruction.

To remove SAM card, you will need to take the SAM 2 card out first. Otherwise it will be difficult to operate.

How to install TF

- Remove the battery. Please make sure your device is powered off before remove the battery.
- Insert TF, make sure TF insert into the first layer.

☑ Please pay attention to the front and back of the card and the upper and lower sides of the card when you insert. Please make sure TF insert in same direction as instruction.

To remove TF, please push TF inward to trigger the switch, card will eject automatically.