


## Shadow Bluetooth® Speaker

IC :21530-3778B  
 FCC ID: 2AGR4-3778B  
 Shadow BT®3778B



Instruction Manual

### General Functions



1. Power On/Off
2. Mute, Play/Pause
3. Volume -, Previous Track (press once to decrease volume, press and hold for previous track)
4. Volume +, Next Track (press once to increase volume, press and hold for next track)
5. Mode
6. Hands-Free

Front Cover

page 02

### Bluetooth® Operation

1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device.
2. Turn the speaker on by pressing and holding the Power button for several seconds. The indicator light will flash as it detects Bluetooth enabled devices near you. The indicator light will turn off if no Bluetooth device is detected within 10 minutes.
3. "GEMLINE SPKR" will appear on the Bluetooth device list, select "GEMLINE SPKR" to establish pairing. If instructed to enter a PIN code, please enter '0000'.
4. When you want to play audio from another Bluetooth device, disconnect the speaker from the original device and follow steps 1-3 to re-pair the speaker with a new Bluetooth enabled device.

### Speakerphone Operation

1. If you receive a call during Bluetooth mode, press the Hands-Free button to answer the call. Press the button again to end the call.

page 03

2. To reject a call during Bluetooth mode, press and hold the Hands-Free button.
3. To redial the last number called, double click the Hands-Free button.

### AUX Playback Operation

1. Turn on the speaker.
2. Connect the speaker to a smartphone, audio device, or laptop with the 3.5mm AUX cable (included). The speaker will automatically switch to AUX playback mode and play audio from the connected device.
3. The next/previous song button can only be adjusted on the device that is connected through the 3.5mm AUX cable.
4. The volume and play/pause functions can be adjusted using the controls on the speaker while it is connected through the 3.5mm AUX cable.

### Charging the Speaker

1. When the battery is low, please charge via the included USB cable. The charging time is approximately 7-8 hours and

page 04

### Specification

Bluetooth specifications: Bluetooth® version V4.2+EDR  
 Support profile: HSP/HFP/A2DP/AVRCP  
 Transmission distance: up to 10 m (This may vary based on environmental factors or the type of Bluetooth® device being used)  
 Built-in battery: Lithium Battery 2500mAh  
 USB Recharge voltage: 5V  
 Output power: 3W x 2  
 Frequency Response: 100HZ-20KHZ  
 Signal to Noise Ratio (SNR): ≥60dB  
 Sensitivity Rating: 65dB

### Packing

- Bluetooth® Speaker
- USB Charging Cable
- 3.5mm AUX cable
- User Manual
- Gift Box

Back Cover

provides up to 12-13 hours of continuous operation (operation time may vary based on volume level).  
 2. The LED indicator light will be red during charging and will turn off once it is fully charged.

### Warning

1. Do not disassemble, repair, or modify the speaker.
2. Do not place product in or near fire to avoid danger, as it uses a lithium battery.
3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the speaker.
4. Keep the speaker dry and do not store the speaker in damp areas to avoid damage to the speaker.
5. Avoid dropping the speaker as it may damage the speaker.

### Kind Reminder

1. To prolong the speaker's life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time.

page 05

2. When an error occurs with the speaker, please turn off the speaker and restart it to troubleshoot.
3. When the speaker's power is low, the Bluetooth range may be affected. Please charge the speaker to avoid disruptions during use.

PROBLEM	TROUBLESHOOTING METHOD
Unable to pair the speaker with a mobile device	<ol style="list-style-type: none"> <li>1. Inspect whether the speaker is searching for a Bluetooth enabled device to connect to. If not, restart the speaker.</li> <li>2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices.</li> <li>3. The power of the battery is insufficient, please recharge the speaker.</li> </ol>

page 06

PROBLEM	TROUBLESHOOTING METHOD
The music stops from time to time	<ol style="list-style-type: none"> <li>1. Inspect the distance between the speaker and the Bluetooth enabled device, it may exceed the Bluetooth transmission range.</li> <li>2. Inspect if there is an obstacle between the speaker and the Bluetooth enabled device.</li> <li>3. The power of the battery is insufficient, please recharge the speaker.</li> </ol>
The sound is low or distorted	<ol style="list-style-type: none"> <li>1. Inspect the volume of the connected speaker or Bluetooth enabled device and adjust the volume as needed.</li> <li>2. The power of the battery is insufficient, please recharge the speaker.</li> </ol>

The *Bluetooth®* word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.

page 07

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.