

**Test positions for body:**

According to the antenna position, the Body SAR is tested at the following 6 test positions all with the distance =10mm between the EUT and the phantom bottom :



**Toward Phantom (10mm)**




**Toward Ground (10mm)**



**Toward Left (10mm)**



**Toward Right (10mm)**



**Toward Top (10mm)**



**Toward Bottom (10mm)**