

快速入门指南

- **前置摄像头(选配)**
- **指示灯**
用于充电、信息、扫描等灯光提示。
- **自定义键**
可设置快捷功能。
- **扫描键**
别称扫描键。
- **电源键**
短按：点亮屏幕、锁定屏幕。
长按：关机状态下，长按2-3秒开机；
使用状态下，长按2-3秒，可选择关机或重启；
死机状态下，长按1秒，自动重启。
- **喇叭出声孔**
注意：请保持出声孔清洁。
- **扫描头**
用于条码数据读取。
注意：请保持扫描头清洁。
- **后置摄像头**
支持拍照及1D/2D快速扫码。
- **背屏摄像头**
配置不同，数量不同。
- **SIM/PSAM卡槽**
SIM和PSAM功能二选一，默认是SIM卡功能。
PSAM功能仅特定的机型支持。
注意：插卡时按照图示插入。
取卡时先按住卡槽金属触点卡推出，然后将金属触点卡取出。
- **Nano SIM/Micro SD卡槽**
用于插入Nano SIM卡以及Micro SD卡。
注意：插入或取出Nano SIM卡时，请务必让机器处于关机状态，若开机状态下插拔可能造成机器故障。
- **电池盖开关**
左右滑动实现电池盖开关功能。
注意：电池盖安装在设备上，否则影响正常使用。

● **NFC读卡器(选配)**
用以感应会员卡等NFC卡。

系统预装软件列表

软件名称	信	来	预	装	功	能	多	语	多	语	多	语
语言	中	英	法	德	日	韩	俄	西	葡	意	希	印
操作系统	√	√	√	√	√	√	√	√	√	√	√	√
浏览器	√	√	√	√	√	√	√	√	√	√	√	√
短信	√	√	√	√	√	√	√	√	√	√	√	√
通讯录	√	√	√	√	√	√	√	√	√	√	√	√

● **本产品含有有害物质名称及含量列表**

● **有害物质名称及含量**

● **有害物质名称**

● **含量**

● **备注**

● **说明**

● **产品合格证**

● **产品保修卡**

● **产品名称**

● **产品型号**

● **产品编号**

● **保修期限**

● **保修说明**

● **联系方式**

安全警告

● **注意**

● **重要安全提醒**

● **建议**

● **声明**

● **免责声明**

● **产品合格证**

● **产品保修卡**



Quick Start Guide

- **Front Camera (Optional)**
- **Indicator Light**
For indicating the charging status, messages and screens.
- **Function Button**
Use it to create a custom shortcut.
- **Scan Button**
Short press the button to scan barcodes.
- **Power Button**
Short press: turn the device on/off, press for 2-3 seconds to turn on the device.
When the device is on, press for 2-3 seconds to power off or restart the device.
When the system crashes, press for 11 seconds to restart the device.
- **Speaker Holes**
Please keep the speaker holes clean.
- **Scanner**
For barcode data collection.
Note: laser radiation. Do not stare into beam.
- **Rear Camera**
For photo taking and 1D/2D barcode scanning.
- **Pogo Pin**
The number depends on the specific configuration.
- **SIM/PSAM Card Slot**
It by default is a SIM card slot, but you can choose a PSAM card feature which is available in certain device versions.
Note: please follow the instruction label to insert the card. To remove the card, hold and pull the metal slot handle out, push the handle back and then take the card out.

● **Nano SIM & Micro SD Card Slot**
For Nano SIM card and Micro SD card.
Note: please shut down the device down before inserting or taking the Nano SIM card out.
Otherwise, it may cause device malfunction.

● **Battery Cover Lock**
Slide to open or close the cover.
Note: please keep the cover closed.
Otherwise, it may affect your use.

● **NFC Reader (optional)**
For reading NFC cards, like loyalty cards.

Table for RoHS and Content identification of toxic and hazardous substances in this product

Part	Pb	Hg	Cd	Cu	Cr(VI)	PbA	PbB2
Circuit Board Component	×	0	0	0	0	0	0
Structural Component	0	0	0	0	0	0	0
Fastening Component	0	0	0	0	0	0	0

● **Notes**

● **Safety Warning**

● **Battery replacement**

● **Significant Safety Instructions**

● **Restrictions of use**

● **Product safety warning**

● **Battery safety**

● **CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.**

● **Manufacturer**
Shanghai Sunmi Technology Co., Ltd.
Room 505, Building 7, KIC Plaza, 388 Songhu Rd.,
Tangqiu District, Shanghai, China.

Table for RoHS and Content identification of toxic and hazardous substances in this product

● **Notes**

● **Safety Warning**

● **Battery replacement**

● **Significant Safety Instructions**

● **Restrictions of use**

● **Product safety warning**

● **Battery safety**

● **CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.**

● **Manufacturer**
Shanghai Sunmi Technology Co., Ltd.
Room 505, Building 7, KIC Plaza, 388 Songhu Rd.,
Tangqiu District, Shanghai, China.

Certification information (SAR)

Technical features and characteristics

Model	Power (dBm)
CS6800	20.2
CS6801	20.2
CS6802	20.2
CS6803	20.2
CS6804	20.2
CS6805	20.2
CS6806	20.2
CS6807	20.2
CS6808	20.2
CS6809	20.2
CS6810	20.2
CS6811	20.2
CS6812	20.2
CS6813	20.2
CS6814	20.2
CS6815	20.2
CS6816	20.2
CS6817	20.2
CS6818	20.2
CS6819	20.2
CS6820	20.2
CS6821	20.2
CS6822	20.2
CS6823	20.2
CS6824	20.2
CS6825	20.2
CS6826	20.2
CS6827	20.2
CS6828	20.2
CS6829	20.2
CS6830	20.2
CS6831	20.2
CS6832	20.2
CS6833	20.2
CS6834	20.2
CS6835	20.2
CS6836	20.2
CS6837	20.2
CS6838	20.2
CS6839	20.2
CS6840	20.2
CS6841	20.2
CS6842	20.2
CS6843	20.2
CS6844	20.2
CS6845	20.2
CS6846	20.2
CS6847	20.2
CS6848	20.2
CS6849	20.2
CS6850	20.2

● **CE**

● **RoHS**

● **REACH**

● **WEEE**

● **Information about the software**

● **Restrictions of use**

● **Product safety warning**

● **Battery safety**

● **CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.**

● **Manufacturer**
Shanghai Sunmi Technology Co., Ltd.
Room 505, Building 7, KIC Plaza, 388 Songhu Rd.,
Tangqiu District, Shanghai, China.

CE

RoHS

REACH

WEEE

Information about the software

Restrictions of use

Product safety warning

Battery safety

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

Manufacturer
Shanghai Sunmi Technology Co., Ltd.
Room 505, Building 7, KIC Plaza, 388 Songhu Rd.,
Tangqiu District, Shanghai, China.

制作工艺说明

成品尺寸: 62mm × 155mm

展开尺寸: 310mm × 155mm

工艺: 黑色印刷+2专色, 5折页

材质: 105g 雅粉纸

物料编码: M05052179

制 图: 张盼

图纸名称: L2Ks 移动数据终端----说明书


供 应 商: 华勤

发行日期: 20210914

变更原因: 增加NFC功能

单位: mm

版本: 1.2



制 图:	张盼
图纸名称	L2Ks 移动数据终端----说明书
供 应 商	华勤
发行日期	20210914
变更原因	增加NFC功能
单位	mm
版本	1.2