

104 mm

Wireless Presenter

User Manual

Wireless Presenter

User Manual

Wireless Presenter

User Manual

Wireless Presenter

User Manual

Wireless Presenter

User Manual

Wireless Presenter User's Manual

Model:DSIT0011

WARNING!

FCC WARNING:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF EXPOSURE STATEMENT:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Charter 1 Introduction

I. Product description

It is a great tool for PowerPoint presentations! With it, You can effortlessly deliver your best PowerPoint presentations with the wireless presenter, Highlight important details with the laser pointer and manage the presentation within a 100 meters range.

II. Features

1) Support PowerPoint, Keynote and Prezi The functions of page down and page up buttons can switch among Page Down/Up, Left/Right Arrow and Up/Down Arrow, by press the page down and page up buttons at the same time.

2) Up to 100 meters wireless range

3) Support hyperlinks function in PowerPoint.

4) Volume up/down

5) Through UniCoding 6 technology, the transmitter can control 1 up to 6 USB receivers.

6) Provide great button-pressing experience by Silica Gel Button.

7) Storable receiver for easy carrying.

The USB receiver can be stored into the wireless presenter

8) On/off power switch

9) 2.4G RF frequency, which is an ISM free frequency and can be used World-wide.

10) Plug-and-play simplicity

11) One AAA battery, easy to replace.

Who should have this device All the people who present with PowerPoint and a projector, such as teachers, trainers, businessmen, will need this device.

III. Operation system

Windows 7, Windows 8, Windows 10, Mac OS, Linux, Android 4.3 or above

IV. Package contents

1) Wireless presenter (USB receiver included) * 1

2) User Manual * 1

3) AAA * 1

IV. Specifications Transmitter

Technology:	Radio Frequency
Frequency:	2.4GHz
Control Distance:	>100m
Laser Class:	II
Max Output:	<1mW
Laser Distance:	>200m
Wavelength:	650nm
Battery:	AAA*1
Working Voltage:	1.5V
Dimension:	139.2*18.2*19.7mm
Weight:	21.7g

USB Receiver

USB Version:	USB 2.0
Working Voltage:	5V DC
Dimension:	26.5*12.7*5.5 mm
Weight:	1.9g

Charter 2 Getting Started

V.Function map

Click: Tab

Double Click:Enter

Press and Hold: Alt-Tab

Page Up

Page Down

Laser Pointer

LED

Press 2 Seconds Play Slides

Press 2 Seconds Black Screen

Long press the "Up" and "Down" at the same time to switch Prezi Mode.

—01—

—02—

—03—

—04—

—05—

Wireless Presenter	User Manual	Wireless Presenter	User Manual	Wireless Presenter	User Manual	Wireless Presenter	User Manual	Wireless Presenter	User Manual
<div><div><div><div><div>Power Switch</div><div>Battery Store</div><div>Receiver</div></div></div></div></div>	<div><div><div><div>VII. Function Description</div><div><p>1) Open Microsoft PowerPoint and PowerPoint files.</p><p>2) Press "Page Up" button for 2 seconds to play slides from the current page. Press the button for 2 seconds again to escape from the full screen.</p><p>3) Press "Page Down" button and "Page Up" button to go forward and backward.</p><p>4) Press and hold Pointer button to turn it on, release button to turn it off.</p><p>5) If hyperlinks exist on the page, click button, you can jump among the hyperlinks and double click can be used to open the hyperlink.</p><p>6) After the hyperlink is opened, you can press and hold button to switch between all opened application windows. Release it to turn to the window you want to switch to.</p><p>7) Press "volume up" or "volume down",you can adjust system volume.</p></div></div></div></div>	<div><div><div><div>IX. Installation</div><div><p>1) Install battery</p><p>Open the presenter battery store cover, and base on battery electrode sign to install battery. Refer to the below figures:</p><p>2) Take out the USB receiver from the wireless presenter</p><p>Take out the USB receiver from the wireless presenter. Push the power switch to on position; you can press any button to check whether the power is on or not. If the LED is flashing when the button is pressed, it means the wireless presenter is turned on.</p><p>3) Install the USB receiver</p></div></div></div></div>	<div><div><div><div>Please plug the receiver into the laptop's USB port. The system will automatically detect the device. Follow the steps to search the driver of the USB device and complete the setup.</div><div>4) Operate the wireless presenter When a button is pressed, the blue LED on the wireless presenter will flash. When the USB receiver receives control signal, the LED on the USB receiver will flash too.</div><div>5) Turn off the wireless presenter Plug the USB receiver into the wireless presenter, and push the power switch to off position.</div></div></div></div>	<div><div><div><div>Charter 3 Frequently Asked Questions</div><div><p>1) How to know the battery is out of power?</p><p>If there is no beam emitted when you click the pointer key; it means your battery runs out, please charge it immediately. Excessive discharge will severely shorten the useful life of lithium battery.</p><p>2) The pointer does not work, why?</p><p>Firstly you need to turn on the power. Secondly you can check whether the wireless presenter is in low power or out of power. If the LED flash slowly, it means the power is low and the battery needs to be replaced. If all the other buttons can work, only the laser pointer cannot work, the laser diode may need replacement.</p><p>3) When the USB receiver plugs into the PC USB, the laptop does not detect the device, why?</p><p>Please try another USB port or another PC.</p></div></div></div></div>	<div><div><div><div>Charter 4 About Safety</div><div>X. Safety measures</div><div><p>1) To avoid possible eye damage, never point the wireless presenter at people especially their faces, or look directly into the wireless presenter's beam.</p><p>2) Avoid pointing the wireless presenter's beam at a mirror or other highly reflective surface.</p><p>3) Keep the wireless presenter away from children.</p><p>4) Never view the wireless presenter's beam using telescopic devices, such as a microscope or binoculars.</p><p>5) Any attempt to disassemble, adjust or repair the wireless presenter may result in exposure to laser light or other safety hazards.</p></div><div><div>XI. Certifications</div><div>CE, FCC, RoHS</div></div></div></div></div>				
	—06—	—07—	—08—	—09—	—10—	—11—			

52 mm