

ViewClix™ 15

Operating Guide

ViewClix makes it easy for families to stay in touch with seniors.

To ensure that using ViewClix is an easy and fun experience for you and your loved ones, we need a family member or friend to do a small amount of organizing and administration for the ViewClix Smart Frame. (this person is called the 'Frame Organizer').

This guide provides a straight-forward, step-by-step process for getting ViewClix setup and then exploring its use and features. **It's really easy! Please follow this guide** from start to finish and you'll quickly be a ViewClix expert.



Table of Contents

Introduction.....	2
Installation of the ViewClix frame	3
Setup Internet connection	6
ViewClix remote control	7
Get the ViewClix Mobile App.....	8
Share pictures with the ViewClix frame	8
Make a Video Call	9
Organize pictures	10
Post a "Sticky Note"	13
Enable family and friends to share	15
with the ViewClix frame	
Set the 'sleep time' for the ViewClix frame	17
Tips and FAQ	19
Change the Wi-Fi network settings	21
Frame Placement, Camera & Room Lighting	23

Introduction

The ViewClix Smart Frame displays beautiful High Definition Pictures and receives Video Calls. Using the free **ViewClix Mobile App**, families can easily share pictures and make video calls to a ViewClix frame

The solution is tied together by the **ViewClix Cloud** which stores all the pictures and manages the networking for sharing and video calling. The ViewClix web site also includes a **Members Portal** where a ViewClix frame is remotely configured and photos are easily organized.

What's in the box

- ViewClix Smart Frame
- ViewClix Remote Control
- ViewClix Microphone
- Frame Stand
- Power Adapter



Remote control



What you'll need

- Web browser on PC or Mac or Tablet to log into the ViewClix Members' Portal.
- Also, you can share Photos, make Video Calls and post Sticky Notes with any of the following devices:
 - Apple or Android smart phone
 - Apple or Android tablet



Frame Stand



Microphone



Power adapter

First, a few essentials...

- The primary operating mode of a ViewClix frame is to display its **Slideshow**, sequencing through pictures that have been shared by family or friends.
- When a Video Call is received, the Slideshow is hidden during the call. After the call is ended, the Slideshow automatically starts displaying again.
- Starting a ViewClix frame is accomplished by plugging it in — **no need to worry about a power switch**. Likewise, if you need to move the ViewClix frame, just unplug it.
- When a ViewClix Smart Frame is powered on, it displays a few “splash screens” and the Internet connection is setup/established. After that, the frame will show a camera preview so that you can make sure the position and lighting is good for Video Calls.

Install the ViewClix Smart Frame


We recommend that the Frame Organizer initially set up the frame in their own home, prior to installing at the senior’s residence.

This “staging” will help the process of getting started go smoothly.

Step 1

Open the box and take out the ViewClix frame.

Remove the frame from packing materials and place it face-down on a cloth-covered flat surface, to avoid scratches.





Install the ViewClix Smart Frame (CONTINUED)

Step 2 Remove the frame stand from the shipping bag.



Install the stand on the frame's back bottom by sliding tabs into back lower center slot.



Push the Stand into the slot to lock into the back of the frame.

Step 3 Remove the ViewClix Microphone from its shipping bag.



Plug the microphone into its input jack as indicated in the picture.

IMPORTANT NOTE

When the ViewClix frame is all set up, the microphone must be placed in front of the frame.



Step 4

Remove the Power Adapter from its shipping bag.




Plug the power connector into the frame power socket, as shown.



Step 5

Place the frame near a power outlet on a table top or counter top. Choose a location that can offer good illumination.



Plug power adapter into the power outlet.



The frame will now start up and display its initial screens.

Setup Internet connection for the frame

The ViewClix Smart Frame includes built-in Wi-Fi connectivity.

When the ViewClix frame starts up, it displays a “welcome” screen with a prompt to start Wi-Fi configuration. The list of available Wi-Fi networks is then shown. After choosing a network or entering a network name, you’ll be prompted to enter the network’s password/key.

NOTE: If you don’t see the Wi-Fi network listed, it may be because the network is configured to be “hidden” or “private”. In this case, you can select “Add Network” to enter the Network name (SSID) and password/key.

The ViewClix frame connects easily to *home* Wi-Fi networks. However, the ViewClix frame should not be connected to *public* Wi-Fi networks such as “xfinitywifi” or “attwifi” because public networks use non-standard, proprietary login techniques.

Potential Issues with Shared Wi-Fi Networks in Senior Living Facilities

The ViewClix frame can be configured to connect to a shared Wi-Fi network. However, we’ve found that those networks often have performance issues at certain times of the day which can cause issues and disruptions with video calls. We recommend that you coordinate with the facility management regarding the coverage quality and Wi-Fi performance if a ViewClix frame is connected to a shared network.

Preview Camera

- After connectivity is confirmed, a preview of the camera is shown. This will help you position the frame in the best location for a Video Call.
- If the preview appears dark or not positioned properly, see the section “**Frame Placement, Camera & Room Lighting**” on page 23 of this guide.
- When you’re OK with the camera preview, the Slideshow begins automatically.

That's it — the installation is complete.

When the ViewClix Smart Frame is shipped, there are a few sample images in the Slideshow. To share pictures and make video calls, you and family members may use the **ViewClix Mobile App** or a web browser on a PC or Mac.

The next pages in this guide will help you get started with those actions.

ViewClix Remote Control

The ViewClix Smart Frame is shipped with a remote control to enter commands.

The Remote Control will be needed to finish the setup/installation process.

You can use the remote control to pause the Slideshow. Use the forward and back buttons < > to move through the pictures.



Get the ViewClix Mobile App

To download and install the ViewClix app from the Apple App Store or Google Play Store, follow the steps in email that was sent after ordering the ViewClix frame.

The app will guide you through logging into your ViewClix account to link your mobile device with the ViewClix frame.




Share pictures with the ViewClix frame

The main screen on the ViewClix app is simple: you can touch the button to 'Share a Picture', 'Make a Video Call', or 'Post a Sticky Note'

- Touch 'Share a Picture:'
 - For Apple devices: You'll then select an album to select pictures.
 - For Android devices: You'll see a collection of pictures
- Select from 1 to 4 pictures to share and then you can enter caption and confirm sharing.
- The picture(s) will be uploaded to the ViewClix Cloud and in a minute or two, the picture(s) will automatically appear in the Slideshow.
- Repeat to share more images.

TIP: When you upload more than one picture, you'll see a small pencil icon in the corner of each picture. Tap on that icon to add caption text for each picture.



Make a Video Call

While it's displaying the Slideshow, the ViewClix Smart Frame is always ready to receive a video call. Here are a few things to keep in mind about ViewClix video calling:

Frame auto-answers: After playing a notification sound, the Video Call is launched on the frame. It's a good idea to arrange the time of your calls in advance.

NOTE: Auto-answer can be disabled within the Frame Settings (see page 18). If disabled, the frame user (i.e. the senior using the frame), will need to press any button on the remote control to answer video calls.

No video calls while in Sleep mode: On page 17, we show how to set up the sleep time for a ViewClix frame. The frame does not answer video calls during this time.

Call Setup Time After you tap the 'Make Video Call' button it will take up to 15 seconds, for the Video Call to begin. Patience is a virtue 😊

Try making a test video call.

NOTE: The best way to make a test call is to have someone by the frame while you call it from a different room. If you call the frame from within the same room, you will probably experience unpleasant echo and audio feedback because the microphones will be picking up the other side's speakers.

- Tap the 'Make Video Call' button to start the call.
- To end the call, touch the Red "hang-up" button.



More video call tips

- **Orientation:** "Landscape" orientation is where the width of the screen is longer than the height. As a stationary device, the ViewClix frame is always in "landscape" orientation. If you **rotate your mobile device to also be in landscape mode**, the video will be larger for both the mobile device and the frame.
- **Video calls using public Wi-Fi networks:** Some commercial places, like restaurants or hotels, have Wi-Fi networks that do not support the video call connections.
- **Video calls using a smart phone's mobile data:** if Wi-Fi is unavailable, you can use your smart phone's data plan to make a ViewClix Video Call. But just like watching any video using a smart phone, your data usage rates from your mobile carrier will apply.

Organize Pictures


Pictures that are shared with a frame are stored on the ViewClix Cloud server.

You can organize the Slideshow and manage photos using the **Members Portal** at the ViewClix web site.


Initially, there are a few sample pictures in the Slideshow. You'll want to use the Photo manager to delete those.

Here are the steps:

- Using a web browser on a PC, Mac or Tablet, go to the Members Portal:
www.viewclix.com/members
- You'll be prompted to login using your email address and password and then the web page below will be displayed.
- Click or tap "Photos"



The Photos web page will open and you'll see the pictures currently in the Slide Show:



The pictures displayed in the Photo Album are in the order in which they appear in the ViewClix frame Slideshow playback, from left to right and top to bottom.

Select multiple pictures by clicking/tapping on them. Click/tap the Move icon to move the selected photos out of the active Slideshow to another album such as 'Archive'. Click or tap the Delete icon remove the photos entirely.

Upload photos

In addition to using the ViewClix mobile app to upload pictures, you can click/tap the Upload icon and a new window will appear.

You can then drag and drop or browse and select additional images from the PC, Mac or Tablet that's in use.



Captions can be added when you upload a picture using the ViewClix mobile app. You can also add or edit captions here by clicking/tapping the on the caption text or the pencil icon  underneath a picture.

NOTE: By default, the ViewClix frame displays the picture captions during its Slideshow. If you'd like to turn off the captions in the Slideshow, you'll need to disable it in the ViewClix frame Settings. See page 18 for information on this setting.

Organize Pictures (CONTINUED)

Rearrange: ☐ Off

If you click or tap on **Rearrange** switch, you can drag and drop photos into a different order to change the sequencing of the Slideshow playing on the ViewClix frame.



Tip: In the lower right corner of each picture is an asterisk (*) icon. Click/tap this icon if you need to rotate a picture or adjust Magic Zoom. The magnifying glass icon on the left will pop up a large version of the picture.

Moving Pictures to Other Albums

Why move pictures to other Albums? After using ViewClix for a while, the Slideshow album might be filled with quite a few photos. It's best to not have too many since the more pictures, the longer it will take the ViewClix frame to cycle through them. A good rule of thumb is to keep the total under 100. This makes room for new photos to be seen by your senior.

In addition to the Archive album, you can create additional albums to store pictures. For example, you can create a "Holidays" album and once the holidays are over, you can move pictures to it. Then next year, you can highlight those memories by moving the photos back to the Slideshow.

Post a Sticky Note to the ViewClix frame

ViewClix includes an innovative feature to post reminders, messages and announcements to a ViewClix frame. We call this feature, "Sticky Notes".



A Sticky Note can be a simple text note that appears in the upper left or lower right corner of the ViewClix screen during the Slideshow. You can also use a full-screen image or picture as a Sticky Note and that image could include a special message — for example, *the Sticky Note feature can be used to send a virtual post card or greeting card!* (the ViewClix blog includes tips on how to add text to a picture: www.viewclix.com/blog)

The display of the Sticky Note is scheduled using the ViewClix mobile app or the ViewClix member web portal. Up to 2 text Sticky Notes and/or 1 image Sticky Note can be displayed at the same time. A alert sound plays when a Sticky Note displays.

Who can post a Sticky Note? The Frame Organizer can post Sticky Notes. Also, the Frame Organizer may enable anyone that's on the frame's Share List to post Sticky Notes. To do that, click the user icon  and edit the permissions. (see page 15 about adding people to the Share list)

Can the display of a repeating Sticky Note be dismissed? Yes, while it's displaying, press the OK button the remote control to dismiss a Sticky Note.

Post a Sticky Note (CONTINUED)

We've made adding a Sticky Note as straight-forward as possible. Below is a screen shot of the display to add or edit a Sticky Note.

The screenshot shows the 'ENTER A NEW STICKY NOTE' form in the ViewClix interface. The form includes a header with the ViewClix logo and navigation links for PHOTOS, STICKY NOTES, and SH. The main form area is titled 'ENTER A NEW STICKY NOTE' and contains the following sections:

- NOTE NAME:** A text input field.
- NOTE TEXT DISPLAYED ON THE VIEWCLIX FRAME:** A large text area for the note content.
- Alternative:** A button labeled 'UPLOAD IMAGE'.
- STARTING DATE & TIME FOR THE NOTE:** A calendar for August 2018 with a time picker set to 09:00 AM.
- DISPLAY TIMING:** A section with a list of options: 'Note will be displayed for 2 minutes.', 'Display will be repeated every 15 minutes.', and 'Display will stop after 1 hour.' Below this is a 'CHANGE' button.
- PERIODIC DISPLAY:** A section titled 'Should the Note re-occur?' with radio buttons for 'No recurrence', 'Daily', 'Weekly' (selected), and 'Monthly'. Below this is a section for 'Recur every 1 week(s) on:' with checkboxes for each day of the week: Sunday (checked), Monday, Tuesday, Wednesday, Thursday, Friday, and Saturday.
- Next Step:** An orange button at the bottom.

Each Sticky Note is given a reference name

In the Note Text area, add the message text for the Sticky Note.

Click the 'Upload Image' button if you'd like to use a full-screen image for the note.

Select the data and time for the display of the Sticky Note. The date must be in the future.

NOTE: The date and time are relative to the **Frame's time zone**.

Display Timing lets you schedule the note to repeat for 1 to 4 hours.

Periodic Display let's you repeat a note with daily, weekly or monthly recurrence.

Enable family and friends to share with the ViewClix Smart Frame

The ViewClix Cloud maintains a **Share List** for each ViewClix frame. There are 2 ways that family and friends can be added to the Share List:


- The Frame Organizer logs into the **Members Portal** of the ViewClix web site and adds the person to the Share List.

... OR ...

- The Frame Organizer can use the ViewClix mobile app to quickly add the person to the Share List.

Here, we will illustrate the first option.

- Click or tap "Share List"



The screenshot displays the ViewClix Member Portal interface. At the top, a dark blue navigation bar contains the ViewClix logo on the left and links for MEMBERS, LOG OUT, ACCOUNT, PHOTOS, STICKY NOTES, SHARE LIST, FRAME, and FAQ on the right. A red arrow points to the SHARE LIST link. Below the navigation bar, the page title is "ViewClix Member Portal". A welcome message reads: "Welcome! You are managing Bob Ranck's ViewClix Frame" followed by a small icon of a frame. The main content area features six large, rounded rectangular tiles arranged in a 2x3 grid. Each tile has an icon, a title, and a brief description. The tiles are: 1. Photos (icon of a photo album), 2. Sticky Notes (icon of a notepad), 3. Share List (icon of three people with a plus sign, highlighted with a red hand cursor), 4. Frame Settings (icon of a frame with a gear), 5. Video Call (icon of a video camera), and 6. Account (icon of a person with a checkmark). The Share List tile's description states: "Add family and friend to the list of people that can share pictures and make video calls with this ViewClix Frame".

ViewClix Member Portal

Welcome! You are managing Bob Ranck's ViewClix Frame

Photos
Manage your frame's Slideshow -- Rearrange, archive, and upload pictures.

Sticky Notes
Add text and images that will pop-up on the ViewClix frame as periodic reminders and special messages.

Share List
Add family and friend to the list of people that can share pictures and make video calls with this ViewClix Frame


Frame Settings
Remotely manage a ViewClix Frame. Change settings such as when the Frame is in 'sleep mode' and how it displays its Slideshow.

Video Call
Make a video call with the ViewClix Frame

Account
Edit account information and how notifications are delivered. Customers can also modify billing settings

Enable family and friends to share (CONTINUED)

After clicking or tapping on '**Share List**', the following web page will be displayed:



Share List: Nancy Norton's ViewClix frame

This is the list of people that may share pictures and make video calls with this ViewClix frame.

When you add someone to this list, they will be sent an email to confirm activation of a ViewClix account as well as information on how to get the ViewClix mobile app

FIRST NAME	LAST NAME	EMAIL		
Bob	Frankina	greenp@icloud.com		
Catherine	Ranick	ranick@icloud.com		
Diane	Pinelli	diane@verizon.net		
Jane	Stier	jane@icloud.com		
Katie	Frankina	katie@icloud.com		
MaryJo	Ciuni	maryjo@icloud.com		

- Add family and friends to the Share List easily: just input their name and email address.
- Immediately after a person is entered in the Share List, they will be sent an account activation email.
- Once setup and activated, they can also get the ViewClix app and start sharing pictures and making video calls.

Share List Icons



User has accepted the Share List invitation and may share with the frame. ALSO: Click this icon to enable other permissions for the user such as enabling them to post Sticky Notes to the frame



Until an account is activated, the red exclamation icon is next to the name. That person can't share or video call with the frame yet.



Click or tap this icon to resend the account activation email.



Click or tap this icon to delete this Share List user from this frame. Once this has been completed, the user will no longer be able to share or make video calls to this frame.

Set the 'sleep time' for the ViewClix Smart Frame

In most instances, it will be desirable to not have the Slideshow running at night.

The good news is that all ViewClix frame settings can be configured remotely and changed whenever you like.

ViewClix

MEMBERS | LOG OUT | ACCOUNT

PHOTOS STICKY NOTES SHARE LIST FRAME FAC

Settings: Irene Ranck's ViewClix frame

SAVE SETTINGS

connection status: ONLINE

First Name

Middle Name

Last Name

Time Zone

View Captions in Slideshow? ☒

Randomize Slideshow? ☐

Slide duration
Enter a whole number between 5 and 15 seconds.

Auto Answer Video Calls? ☒

Magic Zoom Enabled? ☒

Brightness

Volume

Mute video calls? ☐
Turn off the frame's audio during video calls.

Sleep Enabled? ☒

Start sleep time
Time Zone - where the Frame is located

End sleep time

SAVE SETTINGS

- Here are steps to configure sleep. The settings for Sleep are at the bottom of the list of Frame Settings.
- First, make sure the box for "Sleep Enabled?" is checked.
- Second, enter the desired Sleep Start Time and Sleep End Time. The times are local to the time zone where the frame is located.

Other tips regarding Frame Settings

- **Make sure that you click or tap “Save Settings” when you’re ready to update the frame.**
- The ViewClix frame will receive the updated settings immediately.
- **Disable auto-answer of video calls:** some seniors may prefer to answer the video calls manually. When auto-answer is unchecked/disabled, the frame user will need to press any button on the remote control to answer the video call.
- **Viewing captions in the Slideshow:** By default, picture captions are shown during the frame’s Slideshow. If you’d like to change that, use the “View Captions in Slideshow” checkbox.
- **Slide duration:** You can change the number of seconds that a picture is stays on the frame screen before advancing to the next.

Tips and FAQ

• How does a family member or friend share a picture from Facebook to a ViewClix frame?

NOTE: If you're using an Apple smart phone or tablet, you may see the message, "Please Allow Photo Access", when you try to save a photo from Facebook. In that case, follow these steps to enable Facebook to save photos:

- Open the iPhone or iPad Settings.
 - Tap 'Privacy'
 - Tap 'Photos'
 - Set Facebook to ON
1. In Facebook, touch the picture to see it's full view.
 2. In the upper right corner of the screen, touch the menu icon (it's the 3 vertical dots)
 3. Select "Save Photo" from the menu.
 4. After the picture is saved, open the ViewClix mobile app and select "Share a Picture" to select the picture and share it with the ViewClix frame.

• Can the frame's Slideshow be paused?

Yes! First, press the Pause / Play button on the remote control.

To re-start the Slideshow, press this button again.



Then, use the < and > buttons to move backward and forward in the Slideshow pictures

Tips and FAQ (CONTINUED)

- **The words, "not connected" are displayed in the top right corner of the ViewClix Smart Frame. What should be done?**

"Not connected" means that the ViewClix frame is currently not connected to the Internet. This may not require any action since the ViewClix automatically attempts on its own to restore the connection.

Usually, automatic reconnection is successful within 15 minutes.

If the 'not connected' message is displayed for more than 1 hour, a notification message (an alert) will be sent to the ViewClix Frame Organizer to let them know the frame is not connected.

If the ViewClix frame is connected via Wi-Fi

- When 'not connected' is displayed for an extended period of time (more than 1 hour), the following should be checked:
- The Wi-Fi router equipment may have an issue and need to be "rebooted" by unplugging it and re-plugging it in.
- The Internet service provider may be having an issue. In this case, other Wi-Fi devices like smart phones, tablets and PC's will also not be able to connect to the Internet. You may need to contact the Internet service provider.

If the ViewClix frame is connected via Broadband Mobile Data:

- When 'not connected' is displayed for more than an hour, you can try unplugging and re-plugging in the ViewClix Smart Frame to get it reconnected.

- **How many users can send pictures or make video calls to a ViewClix Smart Frame?**

Unlimited. Your whole family and all your friends can be on the frame's 'Share list'.

Tips and FAQ (CONTINUED)

- How can the Wi-Fi Settings be changed?



Press **3** times

With the Slideshow running on the ViewClix frame, you can go to its Frame Settings screen by **pressing the OK button 3 times**.

To change the Wi-Fi settings, use the remote control direction buttons to highlight 'Wi-Fi CONNECTION' on the screen and press OK.

As during the initial frame setup, you'll see a list of available Wi-Fi networks from which to choose.



Tips and FAQ (CONTINUED)

• What if I want to relocate the ViewClix Smart Frame?

No problem. Just unplug the frame and plug it in at its new location.

If you're moving the ViewClix frame to a location that has a different Wi-Fi network, the frame will sense that and prompt you to choose the new network and enter the Wi-Fi password.

Please refer to the next page for testing the camera for adequate room lighting.

• A shared picture is not rotated properly. How can I fix it?


The ViewClix system tries to detect picture rotation and fix issues but sometimes, these can't be automatically corrected. The ViewClix frame organizer can manually rotate the picture by following these steps:

1. The organizer logs in to the ViewClix member portal at www.viewclix.com/members
2. Tap/click on the 'Photos' icon. The 'thumbnail' images of the Slideshow pictures will be displayed
3. Find the picture to rotate and tap/click on the '+' sign at the bottom right hand corner of the thumbnail.
4. A menu will be displayed. Select Rotate Left or Rotate Right and the picture will be rotated 90 degrees in the that direction.
5. After a few minutes, the picture in the Slideshow on the ViewClix Smart Frame will be updated to the correct rotation.

Frame Placement, Camera & Room Lighting


Most seniors want the frame placed in a convenient location where there is seating to engage in a video call. Because the ViewClix Smart Frame displays its Slideshow each day, this location should also be somewhere that adds a focal point in family picture settings.

Because ViewClix Smart Frame displays are reflective surfaces, they will mirror lit images from across a room, especially when displaying dark background pictures. The first consideration is the location in the room relative to any windows with sun exposure. The brighter the window, the brighter the reflection off the frame's screen. Try positioning the screen facing away from any bright sources of lights in a room.



For video calls, you'll want to have good front lighting while avoiding bright background lighting. That way you'll be able to see your senior clearly.

Here's how to re-use the **Camera Preview** feature: As the Frame is running its Slideshow, press the **OK** button 3 times to view the Frame Settings.





ViewClix LLC

12210 SW Main St. #23545
Tigard, Oregon 97223

Phone: 800-304-4281
Email: support@viewclix.com



FCC ID: 2AH7X-VCF156S

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Apple, iPhone, and iPad are registered trademarks of Apple Inc., Google, Android, and Google Play are trademarks of Google Inc.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.