




Band41-10MHz-16QAM-40740-1RB#0-Range2:0.15~30MHz




Band41-10MHz-16QAM-40740-1RB#0-Range3:30~1000MHz



Band41-10MHz-16QAM-40740-1RB#0-Range4:1000~3000MHz



Band41-10MHz-16QAM-40740-1RB#0-Range5:3000~26500MHz




Band41-10MHz-16QAM-41190-1RB#0-Range1:0.009~0.15MHz




Band41-10MHz-16QAM-41190-1RB#0-Range2:0.15~30MHz




Band41-10MHz-16QAM-41190-1RB#0-Range3:30~1000MHz




Band41-10MHz-16QAM-41190-1RB#0-Range4:1000~3000MHz




Band41-10MHz-16QAM-41190-1RB#0-Range5:3000~26500MHz




Band41-15MHz-QPSK-40315-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-QPSK-40315-1RB#0-Range2:0.15~30MHz




Band41-15MHz-QPSK-40315-1RB#0-Range3:30~1000MHz



Band41-15MHz-QPSK-40315-1RB#0-Range4:1000~3000MHz




Band41-15MHz-QPSK-40315-1RB#0-Range5:3000~26500MHz



Band41-15MHz-QPSK-40740-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-QPSK-40740-1RB#0-Range2:0.15~30MHz




Band41-15MHz-QPSK-40740-1RB#0-Range3:30~1000MHz



Band41-15MHz-QPSK-40740-1RB#0-Range4:1000~3000MHz




Band41-15MHz-QPSK-40740-1RB#0-Range5:3000~26500MHz




Band41-15MHz-QPSK-41165-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-QPSK-41165-1RB#0-Range2:0.15~30MHz



Band41-15MHz-QPSK-41165-1RB#0-Range3:30~1000MHz




Band41-15MHz-QPSK-41165-1RB#0-Range4:1.000~3.000MHz




Band41-15MHz-QPSK-41165-1RB#0-Range5:3.000~26.500MHz





Band41-15MHz-16QAM-40315-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-16QAM-40315-1RB#0-Range2:0.15~30MHz




Band41-15MHz-16QAM-40315-1RB#0-Range3:30~1000MHz




Band41-15MHz-16QAM-40315-1RB#0-Range4:1000~3000MHz



Band41-15MHz-16QAM-40315-1RB#0-Range5:3000~26500MHz



Band41-15MHz-16QAM-40740-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-16QAM-40740-1RB#0-Range2:0.15~30MHz




Band41-15MHz-16QAM-40740-1RB#0-Range3:30~1000MHz




Band41-15MHz-16QAM-40740-1RB#0-Range4:1000~3000MHz




Band41-15MHz-16QAM-40740-1RB#0-Range5:3000~26500MHz



Band41-15MHz-16QAM-41165-1RB#0-Range1:0.009~0.15MHz




Band41-15MHz-16QAM-41165-1RB#0-Range2:0.15~30MHz




Band41-15MHz-16QAM-41165-1RB#0-Range3:30~1000MHz




Band41-15MHz-16QAM-41165-1RB#0-Range4:1000~3000MHz




Band41-15MHz-16QAM-41165-1RB#0-Range5:3000~26500MHz




Band41-20MHz-QPSK-40340-1RB#0-Range1:0.009~0.15MHz




Band41-20MHz-QPSK-40340-1RB#0-Range2:0.15~30MHz




Band41-20MHz-QPSK-40340-1RB#0-Range3:30~1000MHz



Band41-20MHz-QPSK-40340-1RB#0-Range4:1000~3000MHz




Band41-20MHz-QPSK-40340-1RB#0-Range5:3000~26500MHz




Band41-20MHz-QPSK-40740-1RB#0-Range1:0.009~0.15MHz



Band41-20MHz-QPSK-40740-1RB#0-Range2:0.15~30MHz




Band41-20MHz-QPSK-40740-1RB#0-Range3:30~1000MHz




Band41-20MHz-QPSK-40740-1RB#0-Range4:1000~3000MHz






Band41-20MHz-QPSK-40740-1RB#0-Range5:3000~26500MHz




Band41-20MHz-QPSK-41140-1RB#0-Range1:0.009~0.15MHz




Band41-20MHz-QPSK-41140-1RB#0-Range2:0.15~30MHz




Band41-20MHz-QPSK-41140-1RB#0-Range3:30~1000MHz



Band41-20MHz-QPSK-41140-1RB#0-Range4:1.000~3000MHz




Band41-20MHz-QPSK-41140-1RB#0-Range5:3000~26500MHz



Band41-20MHz-16QAM-40340-1RB#0-Range1:0.009~0.15MHz




Band41-20MHz-16QAM-40340-1RB#0-Range2:0.15~30MHz




Band41-20MHz-16QAM-40340-1RB#0-Range3:30~1000MHz



Band41-20MHz-16QAM-40340-1RB#0-Range4:1000~3000MHz



Band41-20MHz-16QAM-40340-1RB#0-Range5:3000~26500MHz



Band41-20MHz-16QAM-40740-1RB#0-Range1:0.009~0.15MHz