




Band38-15MHz-QPSK-37825-1RB#0-PASS **Band38-15MHz-16QAM-37825-1RB#0-PASS**




Band38-15MHz-QPSK-37825-75RB#0-PASS **Band38-15MHz-16QAM-37825-75RB#0-PASS**




Band38-15MHz-QPSK-38000-1RB#0-PASS **Band38-15MHz-16QAM-38000-1RB#0-PASS**




Band38-15MHz-QPSK-38000-75RB#0-PASS



Band38-15MHz-16QAM-38000-75RB#0-PASS



Band38-15MHz-QPSK-38175-1RB#0-PASS



Band38-15MHz-16QAM-38175-1RB#0-PASS