



Band66-3MHz-QPSK-131987-1RB#0-PASS **Band66-3MHz-16QAM-131987-1RB#0-PASS**



Band66-3MHz-QPSK-131987-15RB#0-PASS **Band66-3MHz-16QAM-131987-15RB#0-PASS**



Band66-3MHz-QPSK-132322-1RB#0-PASS **Band66-3MHz-16QAM-132322-1RB#0-PASS**

