

MANUAL AWC8-1016-BLK Please call or email us for customer support or for more information. Toll Free: 877-405-2397 info@ArmorA||E|ectronics.com V1.0 1123

Introduction

- • Universal compatibility with all wireless charging
- Includes 3ft. cable to power wireless charging



• Wireless Charging Phone Mount with Gooseneck Suction

- 3ft Micro-USB to USB-A Power Cable
- Manual

USB PD (or QC) power supply adapter with minimum specs of 5V/3A, 9V/2A (NOT INCLUDED)

At a Glance



Get Started

Assembly:

• Place suction gooseneck on a flat surface with orange knob positioned on the right.

- Turn orange knob towards you, counterclockwise,
- With the rubber ring on the phone holder/wireless charger's ball joint facing up, push the ball joint down into the top of the gooseneck's collar.
- Position the wireless charging mount at the desired angle and tighten orange knob 4 to 6 turns to hold it securely in place. (Please be sure not to over tighten
- Plug the included Micro-USB cable into the wireless charging mount's Micro-USB port which is located on the underside of the mount.
- To manage the cable, remove the orange cord clip from the gooseneck and insert the cable into the small hole. Reattach the cord clip on to gooseneck. Slide the clip up or down to your desired position to best manage

Mounting on the Dashboard:

- Make sure to choose the flattest area on the dashboard that doesn't obstruct your view of the road and your surroundings while driving.
- Clean the area with a clean cloth.
- Remove the clear film from the base of the suction cup.
- Mount the AWC8-1016 on your dashboard:
- Method 1: Open release latch on the front of the suction gooseneck's base. Place mount on dashboard. Close the latch by pushing it back down, to secure the mount to the dashboard. This should make a strong connection
- Method 2: If the dashboard is too curved, or if the vinyl surface is patterned the mount may not secure to the dashboard, use the included suction disc. If the mount cannot be securely held on the dashboard peel the protective film off the adhesive side of the disc. Stick the disc, adhesive side down on dashboard. Note that this disc permanently sticks to your dashboard. Follow the steps in Method 1 to secure the AWC8-1016 on suction disc. This should make a strong connection.
- To adjust the viewing angle, adjust the positioning the of the phone mount as needed by loosening the orange knob, rotating ball joint to the best angle, and retightening the
- To power the wireless charger, plug the USB-A end of the USB power cable into a USB-A power port such as the vehicle's USB power output port, or USB vehicle power adapter. (Requires power to charge)
- To use included cord management clip, peel protective coating from back and adhere to desired position. Feed cord

• To remove the mount from the dashboard, open the release latch on the front of the suction mount base by pulling it upward. Then then pull up on the suction

Mounting on the Windshield:

- Make sure to choose an area on the dashboard that doesn't obstruct your view of the road and your surroundings while driving.
- Clean the windshield area with a clean cloth.
- Remove the clear film from the base of the suction cup.
- Open the release latch on the front of the suction gooseneck's base by pulling it upward.. Place mount on vindshield at your desired location and close the latch. This should make a strong connection.
- To adjust the viewing angle, adjust the positioning the of the phone mount as needed by loosening the orange knob, rotating ball joint to best angle, and retightening
- To power the wireless charger, plug the USB-A end of the USB power cable into a USB-A power port such as the vehicle's USB power output port, or USB vehicle power adapter. (Requires power to charge)
- To use included cord management clip peel protective coating from back and adhere to desired position. Feed cord through it.
- To remove the mount from the windshield, open the release latch on the front of the suction mount base by pulling it upward. Then then pull up on the suction

Continued on reverse —

Mounting & Charging your Phone

- Press the oval button on the back on the back of your charger to release the arms. Fully expanded it will fit phones up to 3.6 inches wide in cases. Pull down on the
- Place the phone on the foot and adjust its position to center your phone at the center of the charger where the wireless icon is located. Adjust foot if necessary. Manually close arms to securely hold the phone in place.
- Connect the power cable from the phone holders USB-A port to a PD (or QC) power supply adapter. (NOT INCLUDED)
- The phone will begin charging immediately if the mount is connected to USB power and the phone is aligned properly with the wireless charger. (The charging icon will be displayed on your phone screen when it is being charged)
- * Wireless charging will only work with Qi wireless
- * Wireless charger works with most phone cases. However very thick phone cases can obstruct wireless charging. For effective charging, it may be necessary to reposition the phone or remove the case.

CAUTION:

- To prevent damage to the phone or the charger:
- Remove metal cases, or cases with any magnet/metal components, from phone before charging.
- Do not place metal objects on the charger
- Qi wireless chargeable phones with metallic looking finishes will charge normally.

Safety Instructions

- Please read and understand all instruction before using this product. If damage is caused by failure to follow instructions, the warranty does not apply.
- Keep your attention on the road. Do not operate the controls of this product while driving
- Read all the instructions before using the product, and • Secure and adjust before driving. Do not adjust while
- Keep close supervision of this product if being used • Do not expose to rain or moisture and do not use near
- Do not expose to extreme heat sources. Do not dispose

- Do not place metal items on the surface of the product. Do not cover the product with paper or other materials. Use in a well-ventilated area when charging.

 • Wireless chargers generate heat when charging, and the charger may temporarily stop charging if it gets
- Do not dissemble, modify, or try to use for a non-intended purpose, and do not use if damaged or modified. Never insert objects other than the specified cables into the product.
 Do not place magnetic strip cards or similar magnetically
- sensitive item between the phone and the charger. Wireless charging uses magnetic induction that could
- damage these items.

 Multiple Qi devices cannot be charged at the same time • Disconnect the USB cable from the USB power source if not in use or once the phone is fully charged.
- · Do not use abrasive cleaning solvents to clean the unit.

Specifications

Input: 5V/3A, 9V/2A

ONE YEAR WARRANTY

Xtreme, official licensee of Armor All™ warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the

customer must provide proof of the retailers receipt. *Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at info@ArmorAllElectronics.com

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna
- —Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help. FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator&your body.



Please call or email us for customer support or for more information. Toll Free: 877-405-2397 info@ArmorAllElectronics.com

Jem Accessories, Inc. **PROJECT:** AWC8-1016-BLK DATE: 11-27-2023 **DESIGNER:** Phil A

DIE ORIGIN: NEW

ARTBOARD 1 OF 1

FOLDED PAGE SIZE: 3.250W x 4.625H"

PANTONE[®] **BLACK**

CONCEPT ONLY-NOT FOR RELEASE