

FACE TRACKER SMARTPHONE MOUNT

FOLLOWS FACES FOR THE PERFECT VIDEO



855.999.8041 | WWW.XTREMECABLES.COM


WHAT'S INSIDE:

Face Tracker Smartphone Mount User Manual Requires 3X AA batteries (Batteries not included)

DOWNLOAD THE APP

Download the Live360 App from the Apple App Store (iPhone) or from the Google Play Store (Andriod) or scan the QR code on page 3 to downlad.

KNOW YOUR FACE TRACKER MOUNT



USING YOUR FACE TRACKER

- 1. *Install the batteries*: Open the battery cover, install 3X AA alkaline batteries according to the direction marked in the battery and then replace the battery cover.
- 2. *Install mobile phone*: Open the mounts arms and slide the mobile phone into the extendable arms with the mobile phone facing forward.
- 3. *To Power on:* Press and hold the power button until the red light flashes.
- 4. *To Power off:* Press and hold the power button until the red light goes out.

CONNECTING YOUR PHONE AND THE MOUNT

- Make sure that your phone's Bluetooth and location settings are
- 2. Make sure the mount is powered on. The red LED will be flashing.
- 3. Activate the App.
- 4. The App will automatically connect to the mount in approximately 3 to 6 seconds. The mounts blue LED will flash and the App's Bluetooth indicator will display.

Note: Do not try manually pair the phone to the mount. This is not the method for pairing. The phone and mount will automatically connect when the App is activated.

Tips:

- 1. Some mobile phone models may have Bluetooth link delay. Please wait patiently for Bluetooth automatic connection to succeed or restart the App and to retry automatic connection.
- 2. The mount will automatically shutdown when it looses Bluetooth conection for approximately 40 seconds.
- 3. The App will follow faces and not other objects and it can loose track if movement is too fast.



ONE YEAR WARRANTY

Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service: $\underline{customerservice@xtremecables.com}$

FCC Compliance This device complies with Part 15 of the FCC. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Specifications and operation subject to change without prior notice. Some content may differ from how the product works with your specific device.

Note: The face tracker requires 3X AA batteries (Batteries not included)

▲WARNING:

- Always purchase the correct size and grade of battery most suitable for intended use.
- Do not mix old and new batteries, alkaline, standard (Carbon - Zinc) or rechargeable (Nickel-cadmium) batteries.
- Clean the battery contacts and those of the device prior to battery installation.
- 4) Ensure the batteries are installed correctly with the regard to polarity (+ and -).
- Always remove batteries if consumed or if product is to be left unused for a long time.

SPECIFICATIONS:

37° Downward Rotation

Compatible with: iOS and Android Supported Phone Dimensions: 56-100MM Max Load: 265G Angle: 360° Horizontal Rotation 37° Upward Rotation



4

IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
- —Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- —Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.